


**S|E|D**rive

# Vector inverter for lifts with asynchronous motors



**ADL100**  
**ADL200**

■ ■ ■ ■ .... Functions description  
and parameters list

**GEFRAN**

## Information about this manual

---

This manual explains the functions and the description of the parameters.

The informations about mechanical installation, electrical connection and fast start-up can be found on the ADV200 Quick start guide.

The whole set of manuals (included the expansions and field bus manuals) can be found on the CD provided with the drive.

### Software version

This manual is updated according the software version V 2.X.0

Variation of the number replacing "X" have no influence on the functionality of the device.

The identification number of the software version is indicated on the identification plate of the drive or can be checked with the **Firmware ver.rel** parameter.

### General information

---

#### Note !

In industry, the terms "Inverter", "Regulator" and "Drive" are sometimes interchanged. In this document, the term "Drive" will be used.

---

Before using the product, read the safety instruction section carefully. Keep the manual in a safe place and available to engineering and installation personnel during the product functioning period.

Gefran S.p.A has the right to modify products, data and dimensions without notice. The data can only be used for the product description and they can not be understood as legally stated properties.

Thank you for choosing this Gefran product.

We will be glad to receive any possible information which could help us improving this manual.

The e-mail address is the following: [techdoc@gefran.com](mailto:techdoc@gefran.com).

All rights reserved.

## Table of Contents

---

<b>Information about this manual.....</b>	<b>2</b>
Symbols used in the manual.....	4
<b>A - Programming .....</b>	<b>5</b>
A.1 Menu display modes .....	5
A.2 Programming of “function block” analog and digital input signals .....	5
A.3 Variable interconnections mode .....	5
<b>B - Parameters and functions description (Expert list) .....</b>	<b>7</b>
Legend.....	7
1 - MONITOR .....	8
2 - DRIVE INFO .....	10
3 - STARTUP WIZARD .....	13
4 - DRIVE CONFIG .....	14
5 - LIFT .....	17
5.1 – SPEED .....	17
5.2 – RAMPS .....	18
5.3 – LIFT SEQUENCES.....	20
5.4 – MECHANICAL DATA .....	23
5.5 – DISTANCE.....	25
5.6 – EMERGENCY MODE .....	30
5.7 – LIFT IN/OUT .....	30
5.8 –PRE - TORQUE .....	40
5.9 – LIFT ALARMS.....	41
6 - .....	45
7 - .....	45
8 - .....	45
9 - .....	45
10 - DIGITAL INPUTS .....	46
11 - DIGITAL OUTPUTS .....	47
12 - ANALOG INPUTS.....	48
13 - ANALOG OUTPUTS.....	51
14 - MOTOR DATA .....	53
15 - ENCODER CONFIG.....	56
16 - SPEED REG GAINS .....	59
17 - REGULATOR PARAM .....	63
18 - TORQUE CONFIG .....	65
19 - VF PARAMETERS .....	67
20 - FUNCTIONS .....	70
20.1 - FUNCTIONS/INERTIA COMP.....	70
20.2 - FUNCTIONS/DC BRAKING .....	70
20.3 - FUNCTIONS/MOTOR OVERLOAD .....	72
20.4 - FUNCTIONS/BRES OVERLOAD .....	73
20.5 - FUNCTIONS/DOMAIN PAR SET.....	73
20.6 - FUNCTIONS/SPEED CAPTURE .....	75
20.7 - FUNCTIONS/COMPARE .....	75
20.8 - FUNCTIONS/PADS .....	76
21 - COMMUNICATION .....	77
21.1 - COMMUNICATION/RS232 .....	77
21.2 - COMMUNICATION/FIELDBUS CONFIG .....	77
21.3 - COMMUNICATION/FIELDBUS M2S .....	78
21.4 - COMMUNICATION/FIELDBUS S2M .....	80
21.5 - COMMUNICATION/WORD COMP .....	82
21.6 - COMMUNICATION/WORD COMP .....	83
22 - ALARM CONFIG .....	85
23 - ALARM LOG .....	93
PARAMETERS ON SELECTION LISTS, BUT NOT DISPLAYED ON KEYPAD .....	94
<b>C - SELECTION LISTS.....</b>	<b>98</b>
L_ANOUT .....	98
L_CMP .....	98
L_DIGSEL1 .....	98
L_DIGSEL2 .....	99
L_DIGSEL3 .....	99
L_FBS2M .....	99
L_LIM .....	100
L_MLTREF .....	100
L_REF .....	100
L_SCOPE .....	100
L_VREF .....	100

---

L_WDECOMP .....	100
<b>D - Block Diagrams .....</b>	<b>102</b>
System diagram index .....	102
Drive overview (DrvOverview) .....	102
ADL1 application index (ADL1FunIndex).....	103
Expansion card digital inputs (DigImpExp).....	106
Expansion card digital outputs (DigOutExp).....	107
Analog inputs .....	108
Analog outputs.....	109
Encoder config.....	110
SLS control (ControlVf).....	111
Functions .....	112
Torque control (TorqueCtrl).....	114
Gains adaptive (GainAdapt) .....	115
<b>Appendix - 1.0 CANopen interface .....</b>	<b>117</b>
1.1 CANopen functions.....	117
1.2 CANopen management .....	120
1.3 Process Data Channel Control .....	120
1.4 SDO management.....	122
1.5 Alarms .....	122
1.6 Configuration example.....	124
<b>Appendix - 2.0 Operation according to the DS402 profile.....</b>	<b>131</b>

---

## Symbols used in the manual



**Warning**

Indicates a procedure, condition, or statement that, if not strictly observed, could result in personal injury or death.

*Indique le mode d'utilisation, la procédure et la condition d'exploitation. Si ces consignes ne sont pas strictement respectées, il y a des risques de blessures corporelles ou de mort.*



**Caution**

Indicates a procedure, condition, or statement that, if not strictly observed, could result in damage to or destruction of equipment.

*Indique et le mode d'utilisation, la procédure et la condition d'exploitation. Si ces consignes ne sont pas strictement respectées, il y a des risques de détérioration ou de destruction des appareils.*



**Attention**

Indicates that the presence of electrostatic discharge could damage the appliance. When handling the boards, always wear a grounded bracelet.

*Indique que la présence de décharges électrostatiques est susceptible d'endommager l'appareil. Toujours porter un bracelet de mise à la terre lors de la manipulation des cartes.*



**Note !**

Indicates a procedure, condition, or statement that should be strictly followed in order to optimize these applications.

*Indique le mode d'utilisation, la procédure et la condition d'exploitation. Ces consignes doivent être rigoureusement respectées pour optimiser ces applications.*

## A.1 Menu display modes

The programming menu can be displayed in two modes, which can be selected using the Access mode parameter (04 - DRIVE CONFIG menu):

- **Easy** (default) only the main parameters are displayed.
- **Expert** all the parameters are displayed.

## A.2 Programming of “function block” analog and digital input signals

The signals, variables and parameters of each single “function block” of the drive are interconnected in order to achieve the configurations and controls inside the control system.

These can be managed and modified using the keypad, PC configurator or fieldbus programming.

The programming mode is based on the following logic:


**Src** (source; i.e.: **Ramp ref 1 src**, PAR: 610)

This term defines **the source of the function block input**, i.e. the signal to be processed in the function block.

The different configurations are defined in the relative **selection lists**.

**Mon** (display; i.e.: **Ramp ref 1 mon**, PAR: 620)

This term refers to the **variable output from the function block, which is the result of the calculations performed on the actual block**.



## A.3 Variable interconnections mode

The **source (src)** allows the desired control signal to be assigned to the function block input.

This operation is performed by using specific selection lists.

Possible control signal sources:

### 1 – Physical terminal

The analog and digital signals come from the terminal strip of the regulation card and/or from those of the expansion cards.

### 2 – Drive internal variables

Internal drive control system variables, from “function block” calculations, sent via keypad, PC configurator or fieldbus.

### Practical example

The following examples illustrate the philosophies and methods with which more or less complex operations are performed in the single “function blocks”, the results of which represent the output of the block.

• Example: Changing the Speed Reference source

The main drive reference (in the default configuration) **Ramp ref 1 mon** (PAR: 620) is generated by the output of the function block “**Ramp setpoint Block**”.


Its default source is the **Analog input 1 mon** signal (PAR: 1500), from the output of the function block “**Analog input 1 Block**”, which in this case refers to analog input 1 of the signal terminal strip.

To change the reference source from the analog input to a digital reference inside the drive, the input signal must be changed to “**Ramp setpoint Block**”.

Enter the **Ramp ref 1 src** parameter (PAR: 610) and set a new reference, selecting it from among those listed in the L\_MLTREF selection list, for example **Dig ramp ref 1** (PAR: 600).

• Example: Inverting the analog reference signal

To invert the “**Analog input 1X Block**” output signal, the value of the **An inp 1X sign src** parameter (PAR: 1626), which has a default setting of Null (no operation), must be changed by selecting the source of the command signal from among those listed in the L\_DIGSEL 2 selection list, for example **Digital input X mon, One** (function always enabled), etc.



The diagrams above illustrate the internal processing philosophy of the single “function blocks” and the result of these changes on the other interconnected “function blocks”.

**Note !**

This section contains a brief description of the functions of the other parameters in the function blocks not included for the changes in the example.

The **Ramp ref invert src** parameter (PAR: 616) can be used to select the source for the command to reverse the “**Ramp setpoint**” function block output.

The output signal from the “**Ramp setpoint**” block is displayed in the **Ramp ref 1 mon** parameter (PAR: 620).

## B - Parameters and functions description (Expert list)

### Legend

0	1	2	3	4	5	6	7	8	9	10
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>1 - MONITOR</b>										( Level 1 menu )
1.1	250	Output current	A	FLOAT	16/32	0.0	0.0	0.0	R	FVS
1.2	252	Output voltage	V	FLOAT	16/32	0.0	0.0	0.0	R	FVS
<b>21.5 - COMMUNICATION/WORD COMP</b>										( Level 2 menu )
21.5.1	4400	Word bit0 src	LINK	16BIT		6000	0	16384	ERW	FVS
21.5.16	4430	Word bit15 src	LINK	16BIT		6000	0	16384	ERW	FVS
			L_DIGSEL1						( Selection List ) [*]	

0	Indexing of the menu and parameter	
1	Parameter identifier	
2	Parameter description	
3	UM: unit of measure	
4	Type of parameter BIT Boolean, from modbus seen as 16 bits ENUM Selection list, from modbus seen as 16 bits FLOAT Real, from modbus seen as 32 bits INT16 Integer with sign 16 bits, from modbus seen as 16 bits INT32 Integer with sign 32 bits, from modbus seen as 32 bits ILINK Selection list, from modbus seen as 16 bits LINK Selection list, from modbus seen as 16 bits UINT16 Integer without sign 16 bits, from modbus seen as 16 bits UINT32 Integer without sign 32 bits, from modbus seen as 32 bits	
5	Format of data exchanged on Fieldbus (16BIT, 32BIT)	
6	Default value	CALCF Value calculated as a number with floating point
7	Minimum value	CALCI Value calculated as a whole number
8	Maximum value	SIZE Value depending on the size of the drive

9	<b>Accessibility :</b> E Expert R Read S Size (set value depending on the size of the device) W Write (scrittura) Z parameters that can be modified ONLY with the drive disabled
10	Available in regulation mode: V = V/f Control (open loop) / PM synchronous S = Vect Flux OL F = Vect Flux CL (closed loop)
[*]	<b>Selection lists:</b> The "Sorgente.../Sorg..." format parameters are linked to a selection list. The source of the signal that will control the parameter can be selected from the list indicated. The lists are indicated in paragraph C of this manual.

# 1 - MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.1	250	<b>Output current</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	R	FVS
		The drive output current is displayed.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.2	252	<b>Output voltage</b>	V	FLOAT	16/32BIT	0.0	0.0	0.0	R	FVS
		The drive line voltage output is displayed.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.3	254	<b>Output frequency</b>	Hz	FLOAT	16/32BIT	0.0	0.0	0.0	R	FVS
		The drive output frequency is displayed.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.4	628	<b>Ramp setpoint</b>	rpm	INT16	16/32BIT	0	0	0	R	FVS
		The ramp reference is displayed. This is the speed value the drive must reach at the end of the ramp.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.5	664	<b>Speed setpoint</b>	rpm	INT16	16/32BIT	0	0	0	R	FVS
		The speed reference is displayed. This is the value measured at the output of the speed reference circuit.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.6	260	<b>Motor speed</b>	rpm	INT16	16/32BIT	0	0	0	R	FVS
		The actual output speed of the motor is displayed (in FOC = speed measured by the encoder, in SLS/VF = speed estimated by the drive).								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.7	270	<b>DC link voltage</b>	V	FLOAT	16/32BIT	0.0	0.0	0.0	ER	FVS
		The direct voltage of the intermediate circuit capacitors is displayed (DC-Bus).								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.8	272	<b>Heatsink temperature</b>	C	INT16	16BIT	0	0	0	ER	F_S
		The temperature measured on the drive heatsink is displayed.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.9	280	<b>Torque current ref</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	ER	F_S
		The current reference used for torque control is displayed (in the sensorless vector and field-oriented vector modes).								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.10	282	<b>Magnet current ref</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	ER	FVS
		The magnetizing current reference is displayed (in the sensorless vector and field-oriented vector modes).								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.11	284	<b>Torque current</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	ER	FVS
		The actual torque current value is displayed.								
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
1.12	286	<b>Magnet current</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	ER	FVS
		The actual magnetizing current value is displayed.								

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.13</b>	<b>3212</b>	<b>Motor overload accum</b>		UINT16	16/32BIT	0	0	100	ER	FVS
-------------	-------------	-----------------------------	--	--------	----------	---	---	-----	----	-----

The motor overload level is displayed (100% = alarm threshold).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.14</b>	<b>368</b>	<b>Drive overload accum</b>		UINT16	16/32BIT	0	0	100	ER	FVS
-------------	------------	-----------------------------	--	--------	----------	---	---	-----	----	-----

The drive overload level is displayed. An instantaneous overload of 200% of the drive rated current is allowed for 10s. The thermal image  $I^2t$  adjusts the drive output current thresholds. During normal operation, the instantaneous output current value can reach 200% of the drive rated current. When the overload level par. 368 **Drive overload accum** reaches 100%, the output current threshold is reduced to 100% of the rated current, and stays at that value until the  $I^2t$  integrator cycle is complete. At this point the instantaneous overload of 200% or 150% (below 3Hz) will be re-activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.15</b>	<b>3260</b>	<b>Bres overload accum</b>		UINT16	16/32BIT	0	0	100	ER	FVS
-------------	-------------	----------------------------	--	--------	----------	---	---	-----	----	-----

The braking resistor overload limit is displayed (100% = alarm threshold).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.16</b>	<b>1066</b>	<b>Enable state mon</b>		BIT	16BIT	0	0	1	R	FVS
-------------	-------------	-------------------------	--	-----	-------	---	---	---	---	-----

The drive **Enable** command status is displayed. Voltage must be present on terminal 7. The FR Forwardstart command is needed to start the inverter.

- |                   |                |
|-------------------|----------------|
| <b>1 Enabled</b>  | drive enabled  |
| <b>0 Disabled</b> | drive disabled |

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.17</b>	<b>1068</b>	<b>Start state mon</b>		BIT	16BIT	0	0	1	R	FVS
-------------	-------------	------------------------	--	-----	-------	---	---	---	---	-----

The drive **Start** command status is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.18</b>	<b>1070</b>	<b>FastStop state mon</b>		BIT	16BIT	0	0	1	R	FVS
-------------	-------------	---------------------------	--	-----	-------	---	---	---	---	-----

The drive **FastStop** command status is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.19</b>	<b>1200</b>	<b>Digital input X mon</b>		UINT16	16BIT	0	0	0	R	FVS
-------------	-------------	----------------------------	--	--------	-------	---	---	---	---	-----

The status of the digital inputs of the expansion card is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if voltage is supplied to the corresponding input terminal.

- |                          |
|--------------------------|
| <b>1 Input enabled.</b>  |
| <b>0 Input disabled.</b> |

Example:

0 0 0 0 0 0 0 0 0 0 1 1	Enable DI 1
-------------------------	----------------

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>1.20</b>	<b>1400</b>	<b>Digital output X mon</b>		UINT16	16BIT	0	0	0	R	FVS
-------------	-------------	-----------------------------	--	--------	-------	---	---	---	---	-----

The status of the digital outputs of the expansion card is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if voltage is supplied to the corresponding output terminal.

- |                           |
|---------------------------|
| <b>1 Output enabled.</b>  |
| <b>0 Output disabled.</b> |

Example:

0 0 0 0 0 0 0 0 0 0 1 1	DO 1 DO 2
-------------------------	--------------

## 2 - DRIVE INFO

This menu displays the information for identifying and configuring the drive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.1	480	<b>Drive series</b>		UINT16		3	0	0	R	FVS

The drive series identification code is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.2	482	<b>Drive size</b>		UINT16		0	0	0	RS	FVS

The drive size identification code is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.3	484	<b>Drive family</b>		ENUM		No Power	0	0	RS	FVS

The available mains voltage is displayed (e.g. 400V). The undervoltage alarm refers to this voltage value.

The condition **No power** occurs when the regulation board has just left from production and has never been configured for any power. The configuration adjustment for a given power is achieved by linking it to a power board and running a **Save parameters**.

- 0** No Power
- 1** 230V..480V
- 2** -
- 3** -
- 4** 230V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.4	486	<b>Drive region</b>		ENUM		EU	0	1	R	FVS

Setting of the geographical area in which the drive is to be used (Europe or USA). This setting determines the factory voltage and power supply frequency values.

- 0** EU (400V / 50Hz)
- 1** USA (460 / 60 Hz)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.5	488	<b>Drive cont current</b>	A	FLOAT		CALCF	0.0	0.0	RZS	FVS

The current that the drive can deliver continuously according to size, supply voltage and programmed switching frequency is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.6	490	<b>Firmware ver.rel</b>		UINT16		0	0	0	R	FVS

The version number and release number of the drive firmware are displayed. On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.7	496	<b>Firmware type</b>		UINT16		0	0	0	R	FVS

Identifies the version of the special firmware installed in the drive

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.8	504	<b>Application ver.rel</b>		UINT16		0	0	0	ER	FVS

The version and release number of the application used in the drive are displayed. On the keypad these are displayed in version.release format. When the parameter is read via serial line or fieldbus the version is returned in the high byte and the release in the low byte.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.9	506	<b>Application type</b>		UINT16		0	0	0	ER	FVS

The type of application currently used by the drive is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.10	510	<b>Time drive power on</b>	h:min	UINT32		0	0.0	0.0	ER	FVS																																
The total time for which the drive has been powered is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.11	512	<b>Time drive enable</b>	h:min	UINT32		0	0.0	0.0	ER	FVS																																
The time for which the enable hardware contact on the drive has been connected is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.12	514	<b>Number power up</b>		UINT16		0	0	0	ER	FVS																																
The number of times the drive has been powered on is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.13	516	<b>Power S/N</b>	h:min	UINT32		0	0.0	0.0	ER	FVS																																
The total time for which the drive fan has been running is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.14	520	<b>Product S/N</b>		UINT32		0	0	0	R	FVS																																
The drive serial number is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.15	522	<b>Regulation S/N</b>		UINT32		0	0	0	R	FVS																																
The drive regulation card serial number is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.16	524	<b>Power S/N</b>		UINT32		0	0	0	R	FVS																																
The drive power card serial number is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.17	526	<b>Power file ver.rel</b>		UINT16		0	0	0	ER	FVS																																
The drive power card configuration release is displayed.																																										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod																																
2.18	530	<b>Slot 1 card type</b>		ENUM		None	0	0	R	FVS																																
2.19	532	<b>Slot 2 card type</b>		ENUM		None	0	0	R	FVS																																
2.20	534	<b>Slot 3 card type</b>		ENUM		None	0	0	R	FVS																																
The type of expansion card installed in the relative slot of the drive is displayed.																																										
<table> <tr><td>0</td><td>None</td></tr> <tr><td>257</td><td>I/O 1</td></tr> <tr><td>1281</td><td>I/O 2</td></tr> <tr><td>2305</td><td>I/O 3</td></tr> <tr><td>3841</td><td>I/O 4</td></tr> <tr><td>4865</td><td>I/O 5</td></tr> <tr><td>5377</td><td>I/O 6</td></tr> <tr><td>8</td><td>Enc 1</td></tr> <tr><td>264</td><td>Enc 2</td></tr> <tr><td>520</td><td>Enc 3</td></tr> <tr><td>776</td><td>Enc 4</td></tr> <tr><td>1032</td><td>Enc 5</td></tr> <tr><td>4</td><td>Can/Dnet</td></tr> <tr><td>260</td><td>Profibus</td></tr> <tr><td>516</td><td>Gdnet</td></tr> <tr><td>255</td><td>Unknown</td></tr> </table>											0	None	257	I/O 1	1281	I/O 2	2305	I/O 3	3841	I/O 4	4865	I/O 5	5377	I/O 6	8	Enc 1	264	Enc 2	520	Enc 3	776	Enc 4	1032	Enc 5	4	Can/Dnet	260	Profibus	516	Gdnet	255	Unknown
0	None																																									
257	I/O 1																																									
1281	I/O 2																																									
2305	I/O 3																																									
3841	I/O 4																																									
4865	I/O 5																																									
5377	I/O 6																																									
8	Enc 1																																									
264	Enc 2																																									
520	Enc 3																																									
776	Enc 4																																									
1032	Enc 5																																									
4	Can/Dnet																																									
260	Profibus																																									
516	Gdnet																																									
255	Unknown																																									

**Note!**

See Appendix to the Quick start guide for further information on the expansion cards.

SLOT 3 indicates the presence of the CAN on the regulation card in versions ADL200---C

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.21	536	<b>Slot 1 card S/N</b>		UINT32		0	0	0	R	FVS
2.22	538	<b>Slot 2 card S/N</b>		UINT32		0	0	0	R	FVS
2.23	540	<b>Slot 3 card S/N</b>		UINT32		0	0	0	R	FVS

The serial number of the expansion card installed in the relative slot of the drive is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.24	546	<b>Fw encoder ver.rel</b>		UINT16		0	0	0	R	FVS

The version and release number of the encoder firmware used in the drive are displayed. On the keypad these are displayed in version.release format. When the parameter is read via serial line or fieldbus the version is returned in the high byte and the release in the low byte.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
2.25	548	<b>Fw encoder type</b>		UINT16		0	0	0	R	FVS

The type of firmware installed in the encoder is displayed.

## 3 - STARTUP WIZARD

The startup wizard menu suggests a procedure for commissioning the drive quickly with a reduced number of settings. Advanced customization requires the use of the single parameters relating to the specific performance levels. Refer to the procedure described in chapter 9 **Commissioning via keypad** in the Quick start-up guide.

## 4 - DRIVE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

4.1	550	<b>Save parameters</b>		BIT		0	0	1	RW	FVS
-----	-----	------------------------	--	-----	--	---	---	---	----	-----

Any changes to parameter values immediately affect drive operations, but are not automatically saved in the permanent memory. The “Save Parameters” command is used to save current parameter values in the permanent memory.

Any changes that are not saved will be lost when the drive is switched off.

To save parameters follow the procedure described in STEP 9 of the **Startup wizard**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

4.2	552	<b>Regulation mode</b>		ENUM		SSC	0	3	RWZ	FVS
-----	-----	------------------------	--	------	--	-----	---	---	-----	-----

The ADL200 is capable of operating with different control modes:

- 0    SSC (Sensorless Scalar Control)
- 1    Flux vector OL
- 2    Flux vector CL
- 3    Autotune

The open loop **SSC** mode is the simplest type of asynchronous motor control, as the only parameters required are the rated voltage, current and frequency of the motor.

The open loop **SSC** control mode is factory-set and does not require any speed feedback. The natural variation in speed generated by machine load induction (slippage) can be compensated using **Slip comp** and **Slip comp filter**.

In V/f mode a single drive can be used to control several asynchronous motors, even of different sizes, connected in parallel, provided the sum of the currents of the single motors is less than the drive rated current. If using several motors connected in parallel, be sure to provide adequate thermal protection for each single motor.

Closed loop control is also possible in the **SSC** mode. It requires a speed reading by a digital encoder on the motor shaft; to enable encoder feedback, you must set parameter **2444 Slip comp mode =1**.

An optional card is necessary in order to acquire the encoder signals. The speed feedback supplied by the encoder is used to compensate motor slippage in the different load conditions, to achieve accurate control and greater precision of the actual motor speed.

With the **sensorless vector control (Flux vector OL)** mode, high speed and torque precision can be achieved at low motor rpm. The drive has a powerful algorithm that uses a self-tuning procedure to obtain all the electric measurements of the motor. This allows the speed and position of the motor shaft to be estimated, enabling operation similar to that of a drive with feedback, both in terms of the response in torque to load variations, and of the regularity of rotation even at very low rmp.

In the **field oriented vector mode (Flux vector CL)** an encoder is required for closed loop feedback. With this mode it is possible to achieve extremely high dynamic responses thanks to the regulation bandwidth, maximum torque even with the rotor blocked, speed and torque control. Numerous regulation parameters can be used to adjust the drive to each specific application, for instance adaptive gains, system inertia compensation, etc..

If the **Startup wizard** procedure is not used, self-tuning of the motor parameters is possible in the **self-tuning mode (Autotune)**. This procedure must be used for both self-tuning with the engine standing still and with the motor turning.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

4.3	554	<b>Access mode</b>		ENUM		Easy	0	1	RW	FVS
-----	-----	--------------------	--	------	--	------	---	---	----	-----

- 0    Easy
- 1    Expert

The **Easy** mode gives access to a list of parameters that can be used for rapid drive commissioning. This type of configuration is suitable for the majority of applications.

Setting the parameter to **Expert** gives access to all the parameters in the firmware. This mode allows an extremely high level of customization to be achieved in order to exploit the potential of the ADL200 to the full.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

4.5	558	<b>Application select</b>		ENUM		Application 1	0	2	ERWZ	FVS
-----	-----	---------------------------	--	------	--	---------------	---	---	------	-----

Selection of which IEC 61131-3-compliant application to make operational.

- 0    None
- 1    Application 1
- 2    Application 2

The drive is supplied already incorporating a number of applications developed in the IEC 61331-3 environment. To use these, configure the desired application, run save parameter, switch the drive off and then on again. In the default configuration the drive starts with the EFC lift application (see menu 5 - LIFT for the description of this application).

### Note!

The **Load Default** command (par. 580) does not modify this parameter

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.6	560	<b>Mains voltage</b>	V	ENUM		400 V	SIZE	SIZE	ERWZS	FVS
Setting of the available mains voltage value in Volts. Detection of the undervoltage alarm refers to this value.										
<b>0</b> 200 V <b>1</b> 230 V <b>2</b> 380 V <b>3</b> 400 V <b>4</b> 415 V <b>5</b> 440 V <b>6</b> 460 V <b>7</b> 480 V <b>8</b> 575 V <b>9</b> 690 V										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.7	570	<b>Password</b>		UINT32		0	0	99999	ERW	FVS
You can enter a <b>password</b> to protect the parameters from unauthorized tampering: the password can consist of a combination of a maximum of any 5 figures that can be selected by the user. All parameters are locked, except this one and <b>Save parameters</b> .										
entering the password, press the E key, then enter the password and press the E key again to enable it (a password enabled message ( <b>Enabled</b> ) is displayed).										
So that the password remains valid even after switching the unit off and then switching it back on, save it using the <b>Save parameters</b> command.										

When the password is enabled any attempts to modify a parameter are blocked and the **Password enabled** message is displayed.

To disable the password, enter the **Password** parameter (570) in the **DRIVE CONFIG** menu.

Check that the password is enabled (**Enabled**), press E and enter the combination of figures that make up the password. Press E again. A message is displayed telling you the password is no longer enabled (**Disabled**).

To make sure the password continues to be disabled even after switching the unit off and then switching it back on, save this configuration using the **Save parameters** command.

When an incorrect password is entered, the **Password wrong** message is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.8	572	<b>Application key</b>		UINT32		0	0	4294967295	ERW	FVS
This parameter can be used to enter the key for enabling the PLC application.										
You may need to enter a key to definitively enable some PLC applications. Please contact Gefran for details about which PLC applications require the key.										
If executing an application that envisages a key verification and the key is incorrect, enabling is forced for 200 hours (time drive enabled).										

In this phase a message is displayed informing you that the period of forced enabling time is about to expire.

At the first power-on after the 200 hours an alarm is generated and the application does not start.

Please contact Gefran for the numerical value of the key.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.9	574	<b>Startup display</b>		INT16		-1	-1	20000	ERW	FVS
It is possible to set the parameter that will automatically be displayed when the drive is switched on.										
If set to -1 the main menu is automatically displayed when the drive is turned on.										
If set to 0 the display page is automatically displayed when the drive is turned on.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.10	576	<b>Display backlight</b>		BIT		0	0	1	ERW	FVS
Enabling of the backlight on the drive display.										
If set to 0 the display backlight will go off when the drive has been on for three minutes.										
If set to 1 the backlight will stay on for as long as the drive is powered.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.11	578	<b>Language select</b>		ENUM		English	0	4	RWZ	FVS
Setting of the drive programming language.										
0 English 1 Italian 2 French 3 German 0 Spanish										

**Note!** The **Load Default** command (par. 580) does not modify this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.12	580	<b>Load default</b>		BIT		0	0	1	RWZ	FVS
Transfers the standard factory settings to the drive memory ("Def" column in the parameters table).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.13	590	<b>Save par to keypad</b>		BIT		0	0	1	RW	FVS
Transfers the parameters currently stored in the drive and saves them in the keypad memory (See ADL200 Quick Start manual, chapter 8.8).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.14	592	<b>Load par from keypad</b>		BIT		0	0	1	RWZ	FVS
Transfers the parameters from the keypad memory to the drive (See ADL200 Quick Start manual, chapter 8.8).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.15	594	<b>Keypad memory select</b>		UINT16		1	1	5	ERW	FVS
Selection of the area of the keypad memory to which to transfer and save the parameters stored in the drive.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.16	596	<b>Save to SD card</b>		BIT		0	0	1	RW	FVS
Transfers the drive parameters to the SD memory card (See chapter 8.9 of the Quick start-up guide).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
4.17	598	<b>Load from SD card</b>		BIT		0	0	1	RWZ	FVS
Transfers the parameters from the SD memory card to the drive (See chapter 8.9 of the Quick start-up guide).										

## 5 - LIFT

### 5.1 – SPEED

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.1	11002	Travel units sel	Hz	ENUM		0	0	2	RW	FVS

Selection of the unit of measure for speed references.

**0** Hz (output frequency)

**1** m/s (cabin speed and depends on the mechanical constant)

**2** Rpm (speed of the motor shaft)

When the unit of measure is modified the conversion constants are re-calculated, the units of measure are changed in the parameter list and the multispeed values are converted into the new unit of measure (the result may contain approximations due to the conversion calculations).

A variable representing the speed of the cabin in m/s is always available (PAR 12210).

There are fixed units of measure for the acceleration and deceleration parameters (m/s<sup>2</sup>), and for jerks (m/s<sup>3</sup>).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.2	11020	Multi speed 0	Hz	FLOAT		5.00	-10000	10000	RW	FVS

Setting of the multispeed 0 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default low speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.3	11022	Multi speed 1	Hz	FLOAT		50.00	-10000	10000	RW	FVS

Setting of the multispeed 1 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default high speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.4	11024	Multi speed 2	Hz	FLOAT		20.00	-10000	10000	RW	FVS

Setting of the multispeed 2 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default maintenance speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.5	11026	Multi speed 3	Hz	FLOAT		0.00	-10000	10000	RW	FVS

Setting of the multispeed 3 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.6	11028	Multi speed 4	Hz	FLOAT		0.00	-10000	10000	RW	FVS

Setting of the multispeed 4 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.7	11030	Multi speed 5	Hz	FLOAT		0.00	-10000	10000	RW	FVS

Setting of the multispeed 5 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.8	11032	Multi speed 6	Hz	FLOAT		0.00	-10000	10000	RW	FVS

Setting of the multispeed 6 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.9	11034	Multi speed 7	Hz	FLOAT		0.00	-10000	10000	RW	FVS

Setting of the multispeed 7 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.10	12010	Actual multi spd sel		ENUM					R	FVS

The currently selected speed is displayed.


- 0 Multi speed 0
- 1 Multi speed 1
- 2 Multi speed 2
- 3 Multi speed 3
- 4 Multi speed 4
- 5 Multi speed 5
- 6 Multi speed 6
- 7 Multi speed 7
- 8 Null

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.1.11	12210	Actual speed ref	m/s	FLOAT					R	FVS

The speed of the cabin is displayed in m/s.

## 5.2 – RAMPS

The lift application envisages an S-shaped ramp function with the possibility of setting 4 independent jerks and linear acceleration and deceleration factors, as in the standard profile illustrated in the figure below.



The Acc ini Jerk, Acceleration and Acc end jerk values used to execute the acceleration ramp are calculated by multiplying the corresponding parameters by the acceleration ramp factor (Percent acc factor), while the Dec ini jerk, Deceleration and Dec end jerk values used to execute the deceleration ramp are calculated by multiplying the corresponding parameters by the deceleration ramp factor (**Percent dec factor**, PAR 11056).

When the **Start** command is removed, the reference speed is zero regardless of the reference selected in the multispeeds. In this final part of the profile the jerk deceleration values are used directly (not multiplied by **Percent dec factor**, PAR 11056) with the **Stop deceleration** parameter as the linear deceleration. The factors for the final section of the profile are also used in case of a Stop lift emergency condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.2.1	11040	Acc ini Jerk	m/s <sup>3</sup>	FLOAT		0.50	0.01	20	RW	FVS

Setting of the jerk value for the first part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.2.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT		0.60	0.01	10	RW	FVS

Setting of the maximum acceleration value.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.2.3	11044	Acc end jerk	m/s <sup>3</sup>	FLOAT		1.40	0.01	20	RW	FVS

Setting of the jerk value for the last part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.2.4</b>	<b>11046</b>	<b>Dec ini jerk</b>	m/s <sup>3</sup>	FLOAT		1.40	0.01	20	RW	FVS
Setting of the jerk value for the first part of the deceleration.										
<b>5.2.5</b>	<b>11048</b>	<b>Deceleration</b>	m/s <sup>2</sup>	FLOAT		0.60	0.01	10	RW	FVS
Setting of the maximum deceleration value.										
<b>5.2.6</b>	<b>11050</b>	<b>Dec end jerk</b>	m/s <sup>3</sup>	FLOAT		0.50	0.01	20	RW	FVS
Setting of the jerk value for the last part of the deceleration.										
<b>5.2.7</b>	<b>11052</b>	<b>Stop deceleration</b>	m/s <sup>2</sup>	FLOAT		0.70	0.01	10	RW	FVS
Setting of the maximum deceleration value used when the start command is removed.										
<b>5.2.8</b>	<b>11054</b>	<b>Percent acc factor</b>	Perc	FLOAT		100.00	0	10000	RW	FVS
Setting of the acceleration factor multiplier. If set to 100 the ramp uses the factors entered in the parameters. If set to a value of less than 100 the lift will tend to accelerate over a longer distance. If set to a value of more than 100 the lift will tend to accelerate over a shorter distance.										
<b>5.2.9</b>	<b>11056</b>	<b>Percent dec factor</b>	Perc	FLOAT		100.00	0	10000	RW	FVS
Setting of the deceleration factor multiplier. If set to 100 the ramp uses the factors entered in the parameters. If set to a value of less than 100 the lift will tend to decelerate over a longer distance. If set to a value of more than 100 the lift will tend to decelerate over a shorter distance.										

## 5.3 – LIFT SEQUENCES

This menu shows the parameters used to manage and define the travel of the lift depending on the status of the inputs and alarms. The structure of the lift sequences is summarised below.



### Starting sequence:

- 1 Reading of the enable hardware input and checking for alarms (enabling is aborted in case of an alarm)
- 2 Detection of the **Enable** and **Start** commands as set in the **Sequence start mode** parameter
- 3 When the **Start forward/reverse** command is received, a command is sent to close the contactors, depending on the direction of travel
- 4 When the time set in **Cont close delay** has elapsed the internal **Enable** lift signal is activated
- 5 The system waits for the magnetisation signal from the drive (**Drive ready**)
- 6 At the end of magnetisation the open brake signal is activated

- 7 The system waits for the brake to be opened (**Brake open delay**)
- 8 When the delay before opening the brake has elapsed the **Start** lift command is sent and movement is enabled.

**Sequence of movement:**

- 1 The motor is started and moves slowly at the speed set in Smooth start speed for the time indicated in **Smooth start delay**
- 2 At the end of **Smooth start delay**, movements are managed by the multispeeds and S-shaped ramp
- 3 When the set speed is exceeded, the **Brake 2 mon** output signal can be used to check that the brake has actually been opened
- 4 The EFC function with space control can be used to change to a slower speed
- 5 When the **Start forward/reverse** signal is lowered the signal indicating arrival at the floor is enabled and the start lift signal is disabled
- 6 The start command can be sent again until the drive reaches zero speed: the operating conditions are restored.

**Stopping sequence:**

- 1 When zero speed is reached the DC stop command is enabled (**SSC control**)
- 2 The application waits the time needed to reach zero speed and sends the command to close brakes 1 and 2
- 3 It waits the time necessary for the brakes to close (Brake close delay) and, if the current is to be reduced with a ramp, it waits for the current limit to reach zero. The internal Enable lift, arrival zone and DC brake signals are then lowered.
- 4 The application waits the time set in **Contactor open delay** and checks that the current supplied is zero, before sending a command to open the contactors.

It is essential to make sure that whenever a drive alarm condition is generated or the drive is disabled, the drive is stopped and a command is sent to open the contactors.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.1	11060	<b>Sequence start mode</b>		ENUM		0	0	2	RW	FVS
Setting of the procedure to start the contactor command sequence.										
0 Start forward/reverse										
1 Enable										
2 Multispeed != 0										

If set to **0** the contactor sequences can be enabled without the Enable command (Enable is only required for motor operation). The Enable signal can be sent by an auxiliary contact of the output contactors.

If set to **1** the contactor sequences can only be enabled if the Enable command is active.

If set to **2** the contactor sequences can be enabled using the multispeed values. Multispeed values other than 0 cause the sequence to start. The start command must also be enabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.2	11062	<b>Cont close delay</b>	ms	INT32		200.00	0	10000	RW	FVS
Setting of the delay time for closing the contactor.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.3	11064	<b>Brake open delay</b>	ms	INT32		0	0	10000	RW	FVS
Setting of the brake opening delay time.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.4	11066	<b>Smooth start delay</b>	ms	INT32		0	0	10000	RW	FVS
Setting of the time for which the <b>Smooth start speed</b> speed is enabled. If this parameter is set to zero, the S-shaped profile is executed directly at the start, and the soft start function is excluded.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.5	11068	<b>Brake close delay</b>	ms	INT32		200.00	0	10000	RW	FVS
Setting of the brake closing delay time.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**5.3.6 11070 Current down delay** ms INT32 0 0 10000 RW FVS

Setting of the time necessary to lower the torque from the limit value enabled during travel to 0. It defines the inclination of the down ramp in the "Current down ramp" function. The purpose of this function is to prevent the immediate removal of motor torque when the brake is closed, which would cause mechanical strain in the cabin.

To avoid this phenomenon when the brake is closed the current limits are brought to the current value in use and then lowered on the ramp.

To enable the function the **Current down delay** parameter must be set to a value other than zero.

This is only possible when **Torque curr lim sel** has a value other than "OFF", otherwise **Current down delay** is forced to zero.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**5.3.7 11072 Contactor open delay** ms INT32 200.00 0 10000 RW FVS

Setting of the contactor opening delay time.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**5.3.8 11078 Speed 0 threshold** rpm INT16 30.00 RW FVS

Setting of the zero speed threshold, below which the zero speed signal is activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**5.3.9 11080 Speed 0 delay** ms UINT16 400.00 0 10000 RW FVS

Setting of the zero speed delay. After the zero speed signal and after the time set in this parameter the zero speed signal is activated. These parameters are used to know the cabin stop.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**5.3.10 11082 Smooth start speed** Hz FLOAT 0.00 0.00 10000.0 RW FVS

Setting of the speed in the smooth start phase.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**5.3.11 11084 Smooth start mode** ENUM 2 1 2 RW FVS


Setting of the soft start mode.

- 1 Speed constant
- 2 Jerk variable

If set to 1 the soft speed is automatically selected after the start command regardless of the selected multispeed. The duration of the smooth speed depends on the **Smooth start delay** parameter: if this parameter is set to zero the selected multispeed is used and not the soft speed. This setting is used in systems with a reducer, as it helps to overcome initial friction before starting with the profile.

If set to 2 an even slower starting mode is set, which uses the start jerk of the variable acceleration in the smooth start phase. Depending on the values set in **Smooth start speed** and **Smooth start delay** the jerk value is calculated at the end of the soft start phase with a linear ramp that changes this jerk from 0 to the calculated value.

The use of a variable value jerk obtains a variable start acceleration that follows a parabolic trajectory, enabling extremely reduced variations in initial speed. This setting is mainly used in systems with gearless motors.




Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.12	11086	Door open speed	m/s	FLOAT		0.00			RW	FVS

Setting of the door opening speed.

Source to enable brake release through the digital input. In standard sequence brake release is controlled by the drive and therefore this parameter is set to ONE. In case that brake release should be conditioned by some external control (e.g. PLC), set this parameter to digital input controlled by PLC.

Internal sequence for brake release will wait until this input is asserted.

During run brake will be closed whenever this input becomes not asserted.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.13	12014	Trip number		INT32		0			R	FVS

The lift journey counter is displayed. The counter increases each time the Start lift signal is activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.3.14	12016	Sequence state		UINT16		0			R	FVS

The lift sequence status is displayed. (see graph)

## 5.4 – MECHANICAL DATA


The parameters described in this menu are used to define the mechanical and physical features of the system.

### Mechanical constants

The mechanical constant defines the ratio between motor rpm and distance travelled by the cabin.

The **ConstMech** can be calculated in two ways, depending on which conversion method is used.

- Directly:                   **Mechanical constant = System speed/(Full scale speed/60)**
- Mechanical data:           **Mechanical constant = ( $\pi * \text{Pulley diameter})/\text{Reduction gear ratio}$**



The mechanical constant is calculated when the drive is turned on and re-calculated each time one of the parameters used to determine this value is modified (**Mechanical calc mode**, **Full scale speed**, **Contract speed**, **Pulley diameter**, **Gearbox ratio**).

The method used to calculate the mechanical constant can be selected regardless of the control mode (**SSC**, **Flux vector OL**, **Flux vector CL**, **Synchronous**) or the unit of measure to be used.

## Weights and inertia

Entering the mechanical features of the system makes it possible to calculate the total inertia applied to the motor.

After modifying these parameters the calculated inertia value is automatically saved in the “**Inertia comp**” parameter to enable correct inertia compensation.

The value of the inertia that can be entered in the “**Inertia**” parameter in the “16 - SPEED REG GAINS” menu is displayed to calculate the speed loop parameters more accurately. This operation is performed automatically when PAR 11162 Calc spd reg gain is enabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.1	11006	<b>Contract speed</b>	m/s	FLOAT		0.5	0	10	RW	FVS

Represents the speed of the system. It is also used to calculate the mechanical constant. The cabin speed in m/s is associated with the full scale speed (par. 628) to obtain the conversion factor (m/rpm).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.2	11008	<b>Mechanical calc mode</b>		INT16		0	0	1	ERW	FVS

Setting of the method for calculating the unit of measure, depending on the speed of the cabin and of the motor (Direct method) or according to the mechanical ratios (Mechanical data method).

- 0 Direct method
- 1 Mechanical data

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.3	11010	<b>Gearbox ratio</b>		FLOAT		90			ERW	FVS

Setting of the ratio between the speed of the motor and of the pulley.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.4	11012	<b>Pulley diameter</b>	m	FLOAT		0.60			ERW	FVS

Setting of the diameter of the pulley.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.5	11150	<b>Car weight</b>	kg	FLOAT		0.00			RW	FVS

Setting of the weight of the cabin.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.6	11152	<b>Counter weight</b>	kg	FLOAT		0.00			RW	FVS

Setting of the weight of the counterweight.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.7	11154	<b>Load weight</b>	kg	FLOAT		0.00			RW	FVS

Setting of the weight of the maximum load for system dimensions.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.8	11156	<b>Rope weight</b>	kg	FLOAT		0.00			RW	FVS

Setting of the weight of the cable.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.9	11158	<b>Gearbox inertia</b>	kgm <sup>2</sup>	FLOAT		0.00			RW	FVS

Setting of the inertia of the mechanical reducer.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.10	11160	<b>Motor inertia</b>	kgm <sup>2</sup>	FLOAT		0.00			RW	FVS

Setting of the motor inertia.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.11	11162	<b>Calc spd reg gains</b>	ENUM	INT		0	0	1	RW	F_

If enabled this writes the inertia value in parameter 2240 **Inertia**, calculates the gains of the speed loop, sets parameters 2200 to 2210 to 100% and writes the calculated values in parameters 2236 **Speed reg P gain**, 2238 **Speed reg I time** and

2242 Bandwidth. The value of the parameter is automatically reset to 0 once calculation starts.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.12	12020	Inertia calculated	$\text{kgm}^2$	FLOAT		0			R	FVS

The inertia of the system with half load applied to the motor is displayed. This value can be entered in the Inertia parameter in the "16 - SPEED REG GAINS" menu.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.4.13	12022	SpeedLineCalc	m/s	FLOAT		0			R	FVS

The linear speed in m/s calculated using the 11010 **Gearbox ratio** and 11012 **Pulley diameter** parameters is displayed.


## 5.5 – DISTANCE

Use of the distances facilitates positioning of the deceleration sensors and is helpful for managing short floors.


The aim of the function that considers distances is to start decelerating from high speed in order to reach the approach speed in proximity to the landing zone.

Up to a maximum of 8 different slow down distances can be managed (real distance between the start of the sensor and the floor) associated with the different multispeeds. The distance to be used is selected after enabling the drive, before the cabin starts to move. Different distances cannot be selected while the cabin is travelling.

If the slow down distance is shorter than the real deceleration distance for the selected target speed, the speed is automatically limited so that the stop is always correct. When this speed limiter is enabled a **Speed target** alarm (warning) is generated.



If the slow down sensor is met during acceleration, the distance required to terminate the acceleration and deceleration phases may be greater than the distance available: in that case the last acceleration jerk is increased to enable correct landing.



Also note that when the position sensor is not enabled in the landing zone, its exact length is not known. To ensure correct deceleration this distance is estimated on the basis of the value entered in the **Landing zone dist** parameter.


When this is equal to zero the distance is calculated on the basis of the value of the low speed and deceleration parameters and shown in the **Landing zone space** parameter. The user should make sure this distance is approximately the real length of the landing zone.

In FOC mode the distance is calculated by reading the encoder position.

In the SSC and SLS modes the distance is estimated ( $\text{SpdRef} * \text{Time}$ ) and is thus subject to errors due to the difference between the real speed of the motor and the speed reference.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.1	11102	Distance multispeed0	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 0**.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.2	11104	Distance multispeed1	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 1**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.3	11106	Distance multispeed2	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 2**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.4	11110	Distance multispeed3	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 3**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.5	11112	Distance multispeed4	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 4**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.6	11114	Distance multispeed5	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 5**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.7	11116	Distance multispeed6	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 6**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.8	11118	Distance multispeed7	m	FLOAT		0.00	0.00	10.00	RW	FVS

Setting of the value of the distance associated with **multispeed 7**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.9	11120	Slow speed		UINT16		0	0	9	RW	FVS

Setting of the floor approach speed.

The **Slow speed** is the speed of approach to the landing zone. When the multispeed associated with the **Slow speed** is selected the slow down space is checked in order to reach this speed in proximity to the landing zone.

- 0** Autoselect
- 1** Multispeed 0
- 2** Multispeed 1
- 3** Multispeed 2
- 4** Multispeed 3
- 5** Multispeed 4
- 6** Multispeed 5
- 7** Multispeed 6
- 8** Multispeed 7
- 9** Null

When mode **0 (Autoselect)** is selected, **Slow speed** is automatically connected to the multispeed with absolute value of less and other than zero. If repositioning speeds with a value of less than the **Slow speed** are used, the multispeed corresponding to the floor approach speed must be set.

When mode **9 (Null)** is selected the floor approach spaces are never controlled. In this case the profile depends exclusively on the multispeed selected.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.5.10</b>	<b>11130</b>	<b>Enable landing sel</b>		INT16		0	0	1	RW	FVS

Setting for enabling space control in the landing zone.

This function enables the cabin to arrive exactly at floor level by controlling the position of the encoder in the landing zone sensor. Position control is only possible if an encoder is used (normally in FOC-BRS). SSC and SLS modes simply generate an appropriate profile on the position reference.

When the function is enabled, the **Slow speed**, PAR 11120 (speed at which the cabin enters the landing zone) no longer depends on the relative multispeed but is calculated automatically according to the jerk and deceleration values to enable stopping without exceeding the set limits.

The value of **Slow speed** (PAR 11120 = 1...8) is calculated using the jerk and deceleration values not multiplied by the ramp factor.

During the landing procedure the speed profile is calculated using the fifth-degree polynomial method.

Direct arrival at floor level is also possible, without using the **Slow speed**. This is done by setting the **Slow speed** multispeed value to zero.

- 0** Off
- 1** On

Given the solution that has been selected to calculate the speed profile, before enabling the landing zone function it is important to verify the exactness of the spaces that have been entered (for both slow down and landing), and of the mechanical constants. Incorrect spaces could result in sudden decelerations and errors in arrival at floor level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.5.11</b>	<b>11132</b>	<b>Landing zone dist</b>	m	FLOAT		0.12	0	10.00	RW	FVS

Setting of the landing zone distance.




Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.5.12</b>	<b>11138</b>	<b>Out floor function</b>		BIT		0	0	1	RW	FVS

Enabling of the safe start function when not at floor level. This function enables recognition of arrival at floor level, which is assumed to be correct if the landing zone phase is performed.

If a correct stopping sequence is not recognised this means an emergency stop command has been sent, after which a low speed start is generated.

The restart procedure depends on the stop position as shown in the figure.

- 0** OFF
- 1** ON



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.13	11140	Delay acq time	m	FLOAT		15	0.00	10.00	RW	FVS

Setting of the delay time for sending the slow down signal.

The value of this parameter is used to compensate for the distance covered during the delay time between the passage of the cabin on the slow down sensor and receipt of the decelerate command by the drive. At high speeds this distance can have significant values: e.g. with a cabin travelling at 2 m/s and a delay time of 30 ms, the distance covered and to be taken into consideration during the deceleration phase is 6 cm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.14	11142	Calc space hi-speed		UINT16		1	0	8	RW	FVS

Setting of the high speed to be used to calculate distances.

- 0** Multispeed 0
- 1** Multispeed 1
- 2** Multispeed 2
- 3** Multispeed 3
- 4** Multispeed 4
- 5** Multispeed 5
- 6** Multispeed 6
- 7** Multispeed 7
- 8** Null


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.15	12030	Acceleration space	m	FLOAT		0			R	FVS

The distance necessary to accelerate from zero speed to the high speed selected in the previous parameter is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.16	12032	Deceleration space	m	FLOAT		0			R	FVS

The distance necessary to stop from the high speed is displayed.

Different methods are used to calculate this distance, depending on the value of the relative parameters:




- Case 1: -shaped ramp from high speed to zero speed

Distance multispeed0 (PAR 11102) = 0, Enable landing sel (PAR 11130) = Disabled, Slow speed (PAR 11120) = Zero.

Deceleration space (PAR 12032) is the distance covered during the stop ramp from Calc space hi-speed (PAR 11142) (high speed) to zero speed.

The parameters that influence the calculation of this distance are: Calc space hi-speed (PAR 11142), Percent dec factor (PAR 11056), Dec ini jerk (PAR 11046), Deceleration (PAR 11048) and Dec end jerk (PAR 11050).




- Case 2: S-shaped ramp from high to low speed, low speed zone and subsequent stop

Distance multispeed0 (PAR 11102) = 0, Enable landing sel (PAR 11130) = Disabled, Slow speed (PAR 11120) = Multispeed 0.

Deceleration space (PAR 12032) is the distance covered during the slow down ramp from Calc space hi-speed (PAR 11142) (high speed) to Multispeed 0 and during the stop ramp from Calc space hi-speed (PAR 11142) to zero speed. It does not include the distance covered at constant speed (Low speed).

The parameters that influence the calculation of this distance are: Calc space hi-speed (PAR 11142), [11022] Multispeed 0 (PAR 11020), Percent dec factor (PAR 11056), Dec ini jerk (PAR 11046), Deceleration (PAR 11048), Dec end jerk (PAR 11050) and Stop deceleration (PAR 11052).




- Case 3: S-shaped ramp from high to low speed, low speed zone and subsequent stop

Distance multispeed0 (PAR 11102) ≠ 0 (es.0.5m), Enable landing sel (PAR 11130) = Disabled, Slow speed (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 12032) is the distance covered during the slow down ramp from **Calc space hi-speed** (PAR 11142) to **Multispeed 0** and during the stop ramp from **Calc space hi-speed** (PAR 11142) to zero speed. It does not include the distance covered at constant speed (Low speed).

The parameters that influence the calculation of this distance are: **Calc space hi-speed** (PAR 11142), [11022] **Multispeed 0** (11020), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050).



- **Case 4:** S-shaped ramp from high to low speed, low speed zone and subsequent stop with "landing control"

**Distance multispeed0** (PAR 11102) ≠ 0 (es.0.5m), **Enable landing sel** (PAR 11130) = Enabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 12032) is the distance covered during the slow down ramp from **Calc space hi-speed** (PAR 11142) (high speed) to **Multispeed 0** plus **Landing zone dist** (PAR 11132).

The parameters that influence the calculation of this distance are: **Calc space hi-speed** (PAR 11142), [11022] **Multispeed 0** (PAR 11020), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.5.17	12034	Landing zone space	m	FLOAT		0			R	FVS

The landing zone space is displayed. If this parameter is set to a value other than zero, this variable has the same value as the parameter, if **Landing zone space** = 0 this variable assumes the value of the distance necessary to decelerate from the speed set in **Slow speed** to zero using the ramp values not multiplied by the **Percent dec factor**.

## 5.6 – EMERGENCY MODE

The possibility of operating on an emergency module power supply has been implemented in the drive, to overcome the problem of sudden power failures.

The emergency operation condition signal must be connected to the **Emergency** command input (digital input 3 as default) which, if active, disables the **undervoltage** alarm so that the drive can operate powered on the DC link by the EMS emergency module (which is in turn powered by a buffer battery pack).

In order to use batteries with a lower power rating, a function has been implemented to allow the desired direction of travel to be selected before starting an emergency start procedure.

The direction is selected after testing the movement in both directions, choosing the one that requires less current (for more details see EMS manual).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.6.1	11260	Speed emergency mode	Hz	FLOAT		5.00	3.40E+94	3.40E+94	RW	FVS

Setting of the speed during movements in the emergency operation condition. Given the low voltage, high speeds cannot be reached with the drive powered by battery (or emergency module). The speed selected in the multispeed parameter is therefore ignored and this value is used instead.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.6.2	11262	Autoselect direction		BIT		0	0	1	ERW	FVS

Enabling of automatic selection of preferred direction before an emergency start.

- |   |     |
|---|-----|
| 0 | OFF |
| 1 | ON  |

## 5.7 – LIFT IN/OUT

### Inputs

The lift application input commands can be connected to a signal via a selector in order to choose from a series of possibilities

available in the input list.

Generally speaking a signal can be connected to a digital input, to certain internal signals and to a bit of the Decomp word bit. This word is connected to a fieldbus processing channel (**PDC FieldBus M->S1**).

The set of digital inputs in a word is displayed in the Lift control word.

The commands used in the lift application are listed below

Command	Description	Default Source
EnableCmd	Enable command	Dig input enable
StartFwdCmd	Start forward command	Dig input 1x
StartRevCmd	Start reverse command	Dig input 2x
MltSpd S0	Multispeed 0 sel	Dig input 4x
MltSpd S1	Multispeed 1 sel	Dig input 5x
MltSpd S2	Multispeed 2 sel	Dig input 6x
ContFbk	Contactor close contact	Run cont mon
BrakeFbk	Brake close contact	Brake cont mon
DoorOpenEna	Source for enabling the door open function	Null
DoorFbk	Door close contact	Null
Emergency mode	Emergency operation command	Dig input 3x
InvRampSrc	Command to invert the speed direction	Null
UpperLimit	Travel upper limit signal	Null
LowerLimit	Travel lower limit signal	Null

## Outputs

The output signals of the lift control are connected directly to the PAD parameters as shown in the table below:

PAR	Signal	Description
3700	Lift enable	LiftEnable
3702	Run cont mon	RunCont
3704	Up cont mon	UpCont
3706	Down cont mon	DownCont
3708	Brake cont mon	BrakeCont
3710	Lift dc brake	LiftDcBrake
3712	Brake 2 mon	Brake2
3714	Door open mon	DoorOpen
3716	Lift start	LiftStart
3718	PAD10	-----
3720	Lift status word	Lift status word
		Contains pairs of the StatusWord (selectable from SelLiftStatWord)
3722	PAD12	-----
3724	PAD13	-----
3726	Ramp down limit	-----
3728	Input variable	InputVariable
3730	Lift wdec input	LiftWdecInp

These can be accessed from the selection lists and can thus easily be used to configure the relay and digital outputs of the drive. (refer to the PADS menu for configuration).

The set of lift output signals is contained in the LiftStatusWord, connected to PAR 3720 **Lift status word** and fieldbus Tx DW1:

Bit	Description	Notes
0	LiftEnable	Enable lift command.
1	RunCont	Run command contactor
2	UpCont	Up command contactor
3	DownCont	Down command contactor
4	BrakeCont	Brake command contactor
5	LiftDcBrake	DC brake function command (firmware)
6	Brake2	Brake control signal (see sequences)
7	DoorOpen	Open door command
8	Drive Ok	Drive not in alarm condition signal
9	SpeedIsZero	Speed less than 0 limit signal
10	SpeedRefIsZero	Speed reference less than 0 limit signal
11 ... 12		

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>5.7.1</b>	<b>11220</b>	<b>Lift enable cmd sel</b>		ENUM		1110	0	35	ERW	FVS
--------------	--------------	----------------------------	--	------	--	------	---	----	-----	-----

Setting of the source for the enable command.

- 1110**      Digit input E
- 1210**      Digit input 1x
- 1212**      Digit input 2x
- 1214**      Digit input 3x
- 1216**      Digit input 4x
- 1218**      Digit input 5x
- 1220**      Digit input 6x
- 1222**      Digit input 7x
- 1224**      Digit input 8x
- 1226**      Digit input 9x
- 1228**      Digit input 10x
- 1230**      Digit input 11x
- 1232**      Digit input 12x
- 3702**      Run cont mon
- 3706**      Down cont mon
- 3708**      Brake cont mon
- 3714**      Door open mon
- 3728**      Input variable
- 6000**      Null
- 6002**      One
- 12250**     B0 Lift decomp
- 12252**     B1 Lift decomp
- 12254**     B2 Lift decomp
- 12256**     B3 Lift decomp
- 12258**     B4 Lift decomp
- 12260**     B5 Lift decomp
- 12262**     B6 Lift decomp
- 12264**     B7 Lift decomp
- 12266**     B8 Lift decomp
- 12268**     B9 Lift decomp
- 12270**     B10 Lift decomp
- 12272**     B11 Lift decomp
- 12274**     B12 Lift decomp
- 12276**     B13 Lift decomp
- 12278**     B14 Lift decomp
- 12280**     B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

<b>5.7.2</b>	<b>11222</b>	<b>Start fwd cmd sel</b>		ENUM		1210	0	35	ERW	FVS
--------------	--------------	--------------------------	--	------	--	------	---	----	-----	-----

Setting of the source for the start forward command.

- 1110**      Digit input E
- 1210**      Digit input 1x
- 1212**      Digit input 2x
- 1214**      Digit input 3x
- 1216**      Digit input 4x
- 1218**      Digit input 5x
- 1220**      Digit input 6x
- 1222**      Digit input 7x
- 1224**      Digit input 8x
- 1226**      Digit input 9x
- 1228**      Digit input 10x
- 1230**      Digit input 11x
- 1232**      Digit input 12x
- 3702**      Run cont mon
- 3706**      Down cont mon
- 3708**      Brake cont mon
- 3714**      Door open mon
- 3728**      Input variable
- 6000**      Null
- 6002**      One
- 12250**     B0 Lift decomp
- 12252**     B1 Lift decomp
- 12254**     B2 Lift decomp
- 12256**     B3 Lift decomp
- 12258**     B4 Lift decomp
- 12260**     B5 Lift decomp

<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.3</b>	<b>11224</b>	<b>Start rev cmd sel</b>		ENUM		1212	0	35	ERW	FVS

Setting of the source for the start reverse command.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon
<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.4</b>	<b>11226</b>	<b>Multi speed S0 sel</b>		ENUM		1216	0	35	ERW	FVS

Setting of the source for the first multispeed selection bit.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon

**3708** Brake cont mon  
**3714** Door open mon  
**3728** Input variable  
**6000** Null  
**6002** One  
**12250** B0 Lift decomp  
**12252** B1 Lift decomp  
**12254** B2 Lift decomp  
**12256** B3 Lift decomp  
**12258** B4 Lift decomp  
**12260** B5 Lift decomp  
**12262** B6 Lift decomp  
**12264** B7 Lift decomp  
**12266** B8 Lift decomp  
**12268** B9 Lift decomp  
**12270** B10 Lift decomp  
**12272** B11 Lift decomp  
**12274** B12 Lift decomp  
**12276** B13 Lift decomp  
**12278** B14 Lift decomp  
**12280** B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.5</b>	<b>11228</b>	<b>Multi speed S1 sel</b>		ENUM		1218	0	35	ERW	FVS

Setting of the source for the second multispeed selection bit.

**1110** Digit input E  
**1210** Digit input 1x  
**1212** Digit input 2x  
**1214** Digit input 3x  
**1216** Digit input 4x  
**1218** Digit input 5x  
**1220** Digit input 6x  
**1222** Digit input 7x  
**1224** Digit input 8x  
**1226** Digit input 9x  
**1228** Digit input 10x  
**1230** Digit input 11x  
**1232** Digit input 12x  
**3702** Run cont mon  
**3706** Down cont mon  
**3708** Brake cont mon  
**3714** Door open mon  
**3728** Input variable  
**6000** Null  
**6002** One  
**12250** B0 Lift decomp  
**12252** B1 Lift decomp  
**12254** B2 Lift decomp  
**12256** B3 Lift decomp  
**12258** B4 Lift decomp  
**12260** B5 Lift decomp  
**12262** B6 Lift decomp  
**12264** B7 Lift decomp  
**12266** B8 Lift decomp  
**12268** B9 Lift decomp  
**12270** B10 Lift decomp  
**12272** B11 Lift decomp  
**12274** B12 Lift decomp  
**12276** B13 Lift decomp  
**12278** B14 Lift decomp  
**12280** B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.6</b>	<b>11230</b>	<b>Multi speed S2 sel</b>		ENUM		1220	0	35	ERW	FVS

Setting of the source for the third multispeed selection bit.

**1110** Digit input E  
**1210** Digit input 1x  
**1212** Digit input 2x  
**1214** Digit input 3x

<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon
<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.8	11236	Brake fbk sel		ENUM		3708	0	35	ERW	FVS

Setting of the source of the brake status signal.

- 1110** Digit input E
- 1210** Digit input 1x
- 1212** Digit input 2x
- 1214** Digit input 3x
- 1216** Digit input 4x
- 1218** Digit input 5x
- 1220** Digit input 6x
- 1222** Digit input 7x
- 1224** Digit input 8x
- 1226** Digit input 9x
- 1228** Digit input 10x
- 1230** Digit input 11x
- 1232** Digit input 12x
- 3702** Run cont mon
- 3706** Down cont mon
- 3708** Brake cont mon
- 3714** Door open mon
- 3728** Input variable
- 6000** Null
- 6002** One
- 12250** B0 Lift decomp
- 12252** B1 Lift decomp
- 12254** B2 Lift decomp
- 12256** B3 Lift decomp
- 12258** B4 Lift decomp
- 12260** B5 Lift decomp
- 12262** B6 Lift decomp
- 12264** B7 Lift decomp
- 12266** B8 Lift decomp
- 12268** B9 Lift decomp
- 12270** B10 Lift decomp
- 12272** B11 Lift decomp
- 12274** B12 Lift decomp
- 12276** B13 Lift decomp
- 12278** B14 Lift decomp
- 12280** B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.9	11238	Door open sel		ENUM		6000	0	35	ERW	FVS

Setting of the source to enable door closing control.

- 1110** Digit input E
- 1210** Digit input 1x
- 1212** Digit input 2x
- 1214** Digit input 3x
- 1216** Digit input 4x
- 1218** Digit input 5x
- 1220** Digit input 6x
- 1222** Digit input 7x
- 1224** Digit input 8x
- 1226** Digit input 9x
- 1228** Digit input 10x
- 1230** Digit input 11x
- 1232** Digit input 12x
- 3702** Run cont mon
- 3706** Down cont mon
- 3708** Brake cont mon
- 3714** Door open mon
- 3728** Input variable
- 6000** Null
- 6002** One
- 12250** B0 Lift decomp
- 12252** B1 Lift decomp
- 12254** B2 Lift decomp
- 12256** B3 Lift decomp
- 12258** B4 Lift decomp
- 12260** B5 Lift decomp

<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.10</b>	<b>11240</b>	<b>Door feedback sel</b>		ENUM		6000	0	35	ERW	FVS

Setting of the source of the door status signal.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon
<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.11</b>	<b>11242</b>	<b>Emergency mode sel</b>		ENUM		1214	0	35	ERW	FVS

Setting of the source of the emergency operation signal.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon

<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.12</b>	<b>11244</b>	<b>Inversion ramp sel</b>		ENUM		6000	0	35	ERW	FVS

Setting of the source of the command that inverts the direction of the output speed.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon
<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.7.13</b>	<b>11246</b>	<b>Upper limit sel</b>		ENUM		6000	0	35	ERW	FVS

Setting of the source of the upper limit enabling signal.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x

<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon
<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.14	<b>11248</b>	<b>Lower limit sel</b>		ENUM		6000	0	35	ERW	FVS

Setting of the source of the lower limit enabling signal.

<b>1110</b>	Digit input E
<b>1210</b>	Digit input 1x
<b>1212</b>	Digit input 2x
<b>1214</b>	Digit input 3x
<b>1216</b>	Digit input 4x
<b>1218</b>	Digit input 5x
<b>1220</b>	Digit input 6x
<b>1222</b>	Digit input 7x
<b>1224</b>	Digit input 8x
<b>1226</b>	Digit input 9x
<b>1228</b>	Digit input 10x
<b>1230</b>	Digit input 11x
<b>1232</b>	Digit input 12x
<b>3702</b>	Run cont mon
<b>3706</b>	Down cont mon
<b>3708</b>	Brake cont mon
<b>3714</b>	Door open mon
<b>3728</b>	Input variable
<b>6000</b>	Null
<b>6002</b>	One
<b>12250</b>	B0 Lift decomp
<b>12252</b>	B1 Lift decomp
<b>12254</b>	B2 Lift decomp
<b>12256</b>	B3 Lift decomp
<b>12258</b>	B4 Lift decomp
<b>12260</b>	B5 Lift decomp
<b>12262</b>	B6 Lift decomp
<b>12264</b>	B7 Lift decomp
<b>12266</b>	B8 Lift decomp
<b>12268</b>	B9 Lift decomp
<b>12270</b>	B10 Lift decomp
<b>12272</b>	B11 Lift decomp
<b>12274</b>	B12 Lift decomp
<b>12276</b>	B13 Lift decomp
<b>12278</b>	B14 Lift decomp
<b>12280</b>	B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.15	11250	Dcp3 mode command		BIT		0	0	1	ERW	FVS
Enabling of reading of commands from DCP3 serial protocol										
0 OFF 1 ON										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.16	11256	SpeedRefSrc		ENUM		0	0	1	RW	FVS
Selection of the origin (source) of the signal to be used for the speed reference. The signals that can be used are multi-speed, analog inputs or fieldbus (except the PAR 4020 Fieldbus M->S1 ipa)										


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.17	12102	Command input mon		UINT32		0			ER	FVS
The hexadecimal value of the input status is displayed, refer to the "lift control word" for a description of the meaning of each bit.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.7.18	12104	Command output mon		UINT32		0			ER	FVS
The hexadecimal value of the input status is displayed, refer to the "lift status word" for a description of the meaning of each bit.										

## 5.8 -PRE - TORQUE

The Pre-torque function helps to guarantee a linear start without any initial acceleration. This is possible by setting a torque value that corresponds to the load before opening the brake. The value of the initial torque applied to the motor and the direction of the torque applied can be supplied by installing a load cell on the lift cabin. The load cell signal is acquired via the analog input and appropriately scaled if using the Pre-torque function.

If a load cell is not installed, a fixed torque value can be used, only supplying the direction of torque. In that case the fixed torque value is only optimised for one load condition.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.8.1	11166	Pre-torque enable		BIT		0	0	1	RW	F
Enabling of the pre-torque function										
0 OFF 1 ON										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.8.2	11168	Pre-torque source		INT16		11170	0	2	RW	F
Selection of the origin (source) of the signal used for the pre-torque function.										
1600 Analog inp 1 1650 Analog inp 2 4034 FieldbusM->S2 4044 FieldbusM->S3 4054 FieldbusM->S4 4064 FieldbusM->S5 4074 FieldbusM->S6 4084 FieldbusM->S7 4094 FieldbusM->S8 4104 FieldbusM->S9 4114 FieldbusM->S10 4124 FieldbusM->S11 4134 FieldbusM->S12 4144 FieldbusM->S13										

<b>4154</b>	FieldbusM->S14
<b>4164</b>	FieldbusM->S15
<b>4174</b>	FieldbusM->S16
<b>11170</b>	Int pretorque

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.3</b>	<b>11170</b>	<b>Init pre-torque</b>		INT32		1000			RW	F

Setting of the reference value used in the pre-torque function only if the Pre-torque source parameter is set to 0. The value set in this parameter only enables the pre-torque function to be optimised for one load condition. The pre-torque function can also be optimised for different load conditions by using the fieldbus to modify the setting of this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.4</b>	<b>11172</b>	<b>Pre-torque ramp up</b>	ms	INT32		0	0	10000	RW	F

Setting of the ramp time for the rising edge of the torque value (before opening the brake): if this parameter is set to zero the constant feed-forward torque value is maintained during travel.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.5</b>	<b>11174</b>	<b>Pre-torque ramp down</b>	ms	INT32		0	0	60000	RW	F

Setting of the ramp time for the falling edge of the torque value: if this parameter is set to zero the constant feed-forward torque value is maintained during travel.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.6</b>	<b>11176</b>	<b>Pre-torque offset</b>		FLOAT		0			RW	F

Setting of the offset value applied to the input reference of the pre-torque function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.7</b>	<b>11178</b>	<b>Pre torque gain</b>		FLOAT		1			RW	F

Setting of the gain value used to convert the value applied to the analog input in the torque value to be used in the function. This gain is calculated automatically according to the weights and inertia values entered. Ideally, the reference must be set so that the minimum value corresponds to the empty cabin and the maximum value to the full load.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.8</b>	<b>12040</b>	<b>Pre-torque input</b>	cnt	INT32		0			ER	F

The reference value sampled at start is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.9</b>	<b>12056</b>	<b>Pre-torque out</b>	cnt	INT32		0			ER	F

The feed forward torque value output of the pre-torque function is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.8.10</b>	<b>12058</b>	<b>Torque reference</b>	cnt	INT32		0			ER	F

The torque reference value is displayed, given by the sum of the speed loop output and the torque feed forward.

## 5.9 – LIFT ALARMS

The MdPlc application for ADL200 manages and generates the following alarms:

Alarm	Alarm type	Description
Plc1 fault	Cont feedback	Contactor feedback signal error
Plc2 fault	Brake feedback	Brake feedback signal error
Plc3 fault	Door feedback	Door feedback signal error
Plc6 fault	Speed limited	Warning of speed limit to guarantee stop
Plc7 fault	Up/low limit	Speed limit exceeded in power factor regulation zone

All alarms are associated with a parameter to configure the action taken when the alarm is activated.

Activity: used to set the action to be performed after activation of the alarm, as follows.

Action	
<b>Ignore</b>	The alarm is not included in the alarm list, it is not included in the alarm log, it is not signalled on the digital outputs, commands to the drive are not modified.
<b>Warning</b>	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, commands to the drive are not modified.
<b>Disable</b>	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a stop command is sent, the motor is disabled and stops due to inertia.
<b>Stop</b>	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a Stop command is sent. The drive is set to zero speed with maximum available current; when the Speed 0 delay signal is activated the drive is disabled.
<b>Fast Stop</b>	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a Stop command is sent. The drive is set to zero speed with the maximum available current; when the Speed 0 delay signal is activated the drive is disabled.
<b>Lift stop</b>	The drive is set to zero speed with the set ramp time; when the speed is zero the drive is disabled. When the drive has been disabled the alarm is included in the alarm list, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.9.1</b>	<b>11200</b>	<b>Contactor activity</b>		INT16		1	0	5	RW	FVS
Setting of drive behaviour in case of a Cont fbk fail alarm. This alarm indicates that the feedback confirming closing of the contactor has not been received.										
<b>0</b> Ignore <b>1</b> Warning <b>2</b> Disable <b>3</b> Stop <b>4</b> Fast Stop <b>5</b> Lift stop										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.9.2</b>	<b>11202</b>	<b>Cont hold off</b>	ms	INT32		3000			RW	FVS
Setting of the delay time between activation of the Cont fbk fail alarm condition signal and the actual alarm. In case of an alarm condition, the drive waits for the set time to elapse before activating the alarm. If the alarm is removed within the set time, the drive will not activate the alarm.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.9.3</b>	<b>11204</b>	<b>Brake activity</b>		INT16		1	0	5	RW	FVS
Setting of drive behaviour in case of a Brake fbk fail alarm. This alarm indicates that the feedback confirming opening/closing of the brake has not been received.										
<b>0</b> Ignore <b>1</b> Warning <b>2</b> Disable <b>3</b> Stop <b>4</b> Fast Stop <b>5</b> Lift stop										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.9.4</b>	<b>11206</b>	<b>Brake hold off</b>	ms	INT32		3000.00			RW	FVS
Setting of the delay time between activation of the Brake fbk fail alarm condition signal and the actual alarm. In case of an alarm condition, the drive waits for the set time to elapse before activating the alarm. If the alarm is removed within the set time, the drive will not activate the alarm.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>5.9.5</b>	<b>11208</b>	<b>Brake run hold off</b>		INT16		1	0	1	RW	FVS
Setting of drive behaviour when a possible Brake fbk fail alarm is detected.										
<b>0</b> Disable										

## 1 Enable

If set to 0 the brake feedback alarm is indicated immediately

If set to 1 the possible brake feedback alarm is indicated at the end of travel: this allows the cabin to reach the floor in case of a faulty brake status signal.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.9.6	11210	Door activity		INT16		1	0	5	RW	FVS

Setting of drive behaviour in case of a **Door fbk fail** alarm. This alarm indicates that the feedback confirming opening of the door has not been received.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast Stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.9.7	11212	Door hold off	ms	INT32		3000.00			RW	FVS

Setting of the delay time between activation of the **Door fbk fail** alarm condition signal and the actual alarm. In case of an alarm condition, the drive waits for the set time to elapse before activating the alarm. If the alarm is removed within the set time, the drive will not activate the alarm.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.9.8	11214	Limit activity		INT16		2	0	5	RW	FVS

Setting of drive behaviour in case of the **Upper/Lower limit**. This alarm indicates that power factor correction feedback has not been received, i.e. sensors installed at the beginning and end of the space that enable the cabin to be repositioned at a known floor and prevent dangerous overtravel beyond the limits of the space. The power factor correction function implemented in the drive provides an additional control to avoid overtravel.

The alarm condition is generated, if a power factor correction signal is present, when the set speed limit is exceeded.

The **UpperLimit** or **LowerLimit** inputs must be set to enable speed limit control. The **UpperLimit** must always correspond to the upper limit signal and the **LowerLimit** must always correspond to the lower limit signal.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast Stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.9.9	11216	Limit speed thr	ms	INT32		1.00			RW	FVS

Setting of the speed threshold in the power factor correction zone.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
5.9.10	11218	Spd target activity		INT16		1	0	5	RW	FVS

Setting of drive behaviour in case of the **Speed limit** alarm. This alarm is activated if, using the EFC function, the slow down distance is less than the real deceleration distance, thus enabling the speed limiter to ensure correct stopping.

- 0** Ignore
- 1** Warning
- 2** Disable
- 3** Stop
- 4** Fast Stop
- 5** Lift stop

**6 -**

**7 -**

**8 -**

**9 -**

**Note !** These menues are not available.

## 10 - DIGITAL INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
10.01	1240	Dig inp 1X inversion			BIT	0	0	1	ERW	FVS
10.02	1242	Dig inp 2X inversion			BIT	0	0	1	ERW	FVS
10.03	1244	Dig inp 3X inversion			BIT	0	0	1	ERW	FVS
10.04	1246	Dig inp 4X inversion			BIT	0	0	1	ERW	FVS
10.05	1248	Dig inp 5X inversion			BIT	0	0	1	ERW	FVS
10.06	1250	Dig inp 6X inversion			BIT	0	0	1	ERW	FVS
10.07	1252	Dig inp 7X inversion			BIT	0	0	1	ERW	FVS
10.08	1254	Dig inp 8X inversion			BIT	0	0	1	ERW	FVS
10.09	1256	Dig inp 9X inversion			BIT	0	0	1	ERW	FVS
10.10	1258	Dig inp 10X inversion			BIT	0	0	1	ERW	FVS
10.11	1260	Dig inp 11X inversion			BIT	0	0	1	ERW	FVS
10.12	1262	Dig inp 12X inversion			BIT	0	0	1	ERW	FVS

Inversion of the logic status of the function associated with the digital input of the expansion card.

0	Off
1	On

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
10.13	1268	Dig input E dest			ILINK	0	0	0	ER	FVS
10.14	1270	Dig input 1X dest			ILINK	0	0	0	ER	FVS
10.15	1272	Dig input 2X dest			ILINK	0	0	0	ER	FVS
10.16	1274	Dig input 3X dest			ILINK	0	0	0	ER	FVS
10.17	1276	Dig input 4X dest			ILINK	0	0	0	ER	FVS
10.18	1278	Dig input 5X dest			ILINK	0	0	0	ER	FVS
10.19	1280	Dig input 6X dest			ILINK	0	0	0	ER	FVS
10.20	1282	Dig input 7X dest			ILINK	0	0	0	ER	FVS
10.21	1284	Dig input 8X dest			ILINK	0	0	0	ER	FVS
10.22	1286	Dig input 9X dest			ILINK	0	0	0	ER	FVS
10.23	1288	Dig input 10X dest			ILINK	0	0	0	ER	FVS
10.24	1290	Dig input 11X dest			ILINK	0	0	0	ER	FVS
10.25	1292	Dig input 12X dest			ILINK	0	0	0	ER	FVS

Selection of the destination of the digital input of the associated expansion card.

## 11 - DIGITAL OUTPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
11.01	1410	Dig output 1X src		LINK	16BIT	1062	0	16384	ERW	FVS
11.02	1412	Dig output 2X src		LINK	16BIT	3708	0	16384	ERW	FVS
11.03	1414	Dig output 3X src		LINK	16BIT	3702	0	16384	ERW	FVS
11.04	1416	Dig output 4X src		LINK	16BIT	3714	0	16384	ERW	FVS
11.05	1418	Dig output 5X src		LINK	16BIT	1062	0	16384	ERW	FVS
11.06	1420	Dig output 6X src		LINK	16BIT	3708	0	16384	ERW	FVS
11.07	1422	Dig output 7X src		LINK	16BIT	3702	0	16384	ERW	FVS
11.08	1424	Dig output 8X src		LINK	16BIT	3714	0	16384	ERW	FVS

The destination associated with the digital input of the expansion card is displayed. The functions that can be associated with the digital outputs are listed in the “L\_DIGSEL1” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
11.09	1430	Dig out 1X inversion		BIT		0	0	1	ERW	FVS
11.10	1432	Dig out 2X inversion		BIT		0	0	1	ERW	FVS
11.11	1434	Dig out 3X inversion		BIT		0	0	1	ERW	FVS
11.12	1436	Dig out 4X inversion		BIT		0	0	1	ERW	FVS
11.13	1438	Dig out 5X inversion		BIT		0	0	1	ERW	FVS
11.14	1440	Dig out 6X inversion		BIT		0	0	1	ERW	FVS
11.15	1442	Dig out 7X inversion		BIT		0	0	1	ERW	FVS
11.16	1444	Dig out 8X inversion		BIT		0	0	1	ERW	FVS

Inversion of the logic status of the function associated with the digital output of the expansion card.

0 Off  
1 On

## 12 - ANALOG INPUTS

### Note !

These parameters are only available with cards provided with analog inputs.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.1	1600	Analog input 1X mon	cnt	INT16	16/32BIT	0	0	0	ER	FVS
12.12	1650	Analog input 2X mon	cnt	INT16	16/32BIT	0	0	0	ER	FVS

The value of the voltage on the output of the function block of the relative analog input is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.2	1602	Analog inp 1X type		ENUM		-10V..+10V	0	2	ERW	FVS
12.13	1652	Analog inp 2X type		ENUM		-10V..+10V	0	2	ERW	FVS

Selection of the type of input (voltage or current). Depending on the input signal, move the switches on the regulation card. The factory parameter is inputs set for differential voltage signals ( $\pm 10V$ ).

- 0 -10V..+10V
- 1 0.20mA , 0.10V
- 2 4..20mA


Select option 0 in order to connect a maximum voltage of  $\pm 12.5V$  (typically  $\pm 10V/5mA$ ) to the analog input concerned. If the signal is used as a reference, reverse the direction of rotation by inverting the voltage polarity.

Select option 1 to connect a max voltage of 12.5V (typically 10V/5mA) or a signal in current from 0 ... 20 mA to the analog input concerned. The signal must be positive.

Select option 2 to connect a current signal of 4...20 mA to the analog input concerned. The signal must be positive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.3	1604	Analog inp 1X scale		FLOAT		1.0	-10.0	10.0	ERW	FVS
12.14	1654	Analog inp 2X scale		FLOAT		1.0	-10.0	10.0	ERW	FVS

Setting of a multiplier factor to be applied to the relative analog input of the expansion card.



Example :

The speed reference of a drive is assigned with a max external voltage of 5V. With this value the drive must reach the maximum speed allowed (set using **Full scale speed**).

As the **Analog inp XX scale** parameter the scale factor of 2 is entered (10V : 5V)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.4	1606	An inp 1Xoffset tune		BIT		0	0	1	ERW	FVS
12.15	1656	An inp 2Xoffset tune		BIT		0	0	1	ERW	FVS

Self-tuning command for the offset of the relative analog input of the expansion card. Automatic fine tuning of the input. To perform self-tuning, set the input signal to its minimum value and execute the command. The conditions containing an offset can be compensated. When this command is sent, **An inp xx offset tune** is automatically selected so that the available input signal corresponds to the zero value of the variable.

Automatic tuning can only be performed if the following condition is present:

- Input voltage less than 1V or input current less than 2 mA

**NOTE!** The value that is obtained automatically can be changed manually, if necessary, using **An inp offset xX**.

If the voltage setting on the analog input is more than 1V the “Input value too high” message is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.5	1608	<b>An inp 1X gain tune</b>			BIT	0	0	1	ERW	FVS
12.16	1658	<b>An inp 2X gain tune</b>			BIT	0	0	1	ERW	FVS

Self-tuning command for the relative analog input gain. Automatic fine tuning of the input. When this command is sent, **An inp XX gain tune** is automatically selected so that the available input signal corresponds to the maximum value of the variable.

Two conditions are necessary in order to perform automatic tuning:

- Input voltage greater than 1V or input current greater than 2 mA
- Positive polarity. The value that is found is automatically accepted for the other direction of rotation.

**Note!** If necessary, the value obtained automatically can be changed manually via **An inp XX gain tune**.

To perform self-tuning, set the input signal to its maximum value and execute the command. A multiplier factor is calculated to apply to the input signal value (not considering the Analog inp scale parameter) to reach the full scale value.

If the voltage setting on the analog input is less than 1V the “Input value too low” message is displayed.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.6	1612	<b>Analog inp 1X top</b>		cnt	INT16	16384	-32768	+32767	ERW	FVS
12.17	1662	<b>Analog inp 2X top</b>		cnt	INT16	16384	-32768	+32767	ERW	FVS

Setting of the upper speed reference limit as a function of the voltage (or current) of the relative analog reference of the expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.7	1614	<b>Analog inp 1X bottom</b>		cnt	INT16	-16384	-32768	+32767	ERW	FVS
12.18	1664	<b>Analog inp 2X bottom</b>		cnt	INT16	-16384	-32768	+32767	ERW	FVS

Setting of the lower speed reference limit as a function of the voltage (or current) of the relative analog reference of the expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.8	1616	<b>Analog inp 1X offset</b>		cnt	INT16	0	-32768	+32767	ERW	FVS
12.19	1666	<b>Analog inp 2X offset</b>		cnt	INT16	0	-32768	+32767	ERW	FVS



Setting of an offset value to algebraically add to the relative analog input of the expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.9	1618	Analog inp 1X gain			FLOAT	1.0	-10.0	10.0	ERW	FVS
12.20	1668	Analog inp 2X gain			FLOAT	1.0	-10.0	10.0	ERW	FVS

This parameter contains the value of the multiplier factor to apply to the analog reference of the expansion card calculated using the **Analog inp gain tune** function.

Example :

An external analog reference only reaches a maximum of 9.8V instead of 10V. 1.020 (10V : 9.8V) is entered as the **Analog inp x gain** parameter.

The same result can be achieved using the **Analog inp x gain tune** function. This parameter can be selected from the keypad menu. The maximum analog value available (in this case 9.8V) must be present on the terminal, with positive polarity. Press the **Enter** key on the keypad to start analog reference self-tuning.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.10	1626	An inp 1X sign src		LINK	16BIT	6000	0	16384	ERW	FVS
12.21	1676	An inp 2X sign src		LINK	16BIT	6000	0	16384	ERW	FVS

Selection of the origin (source) of the signal to be assigned to the relative digital input of the expansion card for selecting the direction of rotation of the motor. The functions that can be associated with the digital outputs are listed in the “**L\_DIG-SEL2**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
12.11	1632	Analog input 1X dest		ILINK		0	0	0	ER	FVS
12.22	1682	Analog input 2X dest		ILINK		0	0	0	ER	FVS

The function for which the relative analog input of the expansion card has been programmed and on which it acts is displayed.

## 13 - ANALOG OUTPUTS

There can be two programmable analog outputs, depending on the configuration.

Analog output 1 supplies a two-pole +/-10VDC voltage signal, while analog output 2 can be programmed to obtain a 0-20mA or 4-20mA output signal in current or a signal in two-pole +/-10VDC voltage, depending on the parameter assigned.


**Note !** These parameters are only available with cards provided with analog outputs.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.1	1850	Analog out 1X src		LINK	16/32BIT	6000	0	16384	ERW	FVS
13.2	1852	Analog out 2X src		LINK	16/32BIT	6000	0	16384	ERW	FVS

Selection of the origin (source) of the signals that can be placed as variables on the analog outputs of the expansion card. The functions that can be assigned to the analog outputs are listed in the “L\_ANOUT” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.3	1858	Analog out 1X scale		FLOAT		1.0	-10.0	10.0	ERW	FVS
13.4	1860	Analog out 2X scale		FLOAT		1.0	-10.0	10.0	ERW	FVS

Parameter for setting a multiplier factor of the signal of the relative analog output of the expansion card. It can be used to amplify or reduce the input value of the relative analog output block.



$$V_{out} = 10 \times \left( \frac{\text{Stp Var} \times \text{par. 1858 (1860)}}{\text{FS Var}} \right)$$

- Vout** output voltage on the card terminals.  
**Stp Var** actual value of the variable (variable unit)  
**FS Var** full scale of the variable (variable unit)

### Example of calculation of the Analog out Xx scale factor

To display the drive speed, use an analog instrument with field of measurement from 0 ... 2V. This means that, to display the speed of the drive, a voltage of 2V on the analog output of the drive must correspond to the maximum speed. With a scale factor of 1 this would be 10V (Scale factor = 2V / 10 V = 0.200).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.5	1866	Analog out 1X mon		cnt	INT16	0	0	0	ER	FVS

The actual value of the voltage present on analog output 1 of the expansion card is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.6	1868	Analog out 2X mon	cnt		INT16	0	0	0	ER	FVS

The actual value of the voltage or current present on analog output 2 of the expansion card is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.7	1874	An out 1X absolute		ENUM	INT16	Disable	0	1	ERW	FVS
13.8	1876	An out 2X absolute		ENUM	INT16	Disable	0	1	ERW	FVS

Enables the relative analog output as an absolute value. If this parameter is set to 1 the voltage on the analog output assumes the value of 0...10V regardless of the sign of the command signal.

- 0 Disable
- 1 Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.9	1882	Analog out 1X min	cnt		INT16	-16384	-32768	+32767	ERW	FVS
13.10	1884	Analog out 1X max	cnt		INT16	-16384	-32768	+32767	ERW	FVS

Setting of the minimum and maximum values for the analog output for the voltage present on analog output 1 of the expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.11	1890	Analog out 2X min	cnt		INT16	-16384	-32768	+32767	ERW	FVS
13.12	1892	Analog out 2X max	cnt		INT16	16384	-32768	+32767	ERW	FVS

Setting of the minimum and maximum values for the analog output in current or voltage present on analog output 2 of the expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
13.13	1898	Analog out 2X type		ENUM		-10V..+10V	0	2	ERW	FVS

Selection of the programmed signal on analog output 2 of the expansion card. The standard output is coded for the signal in voltage.

- 0 0..20mA
- 1 4..20mA
- 2 -10V..+10V

Select option 0 to apply a signal in current of 0 ... 20 mA to analog output 2. The signal must be positive.

Select option 1 to apply a signal in current of 4...20 mA to analog output 2.

Select option 2 to apply a maximum voltage of ±12.5V (typically ±10V/5mA) to analog output 2.


## 14 - MOTOR DATA

From this menu you can enter the motor plate data and "basic" values for the voltage/frequency characteristics. It is important to enter the correct data in order to optimize drive operation and that of the application as a whole. These data are required in order to obtain:

- Computation of the normalization factors necessary for regulation
- Computation of the estimated values for the motor parameters necessary for regulation

Rated voltage, Rated speed, Rated frequency, Rated current, Cos phi, Basic voltage and Basic frequency must be entered (the Cos phi default value can be used if this value is not present on the plate). After entering these parameters, send a **Take parameters** command to calculate (a) and (b) above. The motor cannot be enabled until the **Take parameters** command has been set. If some results are inconsistent, or if the motor is much smaller than the inverter, an error message is displayed indicating a numerical capacity overflow and the previous set of parameters is restored in the "**Mot plate data**" sub-menu.

Example of kW and HP motor data plates



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.1	2000	<b>Rated voltage</b>	V	FLOAT		SIZE	50.0	690.0	RWZS	FVS

Set the motor rated voltage as indicated on the data plate. This is the voltage the drive must supply at the motor rated frequency.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.2	2002	<b>Rated current</b>	A	FLOAT		SIZE	1.0	1500.0	RWZS	FVS

he motor rated current at its rated power (kW / Hp) and voltage (indicated on the motor data plate).

If using a single drive to control several motors connected in parallel (only possible in the SSC mode), enter a value that corresponds to the sum of the rated currents of all the motors; in this case do not perform any "self-tuning operations".

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.3	2004	<b>Rated speed</b>	rpm	FLOAT		SIZE	10.0	32000.0	RWZS	FVS

Rated speed of the motor with full load in rpm (rpm = m-1). In some motors the synchronous speed (e.g. 1500 rpm for a 4-pole motor) and slippage, i.e. the loss of revolutions between the motor idling condition and the rated load condition (e.g. 80 rpm), is indicated. Enter the following: synchronous speed - slippage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.4	2006	<b>Rated frequency</b>	Hz	FLOAT		SIZE	10.0	1000.0	RWZS	FVS

Rated frequency of the motor expressed in Hz, at which the flux weakening range starts.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.5	2008	<b>Pole pairs</b>	UINT16			SIZE	1	20	RWZS	FVS

Motor pole pairs. The number of motor pole pairs is calculated using the motor plate data and applying the following formula:

$$p = \frac{60 [s] \times f [\text{Hz}]}{nN [\text{rpm}]}$$

Where:  $p$  = motor pole pairs;

$f$  = motor rated frequency (PAR 2006)

$nN$  = motor rated speed (PAR 2004)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.6	2010	<b>Rated power</b>	kW	FLOAT		SIZE	0.1	1500.0	RWZS	FVS
Rated power of the motor at the rated voltage and frequency. This value represents the mechanical power produced on the motor shaft.										
14.7	2012	<b>Rated power factor</b>		FLOAT		SIZE	0.6	0.95	RWZS	FVS
Motor power factor, as indicated on the data plate ( $\cos \phi$ ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.										
14.8	2020	<b>Take parameters</b>		BIT		0	0	1	RWZ	FVS
Saves the set motor data in the drive. This command must be supplied last after entering the appropriate values of all the parameters listed above. This means calculating the normalization factors (a) and estimated values for the motor parameters (b). The drive cannot be started until the <b>Take parameters</b> command has been set.										
14.9	2022	<b>Autotune rotation</b>		BIT		0	0	1	RWZ	FVS
Performs self-tuning in rotation: the motor must be uncoupled from the load or the transmission must not represent more than 5% of the load. This procedure allows the greatest degree of accuracy in measuring the motor parameters. To execute the command you must first open the hardware enabling contact between terminals 9 and DICM.										
Self-tuning can now be performed. At the end of the self-tuning procedure, open the contact between terminals 9 and DICM again and reset the parameters that were modified.										
14.10	2024	<b>Autotune still</b>		BIT		0	0	1	RWZ	FVS
Performs self-tuning with the motor coupled to the transmission. The self-tuning procedure may cause limited rotation of the motor shaft. To perform self-tuning, follow the procedure described for the previous parameter.										
14.11	2026	<b>Autotune mode</b>		ENUM		Reduced	0	1	ERWZ	FVS
Selection of the motor parameter self-tuning mode										
0 Reduced 1 Extended										
If set to <b>0</b> all the motor parameters are measured except those relating to the non-linear saturation curve. Use this mode to obtain a faster self-tuning procedure.										
If set to <b>1</b> all the motor parameters are measured. Use this mode to obtain maximum efficiency: this procedure may take a few minutes.										
14.12	2028	<b>Take status</b>		ENUM		Required	0	0	R	FVS
Indication of the status of parameter saving.										
0 Required 1 Done										
The parameter displays the <b>Required</b> message when the motor parameters that have been entered need to be saved. When they have been saved the parameter indicates <b>Done</b> .										
14.13	2030	<b>Autotune status</b>		ENUM		Required	0	0	R	FVS
Indication of the status of execution of motor parameter self-tuning.										
0 Required 1 Done										
The parameter displays the <b>Required</b> message when motor parameter self-tuning is required. When self-tuning is complete the parameter indicates <b>Done</b> .										
14.14	2050	<b>Measured Rs</b>	ohm	FLOAT		CALCF	0.001	200.0	ERWS	FVS

Measured value of the rotor resistance.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
14.15	2052	<b>Measured DTL</b>	V	FLOAT		0.0	0.0	100.0	ERWS	FVS
Measured value of dead time compensation.										
14.16	2054	<b>Measured DTS</b>	V/A	FLOAT		0.0	0.0	100.0	ERWS	FVS
Measured compensation gradient value.										
14.17	2056	<b>Measured Lsig</b>	mH	FLOAT		CALCF	0.1	200.0	ERWS	FVS
Measured leakage inductance value.										
14.18	2058	<b>Measured ImN</b>	A	FLOAT		CALCF	0.1	1000.0	ERWS	FVS
Measured rated magnetizing current value.										
14.19	2060	<b>Measured ImX</b>	A	FLOAT		CALCF	0.0	0.0	ERWS	FVS
Measured magnetizing current saturation value.										
14.20	2062	<b>Measured FlxN</b>	Wb	FLOAT		CALCF	0.05	10.0	ERWS	FVS
Measured rated flux value.										
14.21	2064	<b>Measured FlxX</b>	Wb	FLOAT		CALCF	0.0	0.0	ERWS	FVS
Measured flux saturation value.										
14.22	2066	<b>Measured P1</b>		FLOAT		0.5	0.0	1.0	ERWS	FVS
Measured value of the first parameter to define the motor magnetization curve.										
14.23	2068	<b>Measured P2</b>		FLOAT		9.0	3.0	18.0	ERWS	FVS
Measured value of the second parameter to define the motor magnetization curve.										
14.24	2070	<b>Measured P3</b>		FLOAT		0.87	0.0	1.0	ERWS	FVS
Measured value of the third parameter to define the motor magnetization curve.										
14.25	2072	<b>Measured Rr</b>	ohm	FLOAT		CALCF	0.001	200.0	ERWS	FVS
Measured rotor resistance value.										
14.26	2078	<b>Take tune parameters</b>		BIT		0	0	1	ERWZ	FVS
Saves the motor data calculated by the self-tuning procedure in the drive.										

**Note!**

Data are not saved permanently. Use the “Save Parameters” command in the DRIVE CONFIG menu to save in the permanent memory.

## 15 - ENCODER CONFIG

The closed-loop control mode requires a speed reading by a digital encoder on the motor shaft. The optional card is necessary in order to acquire the encoder signals. The natural variation in speed generated by machine load induction, known as slippage, can be compensated by the speed feedback supplied by the encoder in SSC mode. In the field oriented vector mode, closed-loop encoder feedback is essential for correct drive operation.

### Note !

This menu is only displayed if a feedback card is installed

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.1	2100	<b>Encoder pulses</b>	ppr	UINT16		1024	128	16384	RWZ	FVS

Setting of the number of feedback encoder impulses. During setup, for incremental sinusoidal encoders + absolute EnDat and Hiperface encoders this value is set automatically by reading the number of incremental encoder impulses.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.2	2102	<b>Encoder supply</b>	V	FLOAT		5.2	5.2	CALCF	ERWZ	FVS

Setting of the encoder supply voltage supplied by the relative optional card. Min and max values are modified according to the type of encoder card applied.

Type of encoder option		Def	Min	Max
Enc 1	EXP-DE-I1R1F2-ADL	5.2 V	5.2 V	22.0 V
Enc 2	EXP-SE-I1R1F2-ADL	5.2 V	5.2 V	6.0 V
Enc 3	EXP-SESC-I1R1F2-ADL	5.2 V	5.2 V	6.0 V
Enc 4	EXP-EN/SSI-I1R1F2-ADL	5.2 V	5.2 V	10.0 V
Enc 5	EXP-HIP-I1R1F2-ADL	8.0 V	7.0 V	12.0 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.3	2104	<b>Encoder input config</b>		ENUM		TTL	0	1	ERWZ	FVS

Setting of the input configuration of the incremental digital encoder, TTL or HTL.

- 0** HTL
- 1** TTL

This parameter is automatically set to HTL when the value set in the **Encoder supply** parameter is more than 6.0V.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.4	2106	<b>Encoder repetition</b>		ENUM		No division	0	3	ERWZ	FVS

Setting of the divider to apply to the encoder repeat output frequency.

- 0** No division
- 1** Divide 2
- 2** Divide 4
- 3** Divide 8

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.5	2108	<b>Encoder signal Vpp</b>	V	FLOAT		1	0.8	1.2	ERWZ	FVS

Setting of the peak-to-peak voltage value of the encoder signal. Incremental sinusoidal encoders and absolute SinCos encoders normally produce signals with a peak-to-peak voltage of 1 Vpp. Due to loss of voltage along the cable, the value of the peak-to-peak voltage signal received by the feedback card could be lower, generating a **Speed fbk loss** alarm.

This parameter can be used to set the peak-to-peak voltage value of the incremental sinusoidal encoders and absolute SinCos encoders on the input terminals of the feedback card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.6	2110	<b>Encoder signal check</b>		ENUM		Check A-B	0	3	ERWZ	FVS

Configuration of which incremental digital encoder channels are to be controlled in order to process the **Speed fbk loss** alarm signal.

- 0** Check disabled
- 1** Check A-B
- 2** Check A-B-Z
- 4** Check A-B-SE

Set 1 to check for signal on channels A-B  
 Set 2 to check for signal on channels A-B-Z

If set to 4 the encoder signals A and B are controlled in single-ended mode (single channel)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.7	2112	<b>Encoder SSI bits</b>		UINT16		25	13	25	ERWZ	FVS

Setting of the length of the SSI package, defined as the number of clock cycles, in that the packages of the absolute SSI encoders available on the market vary in length from 13 to 25 bits.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.8	2130	<b>Encoder direction</b>		ENUM		Not inverted	0	1	RWZ	FVS

Setting of the sign of the information obtained from the incremental or absolute encoder.

- 0 Not inverted
- 1 Inverted

By setting 0 the encoder feedback signals are not inverted.

By setting 1 the encoder feedback signals are inverted

According to international standards, positive references are associated with clockwise motor rotation, seen from the control side (shaft). To ensure correct operation, the regulation algorithms ensure that positive speed references correspond to positive speed measurements.

If the motor pulley is mounted on the side opposite the command side, it will turn in an anticlockwise direction when the speed is positive: to make the pulley turn in a clockwise direction, the motor phase sequence is modified, which inverts the speed measurement sign. To restore the correct speed measurement sign, invert the incremental encoder A+ and A-signals and the absolute encoder Sin+ and Sin- signals on the encoder connections. The absolute part cannot be inverted with Endat and Hiperface absolute encoders.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.9	2132	<b>Encoder mode</b>		ENUM		None	CALCI	CALCI	ERWZ	FVS

Setting of the method for measuring the speed of the digital encoder connected to the optional card.

- 0 None
- 1 Digital FP
- 2 Digital F
- 3 Sinus
- 4 Sinus SINCOS
- 5 Sinus ENDAT
- 6 Sinus SSI
- 7 Sinus HIPER
- 8 Resolver

The speed measurement mode depends on the type of encoder card: default, minimum and maximum values are set according to the type of feedback card applied

Type of encoder option	Def	Min	Max
Enc 1	Digital F	Digital FP	Digital F
Enc 2	Sinus	Sinus	Sinus
Enc 3	Sinus SINCOS	Sinus SINCOS	Sinus SINCOS
Enc 4	Sinus SSI	Sinus ENDAT	Sinus SSI
Enc 5	Sinus HIPER	Sinus HIPER	Sinus HIPER

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.10	2134	<b>Encoder speed filter</b>	ms	FLOAT		2.0	0.1	20.0	ERW	FVS

Setting of the time constant of the filter applied to the feedback encoder pulse reading. The parameter affects both the accuracy of the speed measurement and the dynamics obtainable in closed loop control. On the other hand, the use of a speed measurement filter introduces delays that do not permit high control loop dynamics. Low settings extend the regulation bandwidth but may accentuate any disturbance. The filter is applied to the speed reported in the **Encoder speed** parameter

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.11	2150	<b>Encoder speed</b>	rpm	INT16	16/32BIT	0	0	0	ER	FVS

The motor speed measured by the incremental encoder is displayed, filtered by the **Encoder speed filter** parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.12	2162	Encoder position	cnt	UINT16	16BIT	0	0	0	ER	FVS

The impulse count obtained from the incremental encoder reading is displayed: 1 encoder turn is equal to the value entered in Encoder pulses multiplied by 4.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
15.13	2172	SpdFbkLoss code		UINT32		0	0	0	ER	FVS

The **Speed fbk loss** alarm generated by an encoder fault is displayed. Each type of encoder generates the alarm differently (incremental signal error, absolute signal error, serial error), so this parameter is used to display information about the alarm that has been activated. In case of several concurrent causes, these are shown in this parameter.

Bit	Value	Name
0	0x01	CHA
1	0x02	CHB
2	0x04	CHZ
3	0x08	MOD_INCR
4	0x10	MOD_ABS
5	0x20	CRC_CKS_P
6	0x40	ACK_TMO
7	0x80	DT1_ERR
8	0x100	Setup error
10..15		Free
16..31		Depends on the encoder

For further details reference should be made to the description of the **Speed fbk loss** alarm and to the SFL alarms chapter according to the type of feedback.

#### Note !

For the correct interpretation of the cause of the alarm trigger, it is necessary to transform the hex code indicated in parameter 15.13 SpdFbkLoss code, PAR 2172 , in the corresponding binary and verify in the encoder table that the active bits and related description are used.

Example with encoder Endat:

PAR 2172 = A0H      (hex value)

In the table “**Speed fbk loss [22] alarm with absolute encoder EnDat**” A0 is not indicated in the value column.

A0 should be contemplated as a bitword with meaning A0 -> 10100000 -> bit 5 and bit 7 . The following causes simultaneously intervene:

Bit 5 = 20H Cause: the SSI signal interferences cause an error in the CKS or parity

Bit 7 = 80H Cause: The encoder has detected an incorrect operation and communicates it to the converter through the Error bit. Bits 16..31 present the type of incorrect encoder operation detected.

## 16 - SPEED REG GAINS

The speed adaptive allows different speed regulator gains to be obtained according to the speed or another value. The behaviour of the speed regulator can thus be configured in the best way for the specific application requirements.

### Note !

Current, flux and voltage regulators can be set using the self-tuning procedure. If this is not successful, current and flux regulators can be tuned manually (this does not apply to voltage regulators, which must not be modified by the user). The speed regulator must be tuned manually. Gains are usually adjusted according to the drive speed.

Total gains used by the speed regulator are calculated as shown in the following examples. Results are in engineering units:


$$\text{Total proportional gain} = \frac{\text{Speed reg P1 gain (PAR 2200)}}{100\%} * \text{Speed reg P gain (PAR 2236)}$$

$$\text{Total integral gain} = \frac{\text{Speed reg I1 gain (PAR 2202)}}{100\%} * \text{Total proportional gain} * \frac{1}{\text{Speed reg I time (PAR 2238)}}$$


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
16.1	2200	<b>Speed reg P1 gain</b>	perc	INT16		100	0	1000	RW	F_S
Setting of the proportional gain of the speed regulator, set 1.										
16.2	2202	<b>Speed reg I1 gain</b>	perc	INT16		100	0	1000	RW	F_S
Setting of the integral gain of the speed regulator, set 1. Increasing the proportional gain value increases the proportional action of the regulator										
16.3	2204	<b>Speed reg P2 gain</b>	perc	INT16		100	0	1000	RW	F_S
Setting of the proportional gain of the speed regulator, set 2.										
16.4	2206	<b>Speed reg I2 gain</b>	perc	INT16		100	0	1000	RW	F_S
Setting of the integral gain of the speed regulator, set 2. Increasing the proportional gain value increases the proportional action of the regulator										
16.5	2208	<b>Speed reg P3 gain</b>	perc	INT16		100	0	1000	ERW	F_S
Setting of the proportional gain of the speed regulator, set 3.										
16.6	2210	<b>Speed reg I3 gain</b>	perc	INT16		100	0	1000	ERW	F_S
Setting of the integral gain of the speed regulator, set 3. Increasing the proportional gain value increases the proportional action of the regulator.										
16.7	2228	<b>Speed reg P0 gain</b>	perc	INT16		100	0	1000	ERW	F_S
Setting of the proportional gain of the speed regulator at zero speed.										
16.8	2230	<b>Speed reg I0 gain</b>	perc	INT16		100	0	1000	ERW	F_S
Setting of the integral gain of the speed regulator at zero speed. Increasing the proportional gain value increases the proportional action of the regulator										
16.9	2218	<b>Gain adp spd thr2_1</b>	perc	FLOAT		10.0	0.0	100.0	ERW	F_S
Setting of the speed threshold for changing gains from set 1 to set 2.										
16.10	2220	<b>Gain adp spd band2_1</b>	perc	FLOAT		5.0	0.0	100.0	ERW	F_S
Setting of the band within which gains vary between set 1 and set 2. The use of this parameter ensures a smooth transition between the two parameter sets.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
16.11	2222	<b>Gain adp spd thr3_2</b>	perc	FLOAT		0.0	0.0	100.0	ERW	F_S
Setting of the speed threshold for changing gains from set 3 to set 2.										
16.12	2224	<b>Gain adp spd band3_2</b>	perc	FLOAT		0.0	0.0	100.0	ERW	F_S
Setting of the band within which gains vary between set 3 and set 2. The use of this parameter ensures a smooth transition between the two parameter sets.										
16.13	2246	<b>Gain adp spd thr0_2</b>	perc	FLOAT		0.0	0.0	100.0	ERW	F_S
Setting of the speed threshold for changing gains from set 0 to set 2.										
16.14	2248	<b>Gain adp spd band0_2</b>	perc	FLOAT		0.0	0.0	100.0	ERW	F_S
Setting of the band within which gains vary between set 0 and set 2. The use of this parameter ensures a smooth transition between the two parameter sets.										
16.15	2244	<b>Gain profile mode</b>		ENUM		Profile 21	0	3	ERW	F_S
Gain profile modes.										
<ul style="list-style-type: none"> <li>0 Profile 1</li> <li>1 Profile 21</li> <li>2 Profile 321</li> <li>3 Profile 0213</li> </ul>										
<ul style="list-style-type: none"> <li>• If set to 0 the profile used is that shown in the figure below:</li> </ul>										
<ul style="list-style-type: none"> <li>• If set to 1 the profile used is that shown in the figure below:</li> </ul>										

- If set to 2 the profile used is that shown in the figure below:



- If set to 3 the profile used is that shown in the figure below:



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
16.16	2232	<b>Spd reg P gain Inuse</b>	perc	INT16	16/32BIT	100	0	1000	ER	F_S

The current proportional coefficient of the speed regulator is displayed as a percentage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
16.17	2234	<b>Spd reg I gain Inuse</b>	perc	INT16	16/32BIT	100	0	1000	ER	F_S

The current integral coefficient of the speed regulator is displayed as a percentage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
16.18	2236	<b>Speed reg P gain</b>	N/rpm	FLOAT		CALCF	0.0	500.0	ERWS	F_S

Setting of the proportional coefficient of the speed regulator.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
16.19	2238	<b>Speed reg I time</b>	ms	FLOAT		CALCF	1.0	5000.0	ERWS	F_S
Setting of the integral coefficient of the speed regulator. Reducing the integral time value increases the integral action of the regulator.										
16.20	2240	<b>Inertia</b>	kgm2	FLOAT		SIZE	0.001	100.0	RWZS	F_S
Setting of total inertia of the application with reference to the motor shaft. When this parameter is modified, all speed regulator gains are initialised according to the value specified by parameter PAR 2242. An increase in the dynamic response of the speed regulator to a variation in the reference, can be modified by changing the current value during the acceleration/deceleration phase, to counter the applied machine inertia.										
16.21	2242	<b>Bandwidth</b>	rad/s	FLOAT		SIZE	1.0	500.0	RWZS	F_S
Setting of the bandwidth. Increasing the setting of this parameter increases the dynamic response and makes the system more rigid.										

## 17 - REGULATOR PARAM

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.1	2250	<b>Current reg P gain</b>	V/A	FLOAT		CALCF	0.0	0.0	ERWS	F_S
Setting of the proportional coefficient of the current regulator.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.2	2252	<b>Current reg I time</b>	ms	FLOAT		CALCF	0.01	10000.0	ERWS	F_S
Setting of the integral coefficient of the current regulator.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.3	2260	<b>Flux reg P gain</b>	A/Wb	FLOAT		CALCF	0.0	0.0	ERWS	F_
Setting of the proportional coefficient of the flux regulator.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.4	2262	<b>Flux reg I time</b>	ms	FLOAT		CALCF	0.01	10000.0	ERWS	F_
Setting of the integral coefficient of the flux regulator.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.5	2264	<b>Flux reg P gain OL</b>	A/Wb	FLOAT		CALCF	0.0	0.0	ERWS	S
Setting of the flux regulator proportional gain when the drive is used in open loop sensorless vector control mode. This parameter is set automatically by the self-tuning procedure.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.6	2266	<b>Flux reg I time OL</b>	ms	FLOAT		CALCF	0.01	10000.0	ERWS	S
Setting of the flux regulator integral time when the drive is used in open loop sensorless vector control mode. This parameter is set automatically by the self-tuning procedure.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.7	2270	<b>Voltage reg P gain</b>	Wb/V	FLOAT		CALCF	0.0	0.0	ERWS	F_S
Setting of the proportional coefficient of the voltage regulator.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.8	2272	<b>Voltage reg I time</b>	s	FLOAT		CALCF	0.1	100.0	ERWS	F_S
Setting of the integral coefficient of the voltage regulator.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.9	2280	<b>Dead time limit</b>	V	FLOAT		SIZE	0.0	50.0	ERWS	FVS
Setting of the dead time voltage compensation value. The dead time compensation function ( <b>Dead time compensation</b> ), compensates the distortion of output voltage caused by the voltage drop on the IGBT devices and their switching characteristics. Distortion of output voltage could cause irregular motor rotation.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.10	2282	<b>Dead time slope</b>	V/A	FLOAT		SIZE	0.0	200.0	ERWS	FVS
Setting of the dead time compensation slope value.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.11	2290	<b>Voltage base</b>	V	FLOAT		CALCF	50.0	690.0	ERWS	F_S
Setting of the basic voltage of the motor. This parameter is calculated automatically by the self-tuning procedure.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.12	2292	<b>Voltage margin</b>	perc	FLOAT		5.0	0.0	10.0	ERWS	F_S

Setting of the voltage regulation margin according to the available voltage. In case of a Voltage base setting close to or equal to the actual mains value, **Voltage margin** represents the margin allowable by the voltage regulation to perform rapid current variations when load steps are suddenly applied.

A value of 5% allows a very fast response to load steps but with a loss of output voltage and thus power output (reduced power output).

The minimum value (1%) allows a maximum output voltage (around 98%) of the mains voltage to be achieved but with loss of quality of the dynamic response.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.13	2300	<b>Minimum speed OL</b>	rpm	INT16		15	0	CALCI	ERW	__S

Setting of the minimum speed threshold in the sensorless vector control mode. Below this limit the sensorless regulator is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.14	2302	<b>Min speed delay OL</b>	ms	UINT16		800	0	5000	ERW	__S

Setting of the delay for disabling the sensorless regulator.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.15	2304	<b>Speed filter OL</b>	ms	FLOAT		5.0	0.1	20.0	ERWZ	__S

Setting of the time constant for the estimated speed in sensorless vector mode. By increasing this parameter it is possible to reduce the level of disturbance of the estimated speed, but the speed control dynamics are also lowered.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.16	2306	<b>Flux observe gain OL</b>		FLOAT		500.0	10.0	5000.0	ERW	__S

Flux observer gain in open-loop flux vector control mode.

In case of instability, try changing the value and setting half or twice the default value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
17.17	2310	<b>Flux weakening OL</b>		ENUM		Disable	0	1	ERWZ	__S

Enables or disables flux reduction in the open-loop flux vector control mode.

If set to Disable, the flux is not reduced when the speed of the motor exceeds the nominal speed. This results in loss of control and instability.

This problem can be prevented by setting the parameter to Enable.

In the open-loop mode a flux value of less than the nominal speed of the motor is advantageous in terms of stability.

- 0 Disable
- 1 Enable

## 18 - TORQUE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.1	2350	Torque curr lim Pos	A	FLOAT	16/32BIT	CALCF	0.0	CALCF	ERWS	FVS

Setting of the active torque limit of the drive for the positive current direction (clockwise rotation and anti-clockwise braking).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.2	2352	Torque curr lim Neg	A	FLOAT	16/32BIT	CALCF	0.0	CALCF	ERWS	FVS

Setting of the active torque limit of the drive for the negative current direction (anti-clockwise rotation and clockwise braking).


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.3	2354	Torque curr lim sel		ENUM		Sorg limcoppia	0	3	ERWZ	FVS

Setting of the type of behaviour of the drive in the current limit condition.

- 0 Off
- 1 T clim +/-
- 2 T clim mot/gen
- 3 T limit src

If set to **0** no specific type of current limitation is set.

If set to **1** the active positive torque limit is **Torque curr lim Pos** and the active negative torque limit is **Torque curr lim Neg**.



If set to **2** three conditions are possible:

- 1 – If the motor speed is > +1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** and the active negative torque limit is **Torque curr lim Neg**.
- 2 – If the motor speed is < -1% of **Rated speed** the active positive torque limit is **Torque curr lim Neg** and the active negative torque limit is **Torque curr lim Pos**.
- 4 – If -1% of Motor non speed < motor speed < + 1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** and the active negative torque limit is **Torque curr lim Neg**

If set to **3** the torque limits are symmetrical. The torque reference is the value of **Torque curr lim Pos**. This mode is not managed with SSC control mode.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.4	2358	Torque limit src		LINK	16/32BIT	3726	0	16384	ERWZ	F_S

Selection of the origin (source) of the signal to be used for the torque current limit. The signals that can be associated with the function are listed in the "**L\_LIM**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.5	2360	<b>Torque climPos Inuse</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	ER	FVS
The positive torque limit value currently being used is displayed.										
18.6	2362	<b>Torque climNeg Inuse</b>	A	FLOAT	16/32BIT	0.0	0.0	0.0	ER	FVS
The negative torque limit value currently being used is displayed.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.7	2380	<b>Dig torque ref 1</b>	perc	FLOAT	16/32BIT	0.0	-300.0	300.0	ERW	FVS
Setting of a digital torque reference. The current reference value is proportional to the active motor current and determines the torque value. The sign determines the torque direction.										
18.8	2382	<b>Torque ref 1 src</b>		LINK	16/32BIT	3104	0	16384	ERWZ	F_S
Selection of the origin (source) of the signal to be used for the torque reference. The signals that can be associated with the function are listed in the " <u>L_VREF</u> " selection list.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
18.9	2384	<b>Torque ref filter</b>	ms	FLOAT		1.0	0.1	10.0	ERW	F_S
Setting of a filter on the torque reference.										
18.10	2386	<b>Torque ref</b>	perc	FLOAT	16/32BIT	0.0	0.0	0.0	ER	F_S
The value of the torque reference is displayed.										


## 19 - VF PARAMETERS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.1	2400	<b>Voltage flux boost</b>	perc	FLOAT		CALCF	0.0	15.0	RWS	_V_
Fixed voltage boost level. Value defined during self-tuning.										
The motor flux level is controlled in vector mode. For pure V/f control, set this parameter to zero.										
Increase the value slightly in case of low torque at low speed.										
Increase the value slightly in case of high current with motor saturation or very long motor cables.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.2	2402	<b>Voltage boost gain</b>	V/A	FLOAT		CALCF	0.0	0.0	ERWS	_V_
Setting of the boost flux magnetising current regulator gain.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.3	2404	<b>Voltage torque boost</b>		ENUM		Enable	0	1	ERWZ	_V_
Enables vector torque compensation. For pure V/f control, disable this parameter.										
0 Disable										
1 Enable										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.4	2406	<b>Vf voltage</b>	V	FLOAT		CALCF	10.0	690.0	ERWZS	_V_
Setting of the maximum voltage value to be applied at the motor terminals (usually set according to the motor data plate).										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.5	2408	<b>Vf frequency</b>	Hz	FLOAT		CALCF	10.0	2000.0	ERWZS	_V_
Setting of the motor rated frequency (indicated on the motor data plate)										
This is the frequency at which the drive output voltage reaches the maximum output voltage ( <b>Vf voltage</b> ) on the motor.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.6	2410	<b>Vf voltage 1</b>	V	FLOAT		CALCF	CALCF	CALCF	ERWZS	_V_
Setting of an intermediate voltage value for the custom V/f characteristic curve.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.7	2412	<b>Vf frequency 1</b>	Hz	FLOAT		CALCF	0.0	CALCF	ERWZS	_V_
Setting of an intermediate frequency value for the custom V/f characteristic curve.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.8	2414	<b>Vf voltage 0</b>	V	FLOAT		0.0	0.0	CALCF	ERWZS	_V_
Compensation of IR voltage drop at 0 Hz. This parameter must be increased in case of pure V/f control. The increase depends on the size of the motor. Values that are too high could cause an overcurrent and motor saturation.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.9	2430	<b>Vf shape</b>		ENUM		Linear	0	1	ERWZS	_V_
Selection of the type of V/f characteristic curve										
0 Linear										
1 Custom										



Set **0 (Linear)** to obtain a linear V/f characteristic curve, on which the intermediate points are reset to a value that is equal to half those of parameters **2406** and **2408**.

The Boost joins the curve automatically.



Set **1 (Custom)** to obtain a customized V/f characteristic curve, in which the intermediate voltage and frequency values are defined by parameters **2410** and **2412**, as is the point at which the Boost joins the characteristic curve.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.10	2440	<b>Slip comp</b>	Hz	FLOAT		CALCF	0.0	10.0	RWS	_V_

Setting of the slip compensation. When the asynchronous motor is loaded, the mechanical speed of the motor shaft varies according to the electric slippage, which affects torque generation. The slip compensation function can be used to maintain a constant motor shaft speed. Compensation is performed by varying the drive output frequency as a function of its output current and the motor parameters. Thus, to obtain the best effect, the motor plate data must be set appropriately, and the correct stator resistance value (Par.2050) must be set or measured using the self-tuning function. The slip compensation value is calculated automatically during the self-tuning procedure or set manually in this parameter.

During slip compensation tuning the drive must not be in the current limit condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.11	2442	<b>Slip comp filter</b>	ms	UINT16		200	50	5000	ERW	_V_

Setting of the slip compensation filter. The value set in this parameter determines the slip compensation function reaction time. The lower this parameter is set, the greater the slip compensation reaction. If this parameter is too low, it could cause undesirable oscillations in speed after sudden variations to the applied load.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.12	2444	<b>Slip comp mode</b>		ENUM		Open loop lift	0	2	ERWZ	_V_

- 0 Open loop
- 1 Closed loop
- 2 Open loop lift

When set to **0 (Open loop)** the slip compensation value is that set manually in parameter 5210 or calculated by the self-tuning procedure.

If set to **1 (Closed loop)** the slip compensation value is measured by the reading of the signals by a digital encoder keyed to the motor shaft. The relative expansion card must be installed in the drive to acquire the encoder signals. For best results increase the value of PAR 2440 by 5 times.

If set to 2 (lift open loop) the slip compensation value is that set for lift cycle operation.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.13	2446	<b>Slip P gain</b>	perc	FLOAT		1.0	0.0	100.0	ERWS	_V_

Setting of the slip compensation proportional gain.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.14	2448	<b>Slip I gain</b>	perc	FLOAT		1.5	0.0	100.0	ERWS	_V_
Setting of the slip compensation integral gain.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.15	2460	<b>Vfcurrent lim P gain</b>	Hz/A	FLOAT		CALCF	0.0	1000.0	ERWS	_V_
Setting of the proportional gain limit in SSC mode. This is calculated automatically if the self-tuning procedure is performed.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.16	2462	<b>Vfcurrent lim I time</b>	ms	FLOAT		CALCF	1.0	50.0	ERWS	_V_
Setting of the proportional gain limit in SSC mode. This is calculated automatically if the self-tuning procedure is performed.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.17	2470	<b>Damping gain</b>	perc	UINT16		0	0	100	ERW	_V_
Setting of the damping gain. The parameter is used to eliminate any oscillations or faults in the drive output current, deriving from configurations capable of generating oscillations in the drive/cable/motor system. If oscillations occur, gradually increase the value of this parameter, until they disappear.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.18	2472	<b>Damping threshold 1</b>	Hz	INT16		20	5	100	ERW	_V_
Setting of the first damping gain regulation threshold. These settings are usually effective for intermediate frequencies and make it possible to limit motor oscillations.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.19	2474	<b>Damping threshold 2</b>	Hz	INT16		30	5	100	ERW	_V_
Setting of the second damping gain regulation threshold. These settings are usually effective for intermediate frequencies and make it possible to limit motor oscillations.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.20	2480	<b>Vf min frequency</b>	Hz	FLOAT		0.5	0.2	5.0	ERW	_V_
Setting of the minimum frequency in the SSC control mode. This represents the minimum output frequency, below which frequency regulations are ineffective. It is not possible to go below this value, regardless of the reference that has been set.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.21	2482	<b>Vf min freq delay</b>	ms	UINT16		800	0	5000	ERW	_V_
Setting of the delay for the minimum frequency signal in the SSC control mode.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.22	2490	<b>Dig Vf scale</b>		FLOAT	16/32BIT	1.0	0.0	1.0	ERWZ	_V_
Setting of a digital multiplier factor for the drive output voltage in the SSC mode.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
19.23	2492	<b>Vf scale src</b>		LINK	16/32BIT	2490	0	16384	ERW	_V_
Selection of the origin (source) of the signal to be used to set a multiplier factor for the drive output voltage. The associable functions are listed in the ““L_VREF” selection list.										

## 20 - FUNCTIONS

### 20.1 - FUNCTIONS/INERTIA COMP

An increase in the dynamic response of the speed regulator to a variation in the reference, can be modified by changing the current value during the acceleration/deceleration phase, to counter the applied machine inertia.

These parameters are calculated by the speed loop autotuning procedure but can also be set manually by the user.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.1.1	3100	Inertia comp	kgm2	FLOAT		0.0	0.0	100.0	ERWS	F_S

Total value of the inertia on the motor shaft in Kgm<sup>2</sup> identified during the self-tuning procedure. If known, this value can also be set manually by the user.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.1.2	3102	Inertia comp filter	ms	UINT16		30	1	100	ERW	F_S

Setting of a filter on the torque compensation. The filter reduces noise due to speed differentiation in the inertia block.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.1.3	3104	Inertia comp mon	perc	FLOAT	16/32BIT	0.0	0.0	0.0	ER	F_S

The value of inertia compensation on the function block output is displayed.

### 20.2 - FUNCTIONS/DC BRAKING

The drive is capable of managing a direct current injection phase. During this phase a braking torque is generated that can be used to stop the motor or block the rotor.

The following characteristics can be configured:

- signal used to activate the direct current injection phase
- direct current injection phase activation mode
- delay between activation of request for DC braking and start of direct current injection
- duration of direct current injection phase
- intensity of injected direct current

This function is useful for:

- slowing the motor running at any speed to zero speed
- slowing a motor driven by the load before applying the start command
- keeping the rotor blocked at the end of a deceleration ramp following a stop command.

This function cannot be used for intermediate braking as the motor speed must be brought to zero.

During the direct current injection phase the kinetic energy of the motor is dissipated as heat in the motor.

The following parameters allow complete control of the function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.2.1	3150	DC braking cmd src	LINK	16BIT		3710	0	16384	ERW	FVS

Selection of the origin (source) of the signal to be used for the **DC braking command**. The terminal or signal that can be used for this function can be defined from among those available in the “**L\_DIGSEL2**” selection list”.

- 0 DC braking command not enable  
1 DC braking command enable


In default conditions the origin of the **DC braking command** signal is 0 .

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.2.2	3152	DC brake mode	ENUM			Sponto	0	3	ERW	FVS

This parameter can be used to configure the DC braking activation modes.

- 0 Off  
1 At Stop  
2 On Command  
3 OnCmd & AtStop

## DC Braking



In "Off" mode the direct current injection phase is never executed.

In "At stop" mode the direct current injection phase is executed when the stop command is sent and the speed reference threshold = zero has been reached.

Example:

With the motor running at any speed, when the stop command is enabled the ramp output decreases according to the selected ramp time, when the speed reference threshold = zero is reached PAR 934 **Reference = 0** the direct current injection phase is enabled. When the command is enabled after the delay configured in PAR 3154 **DC brake delay** direct current injection starts. PAR 3156 **DC brake time** is used to configure the duration of the injection phase and PAR 3158 **DC brake curr** is used to configure the intensity of the injection phase current.

In "At command" mode the direct current injection phase is executed when the **DC braking command** configured using parameter PAR 3150 **DC braking command src** is sent.

Example:

Motor running driven by load. When the drive is enabled and the **DC braking command** is sent the direct current injection phase is activated. When the command is enabled after the delay configured in PAR 3154 **DC brake delay** direct current injection starts. PAR 3156 **DC brake time** is used to configure the duration of the injection phase and PAR 3158 **DC brake curr** is used to configure the intensity of the injection phase current.

If the command is an impulse shorter than the time programmed with PAR 3156 **DC brake time**, the direct current injection phase continues at least for the time set in parameter **DC brake time**.

If the command is an impulse longer than the time programmed with 3156 **DC brake time**, the direct current injection

phase continues for as long as the command is present.

In “**OnCmd & AtStop**” modes the direct current injection phase is executed when one of the two conditions described in the “**At stop**” or “**On command**” modes is present

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.2.3	3154	<b>DC brake delay</b>	s	FLOAT		0.0	0.00	30.0	ERW	FVS

This parameter is used to configure the delay in seconds between the moment DC braking is requested and the moment direct current injection starts.

This delay enables the motor to demagnetize, and thus avoid an overcurrent due to the electromotive force of the motor (e.f.m.).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.2.4	3156	<b>DC brake duration</b>	s	FLOAT		1.0	0.01	30.0	ERW	FVS

This parameter is used to configure the duration of direct current injection in the stator windings.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.2.5	3158	<b>DC brake current</b>	perc	FLOAT		75.0	0.0	150.0	ERW	FVS

This parameter is used to configure the value of the injected direct current.

This is expressed as a percentage of the rated current of the motor at full load (par. 488 **Drive cont current**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.2.6	3160	<b>DC brake state</b>		ENUM	16BIT	Non attivo	0	1	ER	FVS

The status of direct current braking is displayed.

0 Not active

1 Active

#### Note!

During braking the **Enable** command must be enabled. If this command is not present or is removed during the braking process, the drive blocks the inverter bridge and the motor stops due to inertia, without braking.

During the direct current injection phase the **Run** command should not be enabled. If the **Run** command is sent to the drive, the ramp output starts following the set reference; direct current output is produced in any case. The moment the **DC braking command** is removed there is immediately a speed step without performing a change in the ramp.

During the direct current injection phase, for the Jog command follow the instructions provided for the Run command.

## 20.3 - FUNCTIONS/MOTOR OVERLOAD

The overload control function provides integrator logic to protect the motor against thermal overload. This protection presents the characteristic  $I^2t$  behaviour and is an emulation of the thermal relay of the motor controlled by the ADL200 drive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.3.1	3200	<b>Motor ovd enable</b>		BIT		0	0	1	ERW	FVS

Enabling of the motor overload control.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.3.2	3202	<b>Motor ovd factor</b>	perc	FLOAT		150.0	100.0	300.0	ERWS	FVS

Setting of the motor overload value. Percentage value of the motor rated current (par. 2002 **Rated current**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.3.3	3204	<b>Motor ovd time</b>	s	FLOAT		30.0	10.0	300.0	ERWS	FVS

Setting of the motor overload duration in seconds. It represents the moment in which the protection (“Motor Overload”) is enabled, if the motor current value is above the overload set in the **Motor ovd factor** parameter. This alarm can be assigned to a programmable digital output (**Motor overload trip**).

The trip time depends on the motor current value and is as follows:



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.3.4	3206	<b>Motor service factor</b>	perc	FLOAT		100.0	25.0	200.0	ERWS	FVS

Setting of the motor service factor. This is the difference between the peak current and rated current. It is used to calculate the thermal image of the motor.

## 20.4 - FUNCTIONS/BRES OVERLOAD

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.4.1	3250	<b>Bres control</b>		BIT		1	0	1	ERWZ	FVS

Enabling of the external braking resistance and relative overload control.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.4.2	3252	<b>Bres value</b>	ohm	FLOAT		SIZE	7.0	1000.0	ERWS	FVS

Setting of the ohm value of the external braking resistor

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.4.3	3254	<b>Bres cont power</b>	kW	FLOAT		SIZE	0.1	100.0	ERWS	FVS

Setting of the power that can be continuously dissipated by the external braking resistor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.4.4	3256	<b>Bres overload factor</b>		FLOAT		SIZE	1.5	10.0	ERWS	FVS

Setting of the external resistor overload factor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.4.5	3258	<b>Bres overload time</b>	s	FLOAT		SIZE	0.5	50.0	ERWS	FVS


Setting of the intervention time of the external braking resistor overload.

## 20.5 - FUNCTIONS/DIDOUBLE PAR SET

Two independent sets of parameters can be stored in the ADL200 drive. These can be selected via the keypad or by using an external command.

This makes it possible to change all the drive parameters quickly and automatically according to the various operating requirements. For example, two motors with different characteristics can be controlled alternately.

**Lift application parameters are not included in the two sets of parameters.** This makes it possible to switch between all drive parameters in two separate groups, while having a single set of parameters for the application.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.5.1	3300	<b>Par set enable</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of management of two parameter sets										
0 Disable										
1 Enable										
When set to <b>0</b> only one parameter set is managed (the one used as the default set).										
If set to <b>1</b> two separate parameter sets can be configured. These can be selected using a command signal on a digital input of the terminal strip.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.5.2	3302	<b>Par set select src</b>		LINK	16BIT	6000	0	16384	ERWZ	FVS
Selection of the origin (source) of the signal to be used to select the parameter set to be used. The terminal or digital command that can be associated with this function can be selected from among those available in the "L_DIGSEL2" selection list.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.5.3	3304	<b>Par set select mon</b>		ENUM	16BIT	Set 0	0	0	ER	FVS
The parameter set currently in use is displayed.										
0 Set 0										
1 Set 1										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.5.4	3306	<b>Par set 0 to 1 copy</b>		BIT		0	0	1	ERWZ	FVS

#### Procedures for setting up and managing the double parameter set

##### **Creating the second set:**

This function copies parameter set 0 onto set 1. Before enabling management of the double parameter set, the first set should be programmed with the correct values.

When the first set is ready, the second can be activated as follows:

- 1 Activate management of the double parameter set by enabling parameter **3300 Par set enable**.
- 2 Copy set 0 onto set 1 using command **3306 Par set 0 to 1 copy**.  
This creates an initial parameter base in set 1 to which changes can be made.  
Save the parameters.
- 3 Activate set 1 using parameter **3302 Par set select src**.  
To select set 1 manually, set this parameter to "One".  
Otherwise select the desired source.
- 4 Modify the parameters in set 1 as necessary.
- 5 Save the parameters.

You can change the set being used by changing the source selected in parameter **3302 Par set select src**. This can only be changed with the drive disabled.

When the double parameter set is active, the number of the set being used is shown next to the number of each parameter on the keypad.

### Modifying and saving parameters:

When the double parameter set is active, any parameters that need to be the same in the two sets must be modified in each set separately.

Parameters are only saved in the set that is active at the time. To save both sets, you must first save one and then select and save the other.

**Note!**

Any changes to the parameters regarding the “parameter sets”, performed when enabled, will be lost at the next switching unless a Par set 0 to 1 copy command is sent.

To save data permanently (even when the drive is switched off), send the Save parameters command (DRIVE CONFIG menu).

## 20.6 - FUNCTIONS/SPEED CAPTURE

**Note!**

This menu is not displayed if the lift application is enabled

## 20.7 - FUNCTIONS/COMPARE

This function allows the comparison among two signals or values.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.1	3650	Dig compare input 1	perc	FLOAT	32BIT	0.0	-100.0	100.0	ERW	FVS

Setting of the digital value of the first element of comparison.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.2	3652	Dig compare input 2	perc	FLOAT	32BIT	0.0	-100.0	100.0	ERW	FVS

Setting of the digital value of the second element of comparison.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.3	3660	Compare input 1 src		LINK	32BIT	3650	0	16384	ERW	FVS

Selection of the origin (source) of the signal to be used as the first term of comparison. The values that can be selected in the compare function are listed in the “L\_CMP” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.4	3662	Compare input 2 src		LINK	32BIT	3652	0	16384	ERW	FVS

Selection of the origin (source) of the signal to be used as the second term of comparison. The values that can be selected in the compare function are listed in the “L\_CMP” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.5	3670	Compare function		ENUM		Nessuna	0	8	ERW	FVS

Setting of the compare function between **Compare input 2** and **Compare input 1** to enable **Cmp output**.

- 0 None
- 1 Inp1=Inp2
- 2 Inp1!=Inp2
- 3 Inp1<Inp2
- 4 Inp1>Inp2
- 5 |Inp1|=|Inp2|
- 6 |Inp1|!=|Inp2|
- 7 |Inp1|<|Inp2|
- 8 |Inp1|>|Inp2|

If set to 0 the comparator is not enabled

If set to 1 the comparator output is enabled when the value of **Compare digital inp 1** is inside the window resulting from the value of **Compare digital inp 2** ± the tolerance set via the **Comparator Window**.

If set to 2 the comparator output is enabled when the value of **Compare digital inp 1** is not inside the window resulting

from the value of **Compare digital inp 2** ± the tolerance set via the **Comparator Window**.

If set to **3** the comparator output is enabled when **Compare input 1** is less than **Compare input 2**.

If set to **4** the comparator output is enabled when **Compare input 1** is greater than **Compare input 2**.

If set to **5** the comparator output is enabled when the value of **Compare digital inp 1** is inside the window resulting from the absolute value of **Compare digital inp 2** ± the tolerance set via the **Comparator Window**.

If set to **6** the comparator output is enabled when the absolute value of **Compare digital inp 1** is not inside the window resulting from the absolute value of **Compare digital inp 2** ± the tolerance set via the **Comparator Window**.

If set to **7** the comparator output is enabled when the absolute value of **Compare digital inp 1** is less than the absolute value of **Compare digital inp 2**.

If set to **8** the comparator output is enabled when the absolute value of **Digital compar inp1** is more than the absolute value of **Digital compar in2**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.6	3672	<b>Compare window</b>	perc	FLOAT		0.0	0.0	100.0	ERW	FVS

Setting of the tolerance window for comparing the **Compare input 1** and **Compare input 2** signals.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.7	3674	<b>Compare delay</b>	s	FLOAT		0.0	0.0	30.0	ERW	FVS

Setting of the delay for signalling the result of the comparison.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.7.8	3676	<b>Compare output</b>		BIT	16BIT	0	0	1	ER	FVS

The status of the comparator output is displayed:

**0** The result of the set comparison is negative

**1** The result of the set comparison is positive

## 20.8 - FUNCTIONS/PADS

The general variables are used to exchange data between the various components of a Bus system. They are similar to the variables of a PLC. Pads can be used, for example, to send information from a fieldbus to an optional card. All Pads can be read and written.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
20.8.1	3700	<b>Lift enable</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.2	3702	<b>Run cont mon</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.3	3704	<b>Up cont mon</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.4	3706	<b>Down cont mon</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.5	3708	<b>Brake cont mon</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.6	3710	<b>Lift dc brake</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.7	3712	<b>Brake 2 mon</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.8	3714	<b>Door open mon</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.9	3716	<b>Lift start</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.10	3718	<b>Pad 10</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.11	3720	<b>Lift status word</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.12	3722	<b>Pad 12</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.13	3724	<b>Pad 13</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.14	3726	<b>Ramp down limit</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.15	3728	<b>Input variable</b>		INT32	32BIT	0	0	0	ERW	FVS
20.8.16	3730	<b>Lift wdec input</b>		INT32	32BIT	0	0	0	ERW	FVS

Setting of general, 32 Bit variables. PAD parameters can be used as supporting parameters to send values written by the fieldbus, serial line, etc. to analog or digital outputs.

## 21 - COMMUNICATION

### 21.1 - COMMUNICATION/RS232

The ADL200 drive is provided with a standard port (9 pole sub-D connector: XS) for connecting the RS232 serial line used for drive-PC point-to-point communication (via the GF-eXpress configuration software).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.1.1	3800	Drive address		UINT16		1	1	255	ERW	FVS

Setting of the address to which the drive responds when connected to the RS232 serial line.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.1.2	3802	Serial baudrate		ENUM		38400	0	2	ERW	FVS

Setting of the RS232 serial communication speed (Baud Rate).

- 0 9600
- 1 19200
- 2 38400

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.1.3	3810	Serial parameter		ENUM		None,8,1	0	3	ERW	FVS

Setting of the format of the RS232 serial line.

- 0 None,8,1
- 1 None,8,2
- 2 Even,8,1
- 3 Odd,8,1

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.1.4	3804	Serial protocol		ENUM		Modbus	0	1	ERW	FVS

Setting of the serial communication protocol:

- 0 Modbus
- 1 Jbus

Setting to **0** selects the Modbus RTU (Remote Terminal Unit) serial communication protocol.

Setting to **1** selects the Jbus serial communication protocol. The Jbus protocol is functionally identical to the Modbus, except for the different numbering of addresses: in the Modbus these start from zero (0000 = 1st address) while in the JBUS they start from one (0001 = 1st address) and maintain this difference throughout numbering.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.1.5	3806	Serial delay	ms	UINT16		0	0	1000	ERW	FVS

Setting of the minimum delay between the drive receiving the last byte and starting its response. This delay avoids conflicts on the serial line when the RS232 interface that is used has not been pre-set for automatic Tx/Rx switching. The parameter only concerns the use of the standard RS232 serial line.

Example: if the delay in Tx/Rx switching on the master is a maximum of 20ms, the **Ser answer delay** parameter must be set to at least 20ms: 22ms

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.1.6	3808	Serial swap data		BIT		0	0	1	ERW	FVS

This parameter enables the exchange of the reading of the High and Low parts of the words for FLOAT type parameters when using the Modbus protocol.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.2.1	4000	Fieldbus type		ENUM		Sponto	0	2	ERW	FVS

Setting of the type of fieldbus to be used.

- 0 Off
- 1 CanOpen
- 10 DS402 Profile

If set to **0** no fieldbus is selected.

If set to **1** the CanOpen fieldbus profile is selected.

If set to **10** the DS402 fieldbus is selected.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod			
21.2.2	4004	Fieldbus baudrate	ENUM			500k	0	4	ERW	FVS			
Setting of the communication network speed (Baud Rate)													
0 Auto													
1 125k													
2 250k													
3 500k													
4 1M													
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod			
21.2.3	4006	Fieldbus address	INT16			3	0	255	ERW	FVS			
Setting of the node address of the drive when connected to the network.													
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod			
21.2.4	4010	Fieldbus M->S enable	ENUM			Enable	0	1	ERWZ	FVS			
Setting of fieldbus data updating.													
0 Disable													
1 Enable													
If set to 0, the possibility of sending commands and references from the drive PLC via the fieldbus is disabled.													
If set to 1 the possibility of sending commands and references from the drive PLC via the fieldbus is enabled.													
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod			
21.2.5	4012	Fieldbus alarm mode	INT32			0	0	1	ERWZ	FVS			
Setting of the Opt Bus Fault alarm generation mode.													
0 Disable													
1 Enable													
If set to 0 the alarm is only generated if the communication with the fieldbus is lost with the drive enabled..													
If set to 1 the alarm is generated when the communication with the fieldbus is lost even if the drive is disabled. .													
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod			
21.2.6	4014	Fieldbus state	ENUM			Stop	0	2	R	FVS			
The logic status of the fieldbus connection is displayed. The value depends on the type of bus that is used.													
0 Stop													
1 Pre operational													
2 Operational													

## 21.3 - COMMUNICATION/FIELDBUS M2S

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.3.1	4020	Fieldbus M->S1 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.5	4030	Fieldbus M->S2 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.9	4040	Fieldbus M->S3 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.13	4050	Fieldbus M->S4 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.17	4060	Fieldbus M->S5 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.21	4070	Fieldbus M->S6 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.25	4080	Fieldbus M->S7 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.29	4090	Fieldbus M->S8 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.33	4100	Fieldbus M->S9 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.37	4110	Fieldbus M->S10 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.41	4120	Fieldbus M->S11 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.45	4130	Fieldbus M->S12 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.49	4140	Fieldbus M->S13 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.53	4150	Fieldbus M->S14 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.57	4160	Fieldbus M->S15 ipa	FBM2SIPA			0	0	20000	ERW	FVS
21.3.61	4170	Fieldbus M->S16 ipa	FBM2SIPA			0	0	20000	ERW	FVS

Setting of the parameter to associate with the bus channel. The default setting is 0, which means channel not active.

If the parameter to be connected is a **sorg** (source), the channel and parameter can also be associated by modifying the **sorg** parameter in its menu.

When setting a parameter, the format is also automatically set in the sys parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.3.2	4022	Fieldbus M->S1 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.6	4032	Fieldbus M->S2 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.10	4042	Fieldbus M->S3 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.14	4052	Fieldbus M->S4 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.18	4062	Fieldbus M->S5 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.22	4072	Fieldbus M->S6 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.26	4082	Fieldbus M->S7 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.30	4092	Fieldbus M->S8 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.34	4102	Fieldbus M->S9 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.38	4112	Fieldbus M->S10 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.42	4122	Fieldbus M->S11 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.46	4132	Fieldbus M->S12 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.50	4142	Fieldbus M->S13 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.54	4152	Fieldbus M->S14 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.58	4162	Fieldbus M->S15 sys		ENUM		Not assigned	0	10	ERW	FVS
21.3.62	4172	Fieldbus M->S16 sys		ENUM		Not assigned	0	10	ERW	FVS

Setting of the format of the datum received on the channel. When the src parameter is programmed, the format is automatically programmed on the relative sys. If the src parameter is reset to null, the format does not change. The value of the format can be selected from the following list, according to the parameter selected as the source:

- 0** Not assigned
- 1** Count 16
- 2** Count 32
- 3** Fill 16
- 4** Fill 32
- 5** Mdplc 16
- 6** Mdplc 32
- 7** EU
- 8** Eu float
- 9** Par 16
- 10** Par 32

If set to **0** the channel is not assigned.

If set to **1** the datum is assigned a 16-bit count.

If set to **2** the datum is assigned a 32-bit count.

If set to **3** 16 bits on the channel are reserved for the datum, not used.

If set to **4** 32 bits on the channel are reserved for the datum, not used.

If set to **5** the datum is assigned a 16-bit count used by MDPLC.

If set to **6** the datum is assigned a 32-bit count used by MDPLC.

If set to **7** the datum is assigned engineering units on a 16-bit integer.

If set to **8** the datum is assigned engineering units on a 32-bit integer.

If set to **9**, the datum is assigned a 16-bit integer engineering unit format not in real time (5-10ms)

If set to **10** the datum is assigned a 32-bit integer engineering unit format or float format if the associated parameter is a float-type parameter not in real time (5-10ms)

#### Note!

If the sys parameter is **not assigned**, none of the subsequent fieldbus channels are read, even if programmed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.3.3	4024	Fieldbus M->S1 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.7	4034	Fieldbus M->S2 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.11	4044	Fieldbus M->S3 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.15	4054	Fieldbus M->S4 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.19	4064	Fieldbus M->S5 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.23	4074	Fieldbus M->S6 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.27	4084	Fieldbus M->S7 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.31	4094	Fieldbus M->S8 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.35	4104	Fieldbus M->S9 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.39	4114	Fieldbus M->S10 mon		INT32	32BIT	0	0	0	ER	FVS
21.3.43	4124	Fieldbus M->S11mon		INT32	32BIT	0	0	0	ER	FVS

21.3.47	4134	Fieldbus M->S12 mon	INT32	32BIT	0	0	0	ER	FVS
21.3.51	4144	Fieldbus M->S13 mon	INT32	32BIT	0	0	0	ER	FVS
21.3.55	4154	Fieldbus M->S14 mon	INT32	32BIT	0	0	0	ER	FVS
21.3.59	4164	Fieldbus M->S15 mon	INT32	32BIT	0	0	0	ER	FVS
21.3.63	4174	Fieldbus M->S16 mon	INT32	32BIT	0	0	0	ER	FVS

The value received from the bus is displayed. This parameter must be associated with the src parameter to enable the M->S channel.

The user may modify the **M->S** and by **S->M** sys parameters. The consistency of the sys with the parameter assigned to the channel is checked.

**A Fieldbus M->S X Mon parameter can only be assigned to a single “src”. If assigned to more than one src, an error signal is generated during fieldbus initialization.**

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.3.4	4026	Fieldbus M->S1 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.8	4036	Fieldbus M->S2 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.12	4046	Fieldbus M->S3 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.16	4056	Fieldbus M->S4 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.20	4066	Fieldbus M->S5 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.24	4076	Fieldbus M->S6 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.28	4086	Fieldbus M->S7 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.32	4096	Fieldbus M->S8 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.36	4106	Fieldbus M->S9 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.40	4116	Fieldbus M->S10 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.44	4126	Fieldbus M->S11 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.48	4136	Fieldbus M->S12 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.52	4146	Fieldbus M->S13 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.56	4156	Fieldbus M->S14 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.60	4166	Fieldbus M->S15 div		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.3.64	4176	Fieldbus M->S16 div		FLOAT		1.0	1.0	1000.0	ERW	FVS

The **Div M->Sx fieldbus** parameters can be used to increase the resolution of the datum sent on the bus to the drive in the corresponding channel in EU and EU\_float exchange mode. The parameter value is used by the drive as the divider of the incoming datum, so that a number with decimal digits can be transferred.

#### Nota!

You must check the size in bits of the datum that is sent to make sure that the maximum value in bits fits in a 16-bit integer. For example, if specifying the divider as “Fieldbus M->Sn div” = 1000, the maximum value that can be used for the exchanged datum is 32.768 (32768/1000).

Example : Div M->Sx fieldbus = 10, M->S1 fieldbus par = Ramp ref src 1, Sys M->S1 fieldbus = Eu. If the PLC sends the decimal value 1000 on the first word the value of ramp ref 1 on the drive is  $1000/10 = 100$ .

## 21.4 - COMMUNICATION/FIELDBUS S2M

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.4.1	4180	Fieldbus S->M1 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.5	4190	Fieldbus S->M2 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.9	4200	Fieldbus S->M3 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.13	4210	Fieldbus S->M4 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.17	4220	Fieldbus S->M5 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.21	4230	Fieldbus S->M6 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.25	4240	Fieldbus S->M7 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.29	4250	Fieldbus S->M8 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.33	4260	Fieldbus S->M9 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.37	4270	Fieldbus S->M10 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.41	4280	Fieldbus S->M11 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.45	4290	Fieldbus S->M12 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.49	4300	Fieldbus S->M13 ipa		FBS2MIPA		0	0	20000	ERW	FVS
21.4.53	4310	Fieldbus S->M14 ipa		FBS2MIPA		0	0	20000	ERW	FVS

<b>21.4.57</b>	<b>4320</b>	<b>Fieldbus S-&gt;M15 ipa</b>	FBS2MIPA	0	0	20000	ERW	FVS
<b>21.4.61</b>	<b>4330</b>	<b>Fieldbus S-&gt;M16 ipa</b>	FBS2MIPA	0	0	20000	ERW	FVS

Setting of the parameter to associate with the bus channel. The default setting is 0, which means channel not active.

When setting a parameter, the format is also automatically set in the sys parameter

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>21.4.2</b>	<b>4182</b>	<b>Fieldbus S-&gt;M1 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.6</b>	<b>4192</b>	<b>Fieldbus S-&gt;M2 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.10</b>	<b>4202</b>	<b>Fieldbus S-&gt;M3 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.14</b>	<b>4212</b>	<b>Fieldbus S-&gt;M4 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.18</b>	<b>4222</b>	<b>Fieldbus S-&gt;M5 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.22</b>	<b>4232</b>	<b>Fieldbus S-&gt;M6 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.26</b>	<b>4242</b>	<b>Fieldbus S-&gt;M7 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.30</b>	<b>4252</b>	<b>Fieldbus S-&gt;M8 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.34</b>	<b>4262</b>	<b>Fieldbus S-&gt;M9 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.38</b>	<b>4272</b>	<b>Fieldbus S-&gt;M10 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.42</b>	<b>4282</b>	<b>Fieldbus S-&gt;M11 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.46</b>	<b>4292</b>	<b>Fieldbus S-&gt;M12 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.50</b>	<b>4302</b>	<b>Fieldbus S-&gt;M13 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.54</b>	<b>4312</b>	<b>Fieldbus S-&gt;M14 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.58</b>	<b>4322</b>	<b>Fieldbus S-&gt;M15 sys</b>		ENUM		Not assigned	0	10	ERW	FVS
<b>21.4.62</b>	<b>4332</b>	<b>Fieldbus S-&gt;M16 sys</b>		ENUM		Not assigned	0	10	ERW	FVS

Setting of the format of the datum sent to the channel. When the src parameter is programmed, the format is programmed as **Eu** or **MDPLC 16**. If the src parameter is reset to null, the datum format does not change. The value of the format can be selected from the following list:

- 0** Not assigned
- 1** Count 16
- 2** Count 32
- 3** Fill 16
- 4** Fill 32
- 5** Mdplc 16
- 6** Mdplc 32
- 7** EU
- 8** Eu float
- 9** Par 16
- 10** Par 32

If set to **0** the channel is not assigned.

If set to **1** the datum is assigned a 16-bit count.

If set to **2** the datum is assigned a 32-bit count.

If set to **3** 16 bits on the channel are reserved for the datum, not used.

If set to **4** 32 bits on the channel are reserved for the datum, not used.

If set to **5** the datum is assigned a 16-bit count used by MDPLC.

If set to **6** the datum is assigned a 32-bit count used by MDPLC.

If set to **7** the datum is assigned engineering units on a 16-bit integer.

If set to **8** the datum is assigned engineering units on a 32-bit integer.

If set to **9**, the datum is assigned a 16-bit integer engineering unit format not in real time (5-10ms)

If set to **10** the datum is assigned a 32-bit integer engineering unit format or float format if the associated parameter is a float-type parameter not in real time (5-10ms)

#### Note!

If the sys parameter is **not assigned**, none of the subsequent channels are transferred to the fieldbus, even if programmed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
<b>21.4.3</b>	<b>4184</b>	<b>Dig Fieldbus S-&gt;M1</b>		INT32	32BIT	0	0	0	ERW	FVS
<b>21.4.7</b>	<b>4194</b>	<b>Dig Fieldbus S-&gt;M2</b>		INT32	32BIT	0	0	0	ERW	FVS
<b>21.4.11</b>	<b>4204</b>	<b>Dig Fieldbus S-&gt;M3</b>		INT32	32BIT	0	0	0	ERW	FVS
<b>21.4.15</b>	<b>4214</b>	<b>Dig Fieldbus S-&gt;M4</b>		INT32	32BIT	0	0	0	ERW	FVS
<b>21.4.19</b>	<b>4224</b>	<b>Dig Fieldbus S-&gt;M5</b>		INT32	32BIT	0	0	0	ERW	FVS
<b>21.4.23</b>	<b>4234</b>	<b>Dig Fieldbus S-&gt;M6</b>		INT32	32BIT	0	0	0	ERW	FVS

21.4.27	4244	Dig Fieldbus S->M7	INT32	32BIT	0	0	0	ERW	FVS
21.4.31	4254	Dig Fieldbus S->M8	INT32	32BIT	0	0	0	ERW	FVS
21.4.35	4264	Dig Fieldbus S->M9	INT32	32BIT	0	0	0	ERW	FVS
21.4.39	4274	Dig Fieldbus S->M10	INT32	32BIT	0	0	0	ERW	FVS
21.4.43	4284	Dig Fieldbus S->M11	INT32	32BIT	0	0	0	ERW	FVS
21.4.47	4294	Dig Fieldbus S->M12	INT32	32BIT	0	0	0	ERW	FVS
21.4.51	4304	Dig Fieldbus S->M13	INT32	32BIT	0	0	0	ERW	FVS
21.4.55	4314	Dig Fieldbus S->M14	INT32	32BIT	0	0	0	ERW	FVS
21.4.59	4324	Dig Fieldbus S->M15	INT32	32BIT	0	0	0	ERW	FVS
21.4.63	4334	Dig Fieldbus S->M16	INT32	32BIT	0	0	0	ERW	FVS

If associated with the relative src, the value of this parameter is sent to the bus.

The user may modify the M->S and by S->M sys parameters. The consistency of the sys with the parameter assigned to the channel is checked.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.4.4	4186	Fieldbus S->M1 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.8	4196	Fieldbus S->M2 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.12	4206	Fieldbus S->M3 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.16	4216	Fieldbus S->M4 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.20	4226	Fieldbus S->M5 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.24	4236	Fieldbus S->M6 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.28	4246	Fieldbus S->M7 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.32	4256	Fieldbus S->M8 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.36	4266	Fieldbus S->M9 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.40	4276	Fieldbus S->M10 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.44	4286	Fieldbus S->M11 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.48	4296	Fieldbus S->M12 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.52	4306	Fieldbus S->M13 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.56	4316	Fieldbus S->M14 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.60	4326	Fieldbus S->M15 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS
21.4.64	4336	Fieldbus S->M16 mul		FLOAT		1.0	1.0	1000.0	ERW	FVS

The “Fieldbus S->Mx mul” parameters are multipliers that the drive applies to the datum before sending it to the bus. It is therefore possible to increase the resolution of some values read in EU and EU\_float mode, also using decimal digits.

#### Note!

The drive does not check that the multiplied parameter expressed in bits fits in a 16-bit integer. You must make sure that the multiplier is compatible with the maximum value of the exchanged parameter and that it does not exceed the maximum size of 32768.

Example: Fieldbus S->Mx mul = 10, S->M1 fieldbus par = Motor speed, Sys S->M1 fieldbus = Eu.

If the motor is running at 100 rpm, the PLC reads the value 100 \* 10 = 1000 on the first word that is exchanged.


## 21.5 - COMMUNICATION/WORD COMP

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.5.1	4400	Word bit0 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.2	4402	Word bit1 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.3	4404	Word bit2 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.4	4406	Word bit3 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.5	4408	Word bit4 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.6	4410	Word bit5 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.7	4412	Word bit6 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.8	4414	Word bit7 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.9	4416	Word bit8 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.10	4418	Word bit9 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.11	4420	Word bit10 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.12	4422	Word bit11 src		LINK	16BIT	6000	0	16384	ERW	FVS

21.5.13	4424	Word bit12 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.14	4426	Word bit13 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.15	4428	Word bit14 src		LINK	16BIT	6000	0	16384	ERW	FVS
21.5.16	4430	Word bit15 src		LINK	16BIT	6000	0	16384	ERW	FVS

Selection of the origin (source) of the signal to be used for coding in **Word comp**. This function allows the user to compose a single word composed of 16 signals, each of which can be selected from among those listed in the “**L\_DIGSEL1**” selection list”.

The values of the sectioned sizes are converted into a single word.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.5.17	4432	Word comp mon		UINT32	16BIT	0	0	0	ER	FVS

The hexadecimal value of the **Word comp** output is displayed.


## 21.6 - COMMUNICATION/WORD COMP

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.6.1	4450	Dig word decomp		UINT32	16BIT	0	0	0	ERW	FVS

Setting of the digital input decoded by the “**Word decomp**” block.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.6.2	4452	Word decomp src		LINK	16BIT	4450	0	16384	ERW	FVS

Selection of the origin (source) of the word to be decoded by the “**Word decomp**” block. Each bit that is part of the word to be decoded is associated with the output channel of the “**Word decomp**” block. The variables that can be used for this function can be selected from among those listed in the “**L\_WDECOMP**” selection list”



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
21.6.3	4454	Bit0 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.4	4456	Bit1 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.5	4458	Bit2 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.6	4460	Bit3 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.7	4462	Bit4 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.8	4464	Bit5 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.9	4466	Bit6 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.10	4468	Bit7 decomp mon		BIT	16BIT	0	0	1	ER	FVS
21.6.11	4470	Bit8 decomp mon		BIT	16BIT	0	0	1	ER	FVS

<b>21.6.12</b>	<b>4472</b>	<b>Bit9 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS
<b>21.6.13</b>	<b>4474</b>	<b>Bit10 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS
<b>21.6.14</b>	<b>4476</b>	<b>Bit11 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS
<b>21.6.15</b>	<b>4478</b>	<b>Bit12 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS
<b>21.6.16</b>	<b>4480</b>	<b>Bit13 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS
<b>21.6.17</b>	<b>4482</b>	<b>Bit14 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS
<b>21.6.18</b>	<b>4484</b>	<b>Bit15 decomp mon</b>	BIT	16BIT	0	0	1	ER	FVS

The single bits that make up the selected word are displayed.

## 22 - ALARM CONFIG

In the ALARM CONFIG menu the type of effect any alarm signals have on the drive is determined:

- The alarm status is saved
- How must the drive react to the alarm signal?
- Auto restart
- Alarm reset

For some alarms, behaviour can be configured separately for each signal, while for the others the **Disable drive** is executed. Individual signals can also be sent to a programmable digital output.

<b>Activity</b>	<b>Ignore</b>	The alarm is not included in the list of alarms, it is not included in the alarm log, it is not signalled on the digital outputs, no drive commands are modified.
	<b>Warning</b>	The alarm is included in the list of alarms, it is included in the alarm log, it is signalled on the digital outputs, the First alarm information is updated, the Alarm enabled information is updated, no drive commands are modified.
	<b>Disable Drive</b>	The alarm is included in the list of alarms, it is included in the alarm log, it is signalled on the digital outputs, the First alarm information is updated, the Alarm enabled information is updated, a command is sent to stop and disable the motor, which stops due to inertia.
	<b>Stop</b>	The alarm is included in the list of alarms, it is included in the alarm log, it is signalled on the digital outputs, the First alarm information is updated, the Alarm enabled information is updated, a Stop command is sent. When the zero speed is reached the drive is disabled. If <b>Ramp</b> control mode is enabled, the drive moves to the zero speed with the set ramp time; when the <b>Speed delay 0</b> signal is activated the drive is disabled. If <b>Speed</b> control mode is enabled, the drive moves to the zero speed with the maximum current possible; when the <b>Speed delay 0</b> signal is activated the drive is disabled. If <b>Torque</b> control mode is enabled, the drive moves to the zero speed with the time set by the load; when the <b>Speed delay 0</b> signal is activated the drive is disabled.
	<b>Fast stop</b>	The alarm is included in the list of alarms, it is included in the alarm log, it is signalled on the digital outputs, the First alarm information is updated, the Alarm enabled information is updated, a Fast Stop command is sent. When the zero speed is reached the drive is disabled. If <b>Ramp</b> control mode is enabled, the drive moves to the zero speed with the set fast stop ramp time (deceleration time 3); when the <b>Speed delay 0</b> signal is activated the drive is disabled. If <b>Speed</b> control mode is enabled, the drive moves to the zero speed with the maximum current possible; when the <b>Speed delay 0</b> signal is activated the drive is disabled. If <b>Torque</b> control mode is enabled, the drive moves to the zero speed with the set load time; when the <b>Speed delay 0</b> signal is activated the drive is disabled.

n alarms with Activity = Ignore or Warning can be enabled at the same time.

If an alarm with Activity = Stop or Fast Stop is enabled and another alarm with an Activity other than Ignore or Warning is enabled, the drive stops and is disabled.

Not all alarms allow the controlled stopping of the drive. The following table shows the possibility of setting the Activities for the individual alarm signals.

Alarm	Ignore	Warning	Disable drive	Stop	Fast stop
ExtFlt	✓	✓	✓	✓	✓
Motor OT	✓	✓	✓	✓	✓
Overspeed	✓	✓	✓	✓	✓
SpdRefLoss	✓	✓	✓	✓	✓
SpdFbkLoss	✓	✓	✓	✓	✓
Drive ovld	✓	✓	✓	✓	✓
Motor ovld	✓	✓	✓	✓	✓

Bres ovlđ	✓	✓	✓	✓	✓
InAir	✓	✓	✓	✓	✓
PhLoss	✓	✓	✓	✓	✓
Opt Bus	✓	✓	✓	✓	✓

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.1	4500	<b>Fault reset src</b>		LINK	16BIT	6000	0	16384	RW	FVS

Selection of the origin (source) of the signal to be used for the command to reset the drive after an alarm. The terminal that can be used for this function can be selected from among those listed in the “**L\_DIGSEL2**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.2	4502	<b>ExtFlt src</b>		LINK	16BIT	6000	0	16384	RW	FVS

Selection of the origin (source) of the signal to be used as the input for the drive external fault alarm **ExtFlt**. The terminal that can be used for this function can be selected from among those listed in the “**L\_DIGSEL2**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.3	4504	<b>ExtFlt activity</b>		ENUM		Disable	0	4	RW	FVS

Setting of the behaviour of the drive in the event of an external fault alarm **ExtFlt**. This alarm indicates the intervention of a drive external protection.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.4	4506	<b>ExtFlt restart</b>		ENUM		Disable	0	1	RW	FVS

Enabling of automatic restart after the external fault alarm **ExtFlt**

- 0 Disable
- 1 Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.5	4508	<b>ExtFlt restart time</b>	ms	UINT16		1000	120	30000	RW	FVS

Setting of the time within which the **External Fault** alarm must be reset in order to perform automatic restart.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.6	4510	<b>ExtFlt holdoff</b>	ms	UINT16		0	0	10000	RW	FVS

Setting of the delay between the signalling of the external fault alarm **ExtFlt** and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before blocking is enabled. If the alarm is removed within the set time, the drive will not indicate any alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.7	4520	<b>MotorOT src</b>		LINK	16BIT	6000	0	16384	RW	FVS

Selection of the origin (source) of the signal to be used for the motor overtemperature alarm **MotorOT**. The terminal that can be used for this function can be selected from among those listed in the “**L\_DIGSEL2**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.8	4522	<b>MotorOT activity</b>		ENUM		Avvisa	0	4	RW	FVS

Setting of the behaviour of the drive in case of a motor overtemperature alarm **MotorOT**. This alarm indicates that the motor temperature is too high.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.9	4524	<b>MotorOT restart</b>		ENUM		Disable	0	1	RW	FVS
Enabling of automatic restart after the motor overtemperature alarm <b>MotorOT</b> .										
0 Disable 1 Enable										
22.10	4526	<b>MotorOT restart time</b>	ms	UINT16		1000	120	30000	RW	FVS
Setting of the time within which the <b>Motor Overtemperature</b> alarm must be reset in order to perform automatic restart.										
22.11	4528	<b>MotorOT holdoff</b>	ms	UINT16		1000	0	30000	RW	FVS
Setting of the delay between the signalling of the motor overtemperature alarm <b>MotorOT</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.										
22.12	4540	<b>Overspeed threshold</b>	rpm	INT16	INT32	CALCI	0	CALCI	RW	FVS
Setting of the threshold above which the overspeed alarm <b>Overspeed</b> is enabled.										
22.13	4542	<b>Overspeed activity</b>		ENUM		Disable	0	4	RW	FVS
Setting of the behaviour of the drive in case of a motor overspeed alarm <b>Overspeed</b> . This alarm indicates that the motor speed has exceeded the threshold set in the <b>Speed ref top lim</b> and <b>Speed ref bottom lim</b> parameters in the COM-MANDS menu.										
0 Ignore 1 Warning 2 Disable 3 Stop 4 Fast stop										
22.14	4544	<b>Overspeed holdoff</b>	ms	UINT16		0	0	5000	RW	FVS
Setting of the delay between the signalling of the motor overspeed alarm <b>Overspeed</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.										
22.15	4550	<b>SpdRefLoss threshold</b>	rpm	INT16		100	0	CALCI	RW	FVS
Setting of the threshold below which the speed reference loss alarm <b>SpdRefLoss</b> occurs .										
22.16	4552	<b>SpdRefLoss activity</b>		ENUM		Avvisa	0	4	RW	FVS
Setting of the behaviour of the drive in case of a speed reference loss alarm <b>SpdRefLoss</b> . This alarm indicates that the difference between the speed regulator reference and the actual motor speed is more than 100 rpm.										
This alarm must be disabled (= 0 Ignore) when parameter <b>2354</b> is set to a value other than zero.										
0 Ignore 1 Warning 2 Disable 3 Stop 4 Fast stop										
22.17	4554	<b>SpdRefLoss holdoff</b>	ms	UINT16		1000	0	10000	RW	FVS
The delay between the <b>Speed ref loss</b> alarm condition signal and activation of the actual alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**22.18 4560 SpdFbkLoss activity**

ENUM

Disable

0

4

RW

FVS

Drive behaviour in case of the Speed fbk loss alarm is displayed. This alarm indicates the loss of the encoder feedback signals. Each type of encoder generates the Speed fbk loss alarm differently (incremental signal error, absolute signal error, serial error).

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast stop

For absolute Endat encoders and absolute Hiperface encoders, after the alarm is generated, the encoder reset command must be sent to the encoder: during this procedure the application verifies whether the encoder is signalling an encoder alarm condition to the drive and the alarm is acquired from this.

The causes of the **Speed fbk loss** alarm and the information acquired from the encoder are shown in the **SpdFbkLoss code** parameter 2172.

**Note!**

See menu 15.13 for further information.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**22.19 4562 SpdFbkLoss holdoff**

ms

UINT16

200

0

10000

RW

FVS

Setting of the delay between the signalling of the speed feedback loss alarm condition **SpdFbkLoss** and the enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**22.20 4564 SpdFbkLoss threshold**

rpm

INT16

100

5

CALCI

RW

FV\_

If using incremental digital encoders in single-ended mode, this parameter sets the limit above which the drive executes the action set with parameter 4560 **SpdFbkLoss activity**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**22.21 4570 Drive ovid activity**

ENUM

Ignora

0

4

ERW

FVS

Setting of the behaviour of the drive in case of a drive overload alarm **Drive ovid**. This alarm indicates that the drive overload threshold has been reached.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**22.22 4572 Motor ovid activity**

ENUM

Avvisa

0

4

ERW

FVS

Setting of the behaviour of the drive in case of a motor overload alarm **Motor ovid**. This alarm indicates that the motor overload threshold has been reached.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
------	-----	-------------	----	------	--------	-----	-----	-----	-----	-----

**22.23 4574 Bres ovid activity**

ENUM

Disable

0

4

ERW

FVS

Setting of the behaviour of the drive in case of a braking resistor overload alarm **Bres ovid**. This alarm indicates that the braking resistor overload threshold has been reached.

- 0 Ignore
- 1 Warning
- 2 Disable
- 3 Stop
- 4 Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.24	4582	<b>HTsens restart</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of automatic restart after the drive heatsink overtemperature alarm <b>HTsens</b> .										
0 Disable 1 Enable										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.25	4584	<b>HTsens restart time</b>	ms	UINT16		20000	120	60000	ERW	FVS
Setting of the time within which the <b>HT sensor</b> alarm must be reset in order to perform automatic restart.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.26	4600	<b>InAir activity</b>		ENUM		Arresto	0	4	ERW	FVS
Setting of the behaviour of the drive in case of an intake air overtemperature alarm <b>InAir</b> . This alarm indicates that the temperature of the intake cooling air is too high.										
0 Ignore 1 Warning 2 Disable 3 Stop 4 Fast stop										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.27	4602	<b>InAir restart</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of automatic restart after the intake air overtemperature alarm <b>InAir</b> .										
0 Disable 1 Enable										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.28	4604	<b>InAir restart time</b>	ms	UINT16		1000	120	30000	ERW	FVS
Setting of the time within which the <b>Intakeair OT</b> alarm must be reset in order to perform automatic restart.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.29	4606	<b>InAir holdoff</b>	ms	UINT16		10000	0	30000	ERW	FVS
Setting of the delay between the signalling of the intake air overtemperature alarm <b>InAir</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.30	4610	<b>Desat restart</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of automatic restart after the desaturation alarm <b>Desat</b> . This alarm indicates a short circuit between the motor phases or on the power bridge.										
0 Disable 1 Enable										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.31	4612	<b>Desat restart time</b>	ms	UINT16		2000	1000	10000	ERW	FVS
Setting of the time within which the <b>Desaturation</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.32	4620	<b>IOverC restart</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of automatic restart after the drive <b>Overcurrent</b> alarm. This alarm indicates an overcurrent (or short circuit between phases or towards the ground).										
0 Disable 1 Enable										
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.33	4622	<b>IOverC restart time</b>	ms	UINT16		2000	1000	10000	ERW	FVS

Setting of the time within which the **Overcurrent** alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.34	4630	<b>OverV restart</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of automatic restart after the <b>Oversvoltage</b> alarm. This alarm indicates an oversvoltage on the intermediate circuit (DC link)										
0 Disable 1 Enable										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.35	4632	<b>OverV restart time</b>	ms	UINT16		2000	1000	10000	ERW	FVS
Setting of the time within which the <b>Oversvoltage</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.36	4640	<b>UnderV restart</b>		ENUM		Enable	0	1	ERW	FVS
Enabling of automatic restart after the <b>Undervoltage</b> alarm. This alarm indicates an undervoltage on the intermediate circuit (DC link).										
0 Disable 1 Enable										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.37	4642	<b>UnderV restart time</b>	ms	UINT16		1000	120	10000	ERW	FVS
Setting of the time within which the <b>Undervoltage</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 100 msec).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.38	4650	<b>UVRep attempts</b>		UINT16		5	0	1000	ERW	FVS
Setting of the maximum number of attempts at automatic restart after the <b>Undervoltage</b> alarm before a <b>Mult Undervoltage alarm</b> is generated. If this parameter is set to 1000 an infinite number of attempts are available.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.39	4652	<b>UVRep delay</b>	s	UINT16		240	0	300	ERW	FVS
Setting of the time within which, if no automatic restarts are executed after the <b>Undervoltage</b> alarm, the attempts counter is reset. In this way the number of attempts set in <b>Underv res attempts</b> are still available.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.40	4660	<b>PhLoss activity</b>		ENUM		Disable	0	4	ERW	FVS
Setting of the behaviour of the drive in case of a <b>no phase</b> alarm. This alarm indicates the absence of a drive power supply phase.										
0 Ignore 1 Warning 2 Disable 3 Stop 4 Fast stop										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.41	4662	<b>PhLoss restart</b>		ENUM		Disable	0	1	ERW	FVS
Enabling of automatic restart after the <b>no phase</b> alarm.										
0 Disable 1 Enable										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.42	4664	<b>PhLoss restart time</b>	ms	UINT16		1000	120	10000	ERW	FVS
Setting of the time within which the <b>Phase loss</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 100 msec).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.43	4668	PhLoss output test		ENUM		Powerup	0	2	ERWZ	FVS
Enabling of the output phase loss test.										
0 Disable										
1 Enable										
2 Powerup										
If set to 0 the test is disable										
If set to 1 the drive verifies the presence of all the output phases each time it receives the enable command.										
If set to 2 the drive only verifies the presence of all the output phases the first time the enable command is sent after powering										

**Note!**

The motor brake must be closed while running this test!

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.44	4670	Optionbus activity		ENUM		Disable	0	4	ERW	FVS
Setting of the behaviour of the drive in case of an "Opt Bus Fault" alarm.										
0 Ignore										
1 Warning										
2 Disable										
3 Stop										
4 Fast stop										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.45	4680	GroundFault thr	perc	FLOAT		10.0	0.0	150.0	ERWS	FVS
Setting of the threshold for the ground short circuit alarm <b>Ground Fault</b> .										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.46	4700	Alarm dig sel 1		ENUM		Nessun allarme	0	40	ERW	FVS
22.47	4702	Alarm dig sel 2		ENUM		Nessun allarme	0	40	ERW	FVS
22.48	4704	Alarm dig sel 3		ENUM		Nessun allarme	0	40	ERW	FVS
22.49	4706	Alarm dig sel 4		ENUM		Nessun allarme	0	40	ERW	FVS

Setting of the alarm signal to enable on a digital output. The digital output is selected using parameters **Alm dig out mon 1÷4**, which can be enabled in the **L\_DIGSEL1** selection list.

- 0 No alarm
- 1 Overvoltage
- 2 Undervoltage
- 3 Ground fault
- 4 Overcurrent
- 5 Desaturation
- 6 MultiUndervolt
- 7 MultiOvercurr
- 8 MultiDesat
- 9 Heatsink OT
- 10 HeatsinkS OTUT
- 11 Intakeair OT
- 12 Motor OT
- 13 Drive overload
- 14 Motor overload
- 15 Bres overload
- 16 Phaseloss
- 17 Opt Bus fault
- 18 Opt 1 IO fault
- 19 Opt 2 IO fault
- 20 Opt Enc fault
- 21 External fault
- 22 Speed fbk loss
- 23 Overspeed
- 24 Speed ref loss
- 25 Emg stop alarm
- 26 Power down

**27** Phaseloss out  
**28** Not Used2  
**29** Not Used3  
**30** Not Used4  
**31** Not Used5  
**32** Not Used6  
**33** Plc1 fault  
**34** Plc2 fault  
**35** Plc3 fault  
**36** Plc4 fault  
**37** Plc5 fault  
**38** Plc6 fault  
**39** Plc7 fault  
**40** Plc8 fault

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.50	4720	<b>Alm autoreset time</b>	s	FLOAT		0.0	0.0	60.0	ERW	FVS

Setting of the time interval that must pass before executing an automatic reset.

If no alarms are enabled the drive is set to restart.

If some alarms are still enabled the drive is set to execute a new attempt at automatic reset.

At each attempted reset a counter increases. If the limit set in the Alm autoreset number parameter is reached the drive is set to make no more attempts at reset and waits for a user reset.

The counter is set to zero when an automatic reset or user reset is performed and no alarms are enabled.


If the parameter is 0 the function is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
22.51	4722	<b>Alm autoreset number</b>		UINT16		20	0	100	ERW	FVS

Setting of the maximum number of attempted automatic resets.

## 23 - ALARM LOG

This is the menu in which the log of previous alarms is saved, with the time the alarm occurred (in relation to the **Time drive power** on parameter). The alarms are displayed starting from the most recent (No. 1) up to the furthest back in time (No. 30). Up to 30 alarm signals can be displayed. The sub-code is used by service technicians to identify the specific type of alarm. Press the **▲** and **▼** keys to scroll the screen pages of the alarm log. The alarm log cannot be deleted.



## PARAMETERS ON SELECTION LISTS, BUT NOT DISPLAYED ON KEYPAD

This menu displays all the parameters that do not refer to one specific menu, but which are visible on the drive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>262</b>	<b>Motor speednofilter</b>	rpm	INT16	16BIT	0	0	0	ER	FVS
This parameter indicates the unfiltered motor speed.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>362</b>	<b>Drive overload trip</b>	BIT	16BIT	0	0	0	1	ER	FVS
This signal indicates that the drive is in the overload alarm condition.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>366</b>	<b>Drive overload 80%</b>	BIT	16BIT	0	0	0	1	ER	FVS
This signal indicates that the drive has reached 80% of the thermal image accumulator (drive overload).										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>626</b>	<b>Ramp ref out mon</b>	rpm	INT16	16BIT	0	0	0	ER	FVS
This parameter displays the reference value output of the ramp remference function block.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>760</b>	<b>Ramp out mon</b>	rpm	INT16	16BIT	0	0	0	ER	FVS
This parameter displays the reference value output of the ramp function block.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>764</b>	<b>Ramp acc state</b>	BIT	16BIT	0	0	0	1	ER	FVS
This signal indicates whether the acceleration ramp is active.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>766</b>	<b>Ramp dec state</b>	BIT	16BIT	0	0	0	1	ER	FVS
This signal indicates whether the deceleration ramp is active.										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>934</b>	<b>Ref is 0</b>	BIT	16BIT	0	0	0	1	ER	FVS
This signal is active when the reference is below the limit set in parameter <b>930 Reference 0 threshold</b> .										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>936</b>	<b>Ref is 0 delay</b>	BIT	16BIT	0	0	0	1	ER	FVS
This parameter is active when the reference is below the threshold set in parameter <b>930 Reference 0 threshold</b> . The signal is enabled after the delay set with parameter <b>932 Reference delay 0</b> .										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>944</b>	<b>Speed is 0</b>	BIT	16BIT	0	0	0	1	ER	FVS
This parameter is active when the speed is below the threshold set in parameter <b>940 Speed 0 threshold</b> .										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>946</b>	<b>Speed is 0 delay</b>	BIT	16BIT	0	0	0	1	ER	FVS
This signal is active when the reference is below the threshold set in parameter <b>940 Speed 0 threshold</b> . The signal is activated after the delay set in parameter <b>942 Speed 0 delay</b> .										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>1060</b>	<b>Sequencer status</b>	UINT16	16BIT	0	0	0	0	ER	FVS
This signal indicates the state of the “machine states” that controls drive operation.										

STS_INIT	0
STS_MAGN	1
STS_STOP	2
STS_START	3
STS_FS_STOP	4
STS_FS_START	5
STS_QSTOP	6
STS_FS_MAGN	7
STS_W_QSTOP	8
STS_READY	9
STS_MAGN_START	10
STS_ALM_DISABLED	11
STS_ALM_END_ACTION	12
STS_ALM_STOP	13
STS_ALM_FSTOP	14
STS_ALM_R_TO_NORMAL	15
STS_READY_START	16
STS_READY_FSTOP	17
STS_ALM_NO_RESTART	18
STS_FS_MAGN_START	19

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>1062</b>	<b>Drive OK</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is active when the drive is in the “OK” condition and no alarms are present.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>1064</b>	<b>Drive ready</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is active when the drive reference is in the “Ready” to run condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>1110</b>	<b>Digital input E mon</b>		BIT	16BIT	0	0	1	ER	FVS

These signals represent the state of the corresponding digital input.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>1210</b>	<b>Digital input 1X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1212</b>	<b>Digital input 2X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1214</b>	<b>Digital input 3X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1216</b>	<b>Digital input 4X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1218</b>	<b>Digital input 5X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1220</b>	<b>Digital input 6X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1222</b>	<b>Digital input 7X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1224</b>	<b>Digital input 8X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1226</b>	<b>Digital input 9X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1228</b>	<b>Digital input 10X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1230</b>	<b>Digital input 11X mon</b>		BIT	16BIT	0	0	1	ER	FVS
-	<b>1232</b>	<b>Digital input 12X mon</b>		BIT	16BIT	0	0	1	ER	FVS

These signals represent the state of the corresponding digital input on the expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>2388</b>	<b>Torque refnofilter</b>	perc	FLOAT	16BIT	0.0	0.0	0.0	ER	FVS

The torque control reference current without filter is displayed (in sensorless vector and field-oriented vector mode).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>3214</b>	<b>Motor overload trip</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is active when the drive is in the motor overload alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>3262</b>	<b>Bres overload trip</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is active when the drive is in the braking resistor overload alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4372</b>	<b>DS402 status word</b>		UINT16	16BIT	0	0	65535	ER	FVS

This parameter displays the status word according to the DS402 profile. For more information reference should be made to the fieldbus manual.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4708</b>	<b>Alm dig out mon 1</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is activated when the alarm configured in parameter **4700 alarm dig sel 1** is active.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4710</b>	<b>Alm dig out mon 2</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is activated when the alarm configured in parameter **4702 alarm dig sel 2** is active.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4712</b>	<b>Alm dig out mon 3</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is activated when the alarm configured in parameter **4704 alarm dig sel 3** is active.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4714</b>	<b>Alm dig out mon 4</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is activated when the alarm configured in parameter **4706 alarm dig sel 4** is active.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4770</b>	<b>First alarm</b>		UINT32	16BIT	0	0	0	ERW	FVS

This parameter displays the first alarm to be activated..

- 0** No alarm
- 1** Overvoltage
- 2** Undervoltage
- 3** Ground fault
- 4** Overcurrent
- 5** Desaturation
- 6** MultiUndervolt
- 7** MultiOvercurr
- 8** MultiDesat
- 9** Heatsink OT
- 10** HeatsinkS OTUT
- 11** Intakeair OT
- 12** Motor OT
- 13** Drive overload
- 14** Motor overload
- 15** Bres overload
- 16** Phaseloss
- 17** Opt Bus fault
- 18** Opt 1 IO fault
- 19** Opt 2 IO fault
- 20** Opt Enc fault
- 21** External fault
- 22** Speed fbk loss
- 23** Overspeed
- 24** Speed ref loss
- 25** Emg stop alarm
- 26** Power down
- 27** Phaseloss out
- 28** Not Used2
- 29** Not Used3
- 30** Not Used4

**31** Not Used5  
**32** Not Used6  
**33** Plc1 fault  
**34** Plc2 fault  
**35** Plc3 fault  
**36** Plc4 fault  
**37** Plc5 fault  
**38** Plc6 fault  
**39** Plc7 fault  
**40** Plc8 fault

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>4780</b>	<b>Alarm PLC</b>			UINT16	0	0	0	ER	FVS

This parameter displays the state of the alarms generated by the application written with the internal PLC.

Bit	Description
0	1 = PLC 1 fault active
1	1 = PLC 2 fault active
2	1 = PLC 3 fault active
3	1 = PLC 4 fault active
4	1 = PLC 5 fault active
5	1 = PLC 6 fault active
6	1 = PLC 7 fault active
7	1 = PLC 8 fault active

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>6000</b>	<b>Null</b>			UINT32 32BIT	0	0	0	ER	FVS

This signal forces the variable to the zero level (always disabled).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>6002</b>	<b>One</b>			UINT32 32BIT	1	1	1	ER	FVS

This signal forces the variable to level one (always active)..

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Mod
-	<b>6006</b>	<b>Current limit state</b>		BIT	16BIT	0	0	1	ER	FVS

This signal is activated when the drive is in the current limit condition.

## C - SELECTION LISTS

PAR	Description	Menu	PAR	Description	Menu	PAR	Description	Menu	
	<b>L_ANOUT</b>		760	Ramp out mon	0.0 (*)	1214	Digital input 3X mon	0.0 (*)	
6000	Null	0.0 (*)	664	Speed setpoint	1.5	1216	Digital input 4X mon	0.0 (*)	
626	Ramp ref out mon	0.0 (*)	260	Motor speed	1.6	1218	Digital input 5X mon	0.0 (*)	
760	Ramp out mon	0.0 (*)	2150	Encoder speed	0.0 (*)	1220	Digital input 6X mon	0.0 (*)	
664	Speed setpoint	1.5	250	Output current	1.1	1222	Digital input 7X mon	0.0 (*)	
260	Motor speed	1.6	252	Output voltage	1.2	1224	Digital input 8X mon	0.0 (*)	
262	Motor speednofilter	0.0 (*)	254	Output frequency	1.3	1226	Digital input 9X mon	0.0 (*)	
2150	Encoder speed	15.11	280	Torque current ref	1.9	1228	Digital input10X mon	0.0 (*)	
250	Output current	1.1	282	Magnet current ref	1.10	1230	Digital input11X mon	0.0 (*)	
252	Output voltage	1.2	284	Torque current	1.11	1232	Digital input12X mon	0.0 (*)	
254	Output frequency	1.3	286	Magnet current	1.12	1062	Drive OK	0.0 (*)	
280	Torque current ref	1.9	2386	Torque ref	18.10	1064	Drive ready	0.0 (*)	
282	Magnet current ref	1.10	2388	Torque refnofilter	0.0 (*)	934	Ref is 0	0.0 (*)	
284	Torque current	1.11	270	DC link voltage	1.7	936	Ref is 0 delay	0.0 (*)	
286	Magnet current	1.12	1600	Analog input 1X mon	12.1	944	Speed is 0	0.0 (*)	
2360	Torque climPos Inuse	18.5	1650	Analog input 2X mon	12.12	946	Speed is 0 delay	0.0 (*)	
2362	Torque climNeg Inuse	18.6	368	Drive overload accum	1.14	1066	Enable state mon	1.16	
2386	Torque ref	18.10	3212	Motor overload accum	1.13	1068	Start state mon	1.17	
2388	Torque refnofilter	0.0 (*)	3260	Bres overload accum	1.15	1070	FastStop state mon	1.18	
270	DC link voltage	1.7	4024	Fieldbus M->S1 mon	21.3.3	1024	Enable cmd mon	9.9	
3104	Inertia comp mon	20.1.3	4034	Fieldbus M->S2 mon	21.3.7	1026	Start cmd mon	9.10	
1600	Analog input 1X mon	12.1	4044	Fieldbus M->S3 mon	21.3.11	4708	Alm dig out mon 1	0.0 (*)	
1650	Analog input 2X mon	12.12	4054	Fieldbus M->S4 mon	21.3.15	4710	Alm dig out mon 2	0.0 (*)	
368	Drive overload accum	1.14	4064	Fieldbus M->S5 mon	21.3.19	4712	Alm dig out mon 3	0.0 (*)	
3212	Motor overload accum	1.13	4074	Fieldbus M->S6 mon	21.3.23	4714	Alm dig out mon 4	0.0 (*)	
3260	Bres overload accum	1.15	4084	Fieldbus M->S7 mon	21.3.27	362	Drive overload trip	0.0 (*)	
2232	Spd reg P gain Inuse	16.16	4094	Fieldbus M->S8 mon	21.3.31	3214	Motor overload trip	0.0 (*)	
2234	Spd reg I gain Inuse	16.17	4104	Fieldbus M->S9 mon	21.3.35	3262	Bres overload trip	0.0 (*)	
4024	Fieldbus M->S1 mon	21.3.3	4114	Fieldbus M->S10 mon	21.3.39	366	Drive overload 80%	0.0 (*)	
4034	Fieldbus M->S2 mon	21.3.7	4124	Fieldbus M->S11 mon	21.3.43	4454	Bit0 decomp mon	21.6.3	
4044	Fieldbus M->S3 mon	21.3.11	4134	Fieldbus M->S12 mon	21.3.47	4456	Bit1 decomp mon	21.6.4	
4054	Fieldbus M->S4 mon	21.3.15	4144	Fieldbus M->S13 mon	21.3.51	4458	Bit2 decomp mon	21.6.5	
4064	Fieldbus M->S5 mon	21.3.19	4154	Fieldbus M->S14 mon	21.3.55	4460	Bit3 decomp mon	21.6.6	
4074	Fieldbus M->S6 mon	21.3.23	4164	Fieldbus M->S15 mon	21.3.59	4462	Bit4 decomp mon	21.6.7	
4084	Fieldbus M->S7 mon	21.3.27	4174	Fieldbus M->S16 mon	21.3.63	4464	Bit5 decomp mon	21.6.8	
4094	Fieldbus M->S8 mon	21.3.31	3700	Lift enable	20.8.1	4466	Bit6 decomp mon	21.6.9	
4104	Fieldbus M->S9 mon	21.3.35	3702	Run cont mon	20.8.2	4468	Bit7 decomp mon	21.6.10	
4114	Fieldbus M->S10 mon	21.3.39	3704	Up cont mon	20.8.3	4470	Bit8 decomp mon	21.6.11	
4124	Fieldbus M->S11 mon	21.3.43	3706	Down cont mon	20.8.4	4472	Bit9 decomp mon	21.6.12	
4134	Fieldbus M->S12 mon	21.3.47	3708	Brake cont mon	20.8.5	4474	Bit10 decomp mon	21.6.13	
4144	Fieldbus M->S13 mon	21.3.51	3710	Lift dc brake	20.8.6	4476	Bit11 decomp mon	21.6.14	
4154	Fieldbus M->S14 mon	21.3.55	3712	Brake 2 mon	20.8.7	4478	Bit12 decomp mon	21.6.15	
4164	Fieldbus M->S15 mon	21.3.59	3714	Door open mon	20.8.8	4480	Bit13 decomp mon	21.6.16	
4174	Fieldbus M->S16 mon	21.3.63	3716	Lift start	20.8.9	4482	Bit14 decomp mon	21.6.17	
3700	Lift enable	20.8.1	3718	Pad 10	20.8.10	4484	Bit15 decomp mon	21.6.18	
3702	Run cont mon	20.8.2	3720	Lift status word	20.8.11	3700	Lift enable	20.8.1	
3704	Up cont mon	20.8.3	3722	Pad 12	20.8.12	3702	Run cont mon	20.8.2	
3706	Down cont mon	20.8.4	3724	Pad 13	20.8.13	3704	Up cont mon	20.8.3	
3708	Brake cont mon	20.8.5	3726	Ramp down limit	20.8.14	3706	Down cont mon	20.8.4	
3710	Lift dc brake	20.8.6	3728	Input variable	20.8.15	3708	Brake cont mon	20.8.5	
3712	Brake 2 mon	20.8.7	3730	Lift wdec input	20.8.16	3710	Lift dc brake	20.8.6	
3714	Door open mon	20.8.8	<sup>(1)</sup> the XXXX parameter changes according to the src parameter used:				3712	Brake 2 mon	20.8.7
3716	Lift start	20.8.9	3660 Compare input 1 src				3714	Door open mon	20.8.8
3718	Pad 10	20.8.10	<sup>(1)</sup> = 3650 Dig compare input 1				3716	Lift start	20.8.9
3720	Lift status word	20.8.11	3662 Compare input 2 src				3718	Pad 10	20.8.10
3722	Pad 12	20.8.12	<sup>(1)</sup> = 3652 Dig compare input 2				3720	Lift status word	20.8.11
3724	Pad 13	20.8.13	3666 Compare input 1 src				3722	Pad 12	20.8.12
3726	Ramp down limit	20.8.14	<sup>(1)</sup> = 3654 Dig compare input 1				3724	Pad 13	20.8.13
3728	Input variable	20.8.15	3668 Compare input 2 src				3726	Ramp down limit	20.8.14
3730	Lift wdec input	20.8.16	<sup>(1)</sup> = 3656 Dig compare input 2				3728	Input variable	20.8.15
5008	Test gen out	24.1.5	3672 Compare input 1 src				3730	Lift wdec input	20.8.16
			<sup>(1)</sup> = 3658 Dig compare input 1				6006	Current limit state	0.0 (*)
			3680 Compare input 2 src				764	Ramp acc state	0.0 (*)
			<sup>(1)</sup> = 3660 Dig compare input 2				766	Ramp dec state	0.0 (*)
			3684 Compare input 1 src				4780	Alarm PLC	0.0 (*)
			<sup>(1)</sup> = 3662 Dig compare input 1				3676	Compare output	20.7.8

PAR	Description	Menu	PAR	Description	Menu	PAR	Description	Menu
<b>L_DIGSEL2</b>								
6000	Null	0.0 (*)	944	Speed is 0	0.0 (*)	664	Speed setpoint	1.5
6002	One	0.0 (*)	946	Speed is 0 delay	0.0 (*)	260	Motor speed	1.6
1110	Digital input E mon	0.0 (*)	1066	Enable state mon	1.16	262	Motor speed nofilter	0.0 (*)
1210	Digital input 1X mon	0.0 (*)	1068	Start state mon	1.17	2150	Encoder speed	15.11
1212	Digital input 2X mon	0.0 (*)	1070	FastStop state mon	1.18	250	Output current	1.1
1214	Digital input 3X mon	0.0 (*)	1024	Enable cmd mon	9.9	252	Output voltage	1.2
1216	Digital input 4X mon	0.0 (*)	1026	Start cmd mon	9.10	254	Output frequency	1.3
1218	Digital input 5X mon	0.0 (*)	1028	FastStop cmd mon	9.11	280	Torque current ref	1.9
1220	Digital input 6X mon	0.0 (*)	4708	Alm dig out mon 1	0.0 (*)	282	Magnet current ref	1.10
1222	Digital input 7X mon	0.0 (*)	4710	Alm dig out mon 2	0.0 (*)	284	Torque current	1.11
1224	Digital input 8X mon	0.0 (*)	4712	Alm dig out mon 3	0.0 (*)	286	Magnet current	1.12
1226	Digital input 9X mon	0.0 (*)	4714	Alm dig out mon 4	0.0 (*)	2360	Torque climPos Inuse	18.5
1228	Digital input10X mon	0.0 (*)	362	Drive overload trip	0.0 (*)	2362	Torque climNeg Inuse	18.6
1230	Digital input11X mon	0.0 (*)	3214	Motor overload trip	0.0 (*)	2386	Torque ref	18.10
1232	Digital input12X mon	0.0 (*)	3262	Bres overload trip	0.0 (*)	2388	Torque refnofilter	0.0 (*)
4454	Bit0 decomp mon	21.6.3	366	Drive overload 80%	0.0 (*)	270	DC link voltage	1.7
4456	Bit1 decomp mon	21.6.4	4454	Bit0 decomp mon	21.6.3	2162	Encoder position	15.12
4458	Bit2 decomp mon	21.6.5	4456	Bit1 decomp mon	21.6.4	2154	Virtual position	24.3.2
4460	Bit3 decomp mon	21.6.6	4458	Bit2 decomp mon	21.6.5	2156	Revolutions	24.3.3
4462	Bit4 decomp mon	21.6.7	4460	Bit3 decomp mon	21.6.6	3104	Inertia comp mon	20.1.3
4464	Bit5 decomp mon	21.6.8	4462	Bit4 decomp mon	21.6.7	1600	Analog input 1X mon	12.1
4466	Bit6 decomp mon	21.6.9	4464	Bit5 decomp mon	21.6.8	1650	Analog input 2X mon	12.12
4468	Bit7 decomp mon	21.6.10	4466	Bit6 decomp mon	21.6.9	368	Drive overload accum	1.14
4470	Bit8 decomp mon	21.6.11	4468	Bit7 decomp mon	21.6.10	3212	Motor overload accum	1.13
4472	Bit9 decomp mon	21.6.12	4470	Bit8 decomp mon	21.6.11	3260	Bres overload accum	1.15
4474	Bit10 decomp mon	21.6.13	4472	Bit9 decomp mon	21.6.12	272	Heatsink temperature	1.8
4476	Bit11 decomp mon	21.6.14	4474	Bit10 decomp mon	21.6.13	1060	Sequencer status	0.0 (*)
4478	Bit12 decomp mon	21.6.15	4476	Bit11 decomp mon	21.6.14	4432	Word comp mon	21.5.17
4480	Bit13 decomp mon	21.6.16	4478	Bit12 decomp mon	21.6.15	4372	DS402 status word	0.0 (*)
4482	Bit14 decomp mon	21.6.17	4480	Bit13 decomp mon	21.6.16	4024	Fieldbus M->S1 mon	21.3.3
4484	Bit15 decomp mon	21.6.18	4482	Bit14 decomp mon	21.6.17	4034	Fieldbus M->S2 mon	21.3.7
3700	Lift enable	20.8.1	4484	Bit15 decomp mon	21.6.18	4044	Fieldbus M->S3 mon	21.3.11
3702	Run cont mon	20.8.2	3700	Lift enable	20.8.1	4054	Fieldbus M->S4 mon	21.3.15
3704	Up cont mon	20.8.3	3702	Run cont mon	20.8.2	4064	Fieldbus M->S5 mon	21.3.19
3706	Down cont mon	20.8.4	3704	Up cont mon	20.8.3	4074	Fieldbus M->S6 mon	21.3.23
3708	Brake cont mon	20.8.5	3706	Down cont mon	20.8.4	4084	Fieldbus M->S7 mon	21.3.27
3710	Lift dc brake	20.8.6	3708	Brake cont mon	20.8.5	4094	Fieldbus M->S8 mon	21.3.31
3712	Brake 2 mon	20.8.7	3710	Lift dc brake	20.8.6	4104	Fieldbus M->S9 mon	21.3.35
3714	Door open mon	20.8.8	3712	Brake 2 mon	20.8.7	4114	Fieldbus M->S10 mon	21.3.39
3716	Lift start	20.8.9	3714	Door open mon	20.8.8	4124	Fieldbus M->S11 mon	21.3.43
3718	Pad 10	20.8.10	3716	Lift start	20.8.9	4134	Fieldbus M->S12 mon	21.3.47
3720	Lift status word	20.8.11	3718	Pad 10	20.8.10	4144	Fieldbus M->S13 mon	21.3.51
3722	Pad 12	20.8.12	3720	Lift status word	20.8.11	4154	Fieldbus M->S14 mon	21.3.55
3724	Pad 13	20.8.13	3722	Pad 12	20.8.12	4164	Fieldbus M->S15 mon	21.3.59
3726	Ramp down limit	20.8.14	3724	Pad 13	20.8.13	4174	Fieldbus M->S16 mon	21.3.63
3728	Input variable	20.8.15	3726	Ramp down limit	20.8.14	3700	Lift enable	20.8.1
3730	Lift wdec input	20.8.16	3728	Input variable	20.8.15	3702	Run cont mon	20.8.2
3676	Compare output	20.7.8	3730	Lift wdec input	20.8.16	3704	Up cont mon	20.8.3
<b>L_DIGSEL3</b>								
XXXX	(2)		(2) the XXXX parameter changes according to the src parameter used:					
6000	Null	0.0 (*)	1014 Local/remote src (2) = 1012 Dig local/remote					
1218	Digital input 5X mon	0.0 (*)						
1220	Digital input 6X mon	0.0 (*)						
1222	Digital input 7X mon	0.0 (*)						
1224	Digital input 8X mon	0.0 (*)						
1226	Digital input 9X mon	0.0 (*)						
1228	Digital input10X mon	0.0 (*)						
1230	Digital input11X mon	0.0 (*)						
1232	Digital input12X mon	0.0 (*)						
1062	Drive OK	0.0 (*)						
1064	Drive ready	0.0 (*)						
934	Ref is 0	0.0 (*)						
936	Ref is 0 delay	0.0 (*)						
<b>L_FBS2M</b>								
XXXX	(3)		(3) the XXXX parameter changes according to the src parameter used:					
6000	Null	0.0 (*)						
6002	One	0.0 (*)						
626	Ramp ref out mon	0.0 (*)						
760	Ramp out mon	0.0 (*)						

<b>PAR</b>	<b>Description</b>	<b>Menu</b>	<b>PAR</b>	<b>Description</b>	<b>Menu</b>	<b>PAR</b>	<b>Description</b>	<b>Menu</b>
4340 DS402 cw src <sup>(3)</sup> = 4024 Fieldbus M->S1 mon		21.3.3	3706	Down cont mon	20.8.4	3726	Ramp down limit	20.8.14
	<b>L_LIM</b>		3708	Brake cont mon	20.8.5	3728	Input variable	20.8.15
			3710	Lift dc brake	20.8.6	3730	Lift wdec input	20.8.16
			3712	Brake 2 mon	20.8.7	5008	Test gen out	24.1.5
6000 Null	0.0 (*)	3714	Door open mon	20.8.8				
1600 Analog input 1X mon	12.1	3716	Lift start	20.8.9				
1650 Analog input 2X mon	12.12	3718	Pad 10	20.8.10				
4024 Fieldbus M->S1 mon	21.3.3	3720	Lift status word	20.8.11				
4034 Fieldbus M->S2 mon	21.3.7	3722	Pad 12	20.8.12				
4044 Fieldbus M->S3 mon	21.3.11	3724	Pad 13	20.8.13				
4054 Fieldbus M->S4 mon	21.3.15	3726	Ramp down limit	20.8.14				
4064 Fieldbus M->S5 mon	21.3.19	3728	Input variable	20.8.15				
4074 Fieldbus M->S6 mon	21.3.23	3730	Lift wdec input	20.8.16				
4084 Fieldbus M->S7 mon	21.3.27	5008	Test gen out	24.1.5				
4094 Fieldbus M->S8 mon	21.3.31							
4104 Fieldbus M->S9 mon	21.3.35							
4114 Fieldbus M->S10 mon	21.3.39							
4124 Fieldbus M->S11 mon	21.3.43							
4134 Fieldbus M->S12 mon	21.3.47							
4144 Fieldbus M->S13 mon	21.3.51							
4154 Fieldbus M->S14 mon	21.3.55							
4164 Fieldbus M->S15 mon	21.3.59							
4174 Fieldbus M->S16 mon	21.3.63							
3700 Lift enable	20.8.1							
3702 Run cont mon	20.8.2							
3704 Up cont mon	20.8.3							
3706 Down cont mon	20.8.4							
3708 Brake cont mon	20.8.5							
3710 Lift dc brake	20.8.6							
3712 Brake 2 mon	20.8.7							
3714 Door open mon	20.8.8							
3716 Lift start	20.8.9							
3718 Pad 10	20.8.10							
3720 Lift status word	20.8.11							
3722 Pad 12	20.8.12							
3724 Pad 13	20.8.13							
3726 Ramp down limit	20.8.14							
3728 Input variable	20.8.15							
3730 Lift wdec input	20.8.16							
5008 Test gen out	24.1.5							
	<b>L_MLTREF</b>							
XXXX <sup>(4)</sup>								
1600 Analog input 1X mon	12.1	626	Ramp ref out mon	0.0 (*)				
1650 Analog input 2X mon	12.12	664	Speed setpoint	1.5				
2150 Encoder speed	15.11	262	Motor speednofilter	0.0 (*)				
4024 Fieldbus M->S1 mon	21.3.3	2150	Encoder speed	15.11				
4034 Fieldbus M->S2 mon	21.3.7	1600	Analog input 1X mon	12.1				
4044 Fieldbus M->S3 mon	21.3.11	1650	Analog input 2X mon	12.12				
4054 Fieldbus M->S4 mon	21.3.15	4024	Fieldbus M->S1 mon	21.3.3				
4064 Fieldbus M->S5 mon	21.3.19	4034	Fieldbus M->S2 mon	21.3.7				
4074 Fieldbus M->S6 mon	21.3.23	4044	Fieldbus M->S3 mon	21.3.11				
4084 Fieldbus M->S7 mon	21.3.27	4054	Fieldbus M->S4 mon	21.3.15				
4094 Fieldbus M->S8 mon	21.3.31	4064	Fieldbus M->S5 mon	21.3.19				
4104 Fieldbus M->S9 mon	21.3.35	4074	Fieldbus M->S6 mon	21.3.23				
4114 Fieldbus M->S10 mon	21.3.39	4084	Fieldbus M->S7 mon	21.3.27				
4124 Fieldbus M->S11 mon	21.3.43	4094	Fieldbus M->S8 mon	21.3.31				
4134 Fieldbus M->S12 mon	21.3.47	4104	Fieldbus M->S9 mon	21.3.35				
4144 Fieldbus M->S13 mon	21.3.51	4114	Fieldbus M->S10 mon	21.3.39				
4154 Fieldbus M->S14 mon	21.3.55	4124	Fieldbus M->S11 mon	21.3.43				
4164 Fieldbus M->S15 mon	21.3.59	4134	Fieldbus M->S12 mon	21.3.47				
4174 Fieldbus M->S16 mon	21.3.63	4144	Fieldbus M->S13 mon	21.3.51				
3700 Lift enable	20.8.1	4154	Fieldbus M->S14 mon	21.3.55				
3702 Run cont mon	20.8.2	4164	Fieldbus M->S15 mon	21.3.59				
3704 Up cont mon	20.8.3	4174	Fieldbus M->S16 mon	21.3.63				
3706 Down cont mon	20.8.4	3700	Lift enable	20.8.1				
3708 Brake cont mon	20.8.5	3702	Run cont mon	20.8.2				
3710 Lift dc brake	20.8.6	3704	Up cont mon	20.8.3				
3712 Brake 2 mon	20.8.7	3706	Down cont mon	20.8.4				
3714 Door open mon	20.8.8	3708	Brake cont mon	20.8.5				
3716 Lift start	20.8.9	3710	Lift dc brake	20.8.6				
3718 Pad 10	20.8.10	3712	Brake 2 mon	20.8.7				
3720 Lift status word	20.8.11	3714	Door open mon	20.8.8				
3722 Pad 12	20.8.12	3716	Lift start	20.8.9				
3724 Pad 13	20.8.13	3718	Pad 10	20.8.10				
3726 Ramp down limit	20.8.14	3720	Lift status word	20.8.11				
3728 Input variable	20.8.15	3722	Pad 12	20.8.12				
3730 Lift wdec input	20.8.16	3724	Pad 13	20.8.13				
5008 Test gen out	24.1.5							
	<b>L_WDECOMP</b>							
XXXX <sup>(6)</sup>								
6000 Null								
6002 One								
4432 Word comp mon								
4024 Fieldbus M->S1 mon								

<b>PAR</b>	<b>Description</b>	<b>Menu</b>	<b>PAR</b>	<b>Description</b>	<b>Menu</b>	<b>PAR</b>	<b>Description</b>	<b>Menu</b>
4034	Fieldbus M->S2 mon	21.3.7						
4044	Fieldbus M->S3 mon	21.3.11						
4054	Fieldbus M->S4 mon	21.3.15						
4064	Fieldbus M->S5 mon	21.3.19						
4074	Fieldbus M->S6 mon	21.3.23						
4084	Fieldbus M->S7 mon	21.3.27						
4094	Fieldbus M->S8 mon	21.3.31						
4104	Fieldbus M->S9 mon	21.3.35						
4114	Fieldbus M->S10 mon	21.3.39						
4124	Fieldbus M->S11 mon	21.3.43						
4134	Fieldbus M->S12 mon	21.3.47						
4144	Fieldbus M->S13 mon	21.3.51						
4154	Fieldbus M->S14 mon	21.3.55						
4164	Fieldbus M->S15 mon	21.3.59						
4174	Fieldbus M->S16 mon	21.3.63						
3700	Lift enable	20.8.1						
3702	Run cont mon	20.8.2						
3704	Up cont mon	20.8.3						
3706	Down cont mon	20.8.4						
3708	Brake cont mon	20.8.5						
3710	Lift dc brake	20.8.6						
3712	Brake 2 mon	20.8.7						
3714	Door open mon	20.8.8						
3716	Lift start	20.8.9						
3718	Pad 10	20.8.10						
3720	Lift status word	20.8.11						
3722	Pad 12	20.8.12						
3724	Pad 13	20.8.13						
3726	Ramp down limit	20.8.14						
3728	Input variable	20.8.15						
3730	Lift wdec input	20.8.16						

<sup>(6)</sup> the XXXX parameter changes according to the src parameter use:

4452 Word decomp src  
<sup>(6)</sup>= 4450 Dig word decomp      21.6.1


(\*) Parameter not shown on the keypad. For information see the "PARAMETERS INCLUDED IN SELECTION LISTS BUT NOT SHOWN ON THE KEYPAD" section.

## D - Block Diagrams

### System diagram index

<b>DRIVE OVERVIEW</b>	<a href="#">DrvOverview</a>	<b>ENCODER CONFIG</b>
<b>LIFT</b>	<a href="#">Lift</a>	<b>SPEED REG GAINS</b>
<b>DIGITAL INPUTS</b>	<a href="#">DigInps</a>	<b>TORQUE CONFIG</b>
<b>DIGITAL OUTPUTS</b>	<a href="#">DigOuts</a>	<b>VF PARAMETERS</b>
<b>ANALOG INPUTS</b>	<a href="#">AnalInps</a>	<b>FUNCTIONS</b>
<b>ANALOG OUTPUTS</b>	<a href="#">AnalOuts</a>	



### Drive overview (DrvOverview)







# ADL1 application index (ADL1FuncIndex)




## Multispeed








## Expansion card digital inputs (DigImpExp)



## Expansion card digital outputs (DigOutExp)





## Analog inputs

ANALOG INPUT 1 EXPANSION CARD

AnInp1Exp

ANALOG INPUT 2 EXPANSION CARD

AnInp2Exp





## Analog outputs

ANALOG OUTPUT 1 EXPANSION CARD


AnOut1Exp

ANALOG OUTPUT 2 EXPANSION CARD


AnOut2Exp



## Encoder config








## SLS control (ControlVf)





## Functions


INERTIA COMP	InertiaComp
DC BRAKING	DCBraking
MOTOR OVERLOAD	MotOvld
BRES OVERLOAD	BresOvld
DOUBLE PAR SET	DoubleParSet









## Torque control (TorqueCtrl)



## Gains adaptive (GainAdapt)





## Appendix - 1.0 CANopen interface

---

CANopen is a communication profile for CAL-based industrial systems. The reference document is the CANopen CAL-Base COMMUNICATION PROFILE for Industrial Systems; CiA Draft Standard 301 Version 4.2 Date 13 February 2002 by CAN in Automation e. V.

The drive also implements the DS402 profile according to the CANopen Device Profile Drives and Motion Control v4.02 specification.

The CAN protocol (ISO 11898) is CAN2.0A with an 11-bit identifier.

The integrated CANopen interface is developed as a "Minimum Capability Device".

The data exchange is cyclic; the Master unit reads the Slave input data and writes the Slave output data.

**Note!**

CANopen is only present in ADL2.0-...-C models.

### 1.1 CANopen functions

This chapter describes the controlled functions of the CANopen communication profile.

#### Main features:

- 1) The "Minimum Boot-up" is managed; the "Extended Boot-up (CAL)" is not managed.
- 2) The SYNC function is implemented.
- 3) The PDO asynchronous assignment and RTR are managed.
- 4) The Node Guarding and HeartBeat protocols are managed.
- 5) The emergency message is managed ("EMERGENCY").
- 6) The Dynamic ID distribution function (DBT slave) is not managed.
- 7) A "Pre-Defined Master/Slave connection" is implemented to simplify the Master tasks during the initialization phase. "Inhibit-Times" (in units of 100 uS) can be modified up to a value of 1 min.
- 8) The high-resolution synchronization is not supported.
- 9) "TIME STAMP" is not managed.
- 10) On the access of the structured parameters, the OFFhex option subindex (access to the whole object) is not managed.
- 11) In order to obtain a higher efficiency level, only the "Expedited" data transfer (max. 4 Bytes) of the SDO services is managed.

#### 1.1.1 Pre-defined Master/Slave Connection

The "Pre-defined Master/Slave connection" allows a peer-to-peer communication between one Master and 127 Slaves; the Broadcast address is zero.

#### 1.1.2 NMT Services (Network Management)

The NMT "mandatory" services are:

- Enter\_Pre-Operational\_State CS = 128
- Reset\_Node CS = 129
- Reset\_Communication CS = 130

Being that the "Minimum Boot-up" is used, also the following NMT services are managed:

- Start\_Remote\_Mode CS = 1
- Stop\_Remote\_Mode CS = 2

The COB-ID \* of an initialization NMT service is always at 0; CS is the Command Specifier defining the NMT service.

#### 1.1.3 Initialization

The ADV drive supports the Node Guarding and HeartBeat mechanism. The Node Guarding configuration can be performed through the master via the standard Object Dictionary elements (1006h, 100Ch, 100Dh) and the 1016h, 1017h objects for HeartBeat.

The drive checks the master functioning conditions through the Life Guarding. If the check fails, the drive enables the "Buss Loss" alarm. The Life Guarding threshold can be calculated as follows:

Value	Condition
60ms SYNC_PERIOD (*)	Default. No parameterization of the Node Guarding.

<b>LIFE_TIME_FACTOR</b>	Use of the synchronous mode. If not stated by the master, the Life_Time_Factor default value is equal to 3.
<b>NODE_GUARDING_PERIOD (*)</b>	set by the master
<b>LIFE_TIME_FACTOR</b>	If not otherwise stated, the value is equal to 3

### 1.1.4 Communication objects

This chapter describes the communication objects of the CANopen protocol; they are managed by the interface card.

The managed communication objects are:

- 1) 1 SDO reception Server.
- 2) 1 SDO transmission Server.
- 3) 2 reception PDOs.
- 4) 2 transmission PDOs.
- 5) 1 Emergency Object.
- 6) 1 Node Guarding - Life Guarding.
- 7) 1 SYNC object.

The following table lists the used communication objects with their priority level and the Message Identifier; the “Resulting COB-ID” is obtained by adding the Node-ID (card address) to the number.

OBJECT	PRIORITY	MESSAGE ID
1st SDO rx	6	1536 600h+Nodeld
1st SDO tx	6	1408 580h+Nodeld
1st PDO rx	2	512 200h+Nodeld
1st PDO tx	2	384 180h+Nodeld
2nd PDO rx	2	768 300h+Nodeld
2nd PDO tx	2	640 280h+Nodeld
3rd PDO rx	2	512 400h+Nodeld
3rd PDO tx	2	384 380h+Nodeld
4th PDO rx	2	768 500h+Nodeld
4th PDO tx	2	640 480h+Nodeld
EMERGENCY	1	220 80h+Nodeld
NODE GUARDING & HB	not used	1792 700h+Nodeld
SYNC	0	128 80h

Table 1.4.1: Communication Objects

Node Guarding has no priority because it is a special NMT service; it has the Message-ID because it is not a Broadcast service.

### 1.1.5 Object Dictionary Elements

The Object Dictionary is accessible from a master CANopen.

The following table shows the communication objects used and accessibility with master CANopen.

Index (hex)	Name
1000	Device Type
1001	Error Register
1002	Manufacturer status register
1005	COB-ID SYNC Message
1006	Communication cycle period
1008	Manufacturer Device Name
1010	Store parameter
1009	Manufacturer Hardware Version
100A	Manufacturer Software Version
100C	Guard Time
100D	Life Time Factor
1014	COB-ID Emergency
1016	HeartBeat time consumer
1017	HeartBeat time producer
1018	Identity object
1400	1st Receive PDO
1401	2nd Receive PDO
1402	3rd Receive PDO

1403	4th Receive PDO
<b>1600</b>	Receive PDO1 mapping parameter
<b>1601</b>	Receive PDO2 mapping parameter
<b>1602</b>	Receive PDO3 mapping parameter
<b>1603</b>	Receive PDO4 mapping parameter
<b>1A00</b>	Transmit PDO1 mapping parameter
<b>1A01</b>	Transmit PDO2 mapping parameter
<b>1A02</b>	Transmit PDO3 mapping parameter
<b>1A03</b>	Transmit PDO4 mapping parameter
1800	1st Transmit PDO
1801	2nd Transmit PDO
1802	3rd Transmit PDO
1803	4th Transmit PDO

Table 1.5.1: Objects used by the CANopen communication profile

The objects shown in bold in the table allow writing of the parameters assigned with the exchange of data in the PDO.

The allocation criterion is variable, and depends on the size (in bytes) of the parameter exchanged.

### 1.1.6 RX PDO Entries

The structure of the PDO Communication Parameter (index 1400h, 1401h) is:

- 1) Subindex 0 (Number of supported entries ) = 2
- 2) The structure of Subindex 1 (COB-ID used by the PDO) is:
  - Bit 31 (valid/invalid PDO) can be set via SDO.
  - Bit 30 (RTR Remote Transmission Request) = 0 because this function is not supported.
  - Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
  - Bits 11-28 are not used.
  - Bit 0-10 COB-ID (see table 1.4.1).
- 3) Cyclic-synchronous Subindex 2 (Transmission Type), or synchronous according to the master performed setting (1 if SYNC has been foreseen, 254...255 if asynchronous). If not stated, the synchronous mode is active.

### 1.1.7 TX PDO Entries

The structure of the PDO Communication Parameter (index 1800h, 1801h) is:

- 1) Subindex 0 (Number of supported entries ) = 3
- 2) The structure of Subindex 1 (COB-ID used by the PDO) is:
  - Bit 31 (valid/invalid PDO) can be set via SDO.
  - Bit 30 (RTR Remote Transmission Request) = 0 because this function is not supported.
  - Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
  - Bits 11-28 are not used.
  - Bit 0-10 COB-ID (see table 1.4.1).
- 3) Cyclic-synchronous Subindex 2 (Transmission Type), or synchronous according to the master performed setting (1 if SYNC has been foreseen, 254...255 if asynchronous). If not stated, the synchronous mode is active.
- 4) Inhibit time

### 1.1.8 SDO Entries

Only the "Expedited" data transfer mode (max. 4 Bytes) is used.

- 1) Subindex 0 (Number of supported entries ) = 3 because the device is a Server of the SDO service.
- 2) The structure of the Subindex 1 and 2 (COB-ID used by the SDO) is:
  - Bit 31 (valid/invalid SDO); it is equal to 1 because just the Default SDOs are used.
  - Bit 30 reserved = 0.
  - Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
  - Bits 11-28 are not used.
  - Bit 0-10 COB-ID (see table 1.4.1).

The element "node ID of SDO's client resp. server" is not supported because just the Default SDOs are used.

### 1.1.9 COB-ID SYNC Entries

The structure of the 32 bits contained in the COB-ID SYNC communication parameter is:

- Bit 31 = 1 because the CANopen interface card is a “consumer” of SYNC messages.
- Bit 30 = 0 because the interface card does not create SYNC messages.
- Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
- Bits 11-28 are not used.
- Bit 0-10 COB-ID (see table 1.4.1).

### 1.1.10 COB-ID Emergency

The structure of the 32 bits contained in the COB-ID Emergency Message communication parameter is:

- Bit 31 = 0 because the CANopen interface card is not a “consumer” of Emergency messages.
- Bit 30 = 0 because the interface card creates Emergency messages.
- Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
- Bits 11-28 are not used.
- Bit 0-10 COB-ID (see table 1.4.1).

## 1.2 CANopen management

The user interface of the CANopen protocol is performed via the drive parameters. The parameters are controlled via hierarchical menus. All the writing parameters referring to the field bus are active only after the drive reset. Here following is a list of drive parameters useful to control the CANopen protocol.

To enable CANopen, set parameter PAR 4000 **Fieldbus type** to CANopen or DS402.

The following parameters are available in the COMMUNICATION->FIELDBUS CONFIG menu:

PAR	Par Name	Type	Default value	Attr
4004	Fieldbus baudrate	Enum	None	Write
4006	Fieldbus address	2 byte unsigned	0	Write
4010	Fieldbus M->S enable	Enum	On	Write
4012	Fieldbus alarm mode	2 byte unsigned	0	Write
4014	Fieldbus state	Enum	Stop	Read only

- Fieldbus baudrate = Sets the network baud rate. Values available for CANopen: 125k, 250k, 500k, 1M
- Fieldbus address = address of this slave node in the network, accepted values from 1 to 127
- Fieldbus M->S enable = if set to Off data in the RPDOs are not processed by the drive
- Fieldbus alarm mode = if set to 1 the drive generates Opt Bus Fault errors relating to the loss of communication (Bus Loss) even when the drive is not enabled.
- Fieldbus state = state of the communication for this node on the CANopen network: Stop, Pre-Operational, Operational.

## 1.3 Process Data Channel Control

This function allows to allocate the drive parameters or application variables to the Process Data Channel data.

As for the CANopen protocol, the PDC is performed via the PDO messages (Process data Object).

The CANopen protocol uses a number of words for the Process Data Channel (abbr. PDC Process Data Channel ), which can always be set.

The fieldbus Process Data Channel configuration is the following:

Data 0      Data...      Data n

The drive can both read and write the Process Data Channel data.

A datum can be made both of 2 and 4 bytes. The word “data” refers to any quantity of bytes included between 0 and 16, if the byte total number required is not higher than 32.

*Example:*


It is possible to have:

- from 0 to 16 data with 2 bytes
- 1 datum with 4 bytes + from 0 to 14 data with 2 bytes
- 2 data with 4 bytes + from 0 to 12 data with 2 bytes
- ...
- 8 data with 4 bytes

The data exchanged via the PDC can be of two types:

- drive parameters
- variables of an MDPlc application. The use of the MDPlc variables is described in par. 1.3.1 and 1.3.2.

The master writes the data defined as PDC input and reads the data defined as PDC output.



### 1.3.1 PDC Input Configuration (FB XXX MS Parameter)

Data exchanged in RPDOs are configured using the parameters in the COMMUNICATION->FIELDBUS M2S menu (refer to the drive manual).

Data mapping in PDOs is performed on the basis of the data format set in Fieldbus M->Sn sys according to the following rules:

- PDOs are filled starting from RPDO1
  - When the PDO contains 4 words it is full and the next RPDO is filled with a maximum of 4 PDOs
  - 32-bit data (long or float) cannot be split among PDOs, they must be placed inside the PDO (an alarm is generated)
  - PDOs containing fewer than 4 words can be created, using **Fieldbus M->Sn dest= None** but assigned (**Fieldbus M->Sn sys** other than Not Assigned, Fill16 or Fill32) after an assigned datum.
- (N.B.: if assigned as Fill16 or Fill32, the datum is included in the PDO anyway)
- At the first **Fieldbus M->Sn sys = Not Assigned** parameter the PDOs are complete. The size of the last PDO thus depends on the data that have been assigned.
  - **Example : RPDO1 di 2 word and RPDO2 di 2 word:**

Fieldbus M->S1 dest = Ramp ref 1 src

Fieldbus M->S1 sys = Eu

Fieldbus M->S2 dest = Word decomp src

Fieldbus M->S2 sys = Count 16

Fieldbus M->S3 dest = None

Fieldbus M->S3 sys = Count 32

Fieldbus M->S4 dest = Compare 1 src

Fieldbus M->S4 sys = Count32

Fieldbus M->S5 sys = Not Assigned

### 1.3.2 PDC Output Configuration (FB XXX SM Parameter)

Data exchanged in RPDOs are configured using the parameters in the COMMUNICATION->FIELDBUS S2M menu (refer to the drive manual).

Data mapping in PDOs is performed on the basis of the data format set in **Fieldbus M->Sn sys** according to the following rules:

- PDOs are filled starting from TPDO1
- When the PDO contains 4 words it is full and the next TPDO is filled with a maximum of 4 PDOs.
- 32-bit data (long or float) cannot be split among PDOs, they must be placed inside the PDO (an alarm is generated).
- PDOs with fewer than 4 words can be created, using Fieldbus S->Mn src= None Used but assigned (**Fieldbus M->Sn sys** other than Not Assigned, Fill16 or Fill32) after an assigned datum.
- At the first **Fieldbus S->Mn sys = Not Assigned** parameter the PDOs are complete. The size of the last PDO thus depends on the data that have been assigned.

### 1.3.3 Use of the PDC in MDPlc Applications

It is possible to configure both the PDC input and output data in order to allow the data direct access via the MDPlc application code.

For read data simply set **Fieldbus M->Sn sys** to MDPLC16 or MDPLC32, leaving **Fieldbus M->Sn dest = None**.

The MDPLC application can now read the incoming datum directly from the **Fieldbus M->Sn mon** parameter.

Write data are configured by setting **Fieldbus S->Mn src = Dig Fieldbus S->Mn**.

**Fieldbus S->Mn sys** is automatically set to MDPLC. The application writes the datum in the **Dig Fieldbus S->Mn** parameter to send it to the bus.

## 1.4 SDO management

The SDO service is always available.

The drive parameters can be accessed via the “MSPA” Manufacturer Specific Profile Area (2000hex < index < 5FFFhex).

The index to be shown in the SDO command to access a drive parameter is obtained via the following rules:

SDO index = PAR + 2000h

SDO subindex = 1

The Data field must contain the value of the drive parameter.

*Example:*

Writing the value 1000 in the PAR 600 **Dig Ramp ref 1** parameter (258hex).

The following information is required:

1) The SDO index resulting from the formula is

$$2000\text{hex} + 258\text{hex} = 2258\text{h}$$

2) The value to be written is 1000, corresponding to 03E8 hex.

Index	Subindex					
22h	58h	01h	E8h	03h	00h	00h
Drive parameter index	Subindex			Drive parameter value to be assigned to SDO		

In case an error occurs during the parameter reading or setting, the CANopen interface sends an Abort domain transfer message; the value of Application-error-codes has the following meanings:

Error class	Error code	Additional code (hex)	Meaning
6	0	0	Parameter doesn't exist
8	0	22	Access failed because of present device state
6	1	2	Read/Write only error
8	0	0	Generic error
6	9	32	Minimum value
6	9	31	Maximum value
5	4	0	SDO time_out
5	4	1	Invalid command
3	9	30	Invalid value

## 1.5 Alarms

### Fieldbus alarms

The bus failure is signaled via the “Opt Bus Fault” alarm. As for CANopen, the possible failure causes are:

- “Bus-off” condition of the CAN line;
- the drive has not been enabled in the “Operational” mode;
- the “Life Guarding” threshold has been overcome.

This alarm becomes active only when the drive is enabled.

If ON, the PAR 4014 **Fieldbus alarm mode** parameter enables the generation of the “Field bus failure” alarm also when the drive is disabled.

Codice	Cfg	Description	Actions
0		Bus Loss	Check line for noise, terminations , problems with cabling
FF01	*	Fieldbus type does not match expansion card	Please contact Technical Assistance.
FF02	*	Wrong baudrate selected	Check "Fieldbus baudrate" is one of 125k, 250k, 500k, 1M
FF03	*	Invalid address for node	Check "Fieldbus address"
FF04	*	Error initializing CAN interface	Internal error, contact manufacturer
FF14..FF23	*	Wrong object selected for mapping in channel M2S n	Check "Fieldbus M->Sn Dest"
FF24..FF33	*	More than 1 Src pointing to M2S Channel n	Check for multiple destinations on "Fieldbus M->Sn Dest"
FF34..FF43	*	M2S Channel n , data size is wrong (16 bits on 32 bits or 32 bits on 16 bits parameter)	Check "Fieldbus M->Sn sys"
FF44..FF53	*	Invalid parameter in channel S2M n	Check "Fieldbus S->Mn src"
FF54..FF63	*	S2M Channel n , data size is wrong (16 bits on 32 bits or 32 bits on 16 bits parameter)	Check "Fieldbus S->Mn sys"
FF64..FF73	*	Wrong object selected for mapping in channel S2M n	Check "Fieldbus S->Mn src"
FF74..FF83	*	M2S Channel n : too many words in PDC	"Fieldbus M-Sn dest" & "Fieldbus M->Sn sys" address more than 16 words in PDC
FF84..FF93	*	S2M Channel n : too many words in PDC	"Fieldbus S->Mn src" & "Fieldbus S->Mn sys" address more than 16 words in PDC
FFB4..FFC3	*	Internal database error on channel n	Internal error, contact manufacturer
8110		CAN msg overflow	Too many packets for selected baudrate
8130		LifeGuard/HeartBeat error	Software timeout from master
FFC5		Wrong NMT message length	Check NMT packets
FFC6		Invalid NMT command	Check NMT packets
FFC7		CAN bus off	Check line state for problems

### Drive alarm handling

Drive alarms are managed by means of an Emergency message containing the error code relating to the alarm that is generated, according to the table below:

Selection	Code
No alarm	0x0000
Oversoltage	0x3210
Undervoltage	0x3220
Ground fault	0x2110
Overcurrent	0x2310
Desaturation	0x2130
MultiUndervolt	0xFF06
MultiOvcurr	0xFF07
TechnMultiDesat	0xFF08
Heatsink OT	0x4210
HeatsinkS OTUT	0x4310
Intakeair OT	0x4130
Motor OT	0xFF0C
Drive overload	0x8311
Motor overload	0x7121
Bres overload	0x7112
Phaseloss	0xFF10
Opt Bus fault	0xFF11
Opt 1 IO fault	0xFF12
Opt Enc fault	0x3130
External fault	0x9000
Speed fbk loss	0x7310
Overspeed	0x8400
Plc1 fault	23
Plc2 fault	24
Plc3 fault	25
Plc4 fault	26
Plc5 fault	27
Plc6 fault	28
Plc7 fault	29
Plc8 fault	30
Emg stop alarm	31
Watchdog	32
Trap error	33

Selection	Code
System error	34
User error	35
Power down	36
Speed ref loss	37
Not Used1	38
Opt 2 IO fault	39
Not Used2	40
Not Used3	41
Not Used4	42
Not Used5	43
Not Used6	44
Param error	45

## 1.6 Configuration example

This chapter provides an example of how to configure the parameters of ADL200 drives so that they can be read and written by a CANopen master via the processing channels (PDO). See the chapter 1.4 for the configuration channels (SDO).

The paragraph 1.6.1 provides the information required on a CANopen master controlling a machine. The paragraph 1.6.2 contains basic information for programming the ADL200 drive starting from the factory settings.

In this example, drive programming is performed using the GF-Express configurator. All operations can, of course, be performed via keypad.

### 1.6.1 CANopen Master

This section contains an example of data exchange seen from the master side. This is the data normally contained in the machine specifications in the case of applications controlled by a CANopen master.

#### 1.6.1.1 Description of Master -> Slave PDO Communication

There are two parameters to be written via the processing channels. The first is a control word, in which the single bits contain certain commands (e.g. enable, start, etc.). The second processing channel contains the ramp reference 1 (RampRef1) in rpm.

*CANopen PDO: Master -> Drive (max 16 word)*

Position	Description	Format	Unit of Measure
Word1 M -> S	Control word	16 bit Word	...
Word2 M -> S			
Word3 M -> S			
Word4 M -> S			
Word5 M -> S			
Word6 M -> S			
Word7 M -> S			
...			
...			
Word16 M > S			

*CONTROL WORD*

Bit	Description	Remarks
0	EnableCmd	Enable command
1	StartFwdCmd	Start forward command
2	StartRevCmd	Start reverse command
3	MltSpd S0	Multi speed 0 sel
4	MltSpd S1	Multi speed 1 sel
5	MltSpd S2	Multi speed 2 sel
6	DoorOpenEna	Source to enable the open door function
7	BrakeOpenExt	External brake command from PLC
8	BrakeFbk	Closed brake contact
9	DoorFbk	Closed door contact
10	ContFbk	Closed contactor contact
11	InvRampSrc	Command to invert the ramp sign
12	UpperLimit	Upper limit Cam

13	LowerLimit	Lower limit Cam
14	Free	
15	Free	

#### 1.6.1.2 Description of PDO Slave -> Master Communication

In this example the CANopen master reads two parameters from the drive. The first contains a status word in which the single bits carry information about the status of the drive (e.g. DriveOk). The second parameter is the actual speed in rpm.

*CANopen PDO Slave > Master (max 16 Word)*

Position	Description	Format	Unit of Measure
Word1 S -> M	Status Word	16 bit Word	BitWide
Word2 S -> M	Actual Speed	Int 16 bit	rpm
Word3 S -> M			
Word4 S -> M			
Word5 S -> M			
Word6 S -> M			
Word7 S -> M			
...			
...			
Word16 S -> M			

Lift control outputs can usually be connected to the PAD parameters according to the table below:

Bit	Description	Remarks
0	LiftEnable	Lift enable command.
1	RunCont	Run command contactor
2	UpCont	Up command contactor
3	DownCont	Down command contactor
4	BrakeCont	Brake command contactor
5	LiftDcBrake	DC brake function command (firmware)
6	Brake2	Brake control signal (See sequences)
7	DoorOpen	Open door command
8	LiftStart	Lift start command
9	----	
10	Lift status word	Contains copy of the StatusWord (selectable via SelLiftStatWord)
11	----	
12	----	
13	----	
14	InputVariable	Connected to the input selector
15	LiftWdeInp	Connected to the LiftWDecomp selector
16		

*LiftStatusWord (connected to Pad11)*

Bit	Description	Remarks
0	LiftEnable	Lift enable command.
1	RunCont	Run command contactor
2	UpCont	Up command contactor
3	DownCont	Down command contactor
4	BrakeCont	Brake command contactor
5	LiftDcBrake	DC brake function command (firmware)
6	Brake2	Brake control signal (See sequences)
7	DoorOpen	Open door command
8	Drive Ok	
9	SpeedIsZero	
10	SpeedRefIsZero	
11		

12		
13		
14		
15	(EPC Enable)	

Outputs available directly on the drive:

- Drive OK
- SpeedIsZero

## 1.6.2 ADL200 Configuration

The example given in this section is based on the assumption that the parameters of the ADL200 drive are the factory settings (**Default parameter** command). Use of the keypad is recommended for performing commissioning in the first phase (see the ADL200 “Quick start guide”). Then the motor should be moved using the digital input commands.

Similarly, a system start-up wizard must be available on the GF\_Express configurator .


The programming sequence is as follows:

- **Fieldbus configuration**
- **Fieldbus M2S configuration**
- **LIFT\LIFT IN/OUT configuration**
- **Fieldbus S2M configuration**

### 1.6.2.1 FIELDBUS CONFIG

This example shows the parameter settings to be performed with 500Kbaud CanOpen and address 12.

- Menù 21.2- COMMUNICATION\FIELDBUS CONFIG.
- Example of configuration with **500Kbaud CanOpen address 12**:



### 1.6.2.2 Fieldbus M2S configuration

As regards communication through process channels (PDC), in the configuration in this example, the first channel is reserved for writing lift commands (writing of the control word).

- Menù 21.3 - COMMUNICATION\FIELDBUS M2S
- PDO M->S configuration:

IPA	Parameter Name	Value	Default value	Unit	Type	Description
4020*	Fieldbus M->S1 dest	Not used	Not used		Enum	
4022	Fieldbus M->S1 sys	Mdpic 16	Not assigned		Enum	
4024*	Fieldbus M->S1 mon	0	0		Long	
4026	Fieldbus M->S1 div	1	1		Float	
4030*	Fieldbus M->S2 dest	Not used	Not used		Enum	
4032	Fieldbus M->S2 sys	Not assigned	Not assigned		Enum	
4034*	Fieldbus M->S2 mon	0	0		Long	
4036	Fieldbus M->S2 div	1	1		Float	
4040*	Fieldbus M->S3 dest	Not used	Not used		Enum	
4042	Fieldbus M->S3 sys	Not assigned	Not assigned		Enum	
4044*	Fieldbus M->S3 mon	0	0		Long	
4048	Fieldbus M->S3 div	1	1		Float	
4050*	Fieldbus M->S4 dest	Not used	Not used		Enum	
4052	Fieldbus M->S4 sys	Not assigned	Not assigned		Enum	
4054*	Fieldbus M->S4 mon	0	0		Long	
4056	Fieldbus M->S4 div	1	1		Float	
4060*	Fieldbus M->S5 dest	Not used	Not used		Enum	
4062	Fieldbus M->S5 sys	Not assigned	Not assigned		Enum	
4064*	Fieldbus M->S5 mon	0	0		Long	
4066	Fieldbus M->S5 div	1	1		Float	
4070*	Fieldbus M->S6 dest	Not used	Not used		Enum	
4072	Fieldbus M->S6 sys	Not assigned	Not assigned		Enum	
4074*	Fieldbus M->S6 mon	0	0		Long	
4076	Fieldbus M->S6 div	1	1		Float	
4080*	Fieldbus M->S7 dest	Not used	Not used		Enum	
4082	Fieldbus M->S7 sys	Not assigned	Not assigned		Enum	
4084*	Fieldbus M->S7 mon	0	0		Long	
4086	Fieldbus M->S7 div	1	1		Float	
4090*	Fieldbus M->S8 dest	Not used	Not used		Enum	

### 1.6.2.3 LIFT IN/OUT configuration

This channel is connected to the “LiftWdecomp” block.

The single output bits from this can be connected to the various lift commands using the following programming procedure:

- Menù 5.7 LIFT\LIFT IN/OUT

IPA	Parameter Name	Value	Default value	Unit	Type	Description
11220	Lift enable cmd sel	Digital input E	Digital input E	Enum	Enum	Enable command selector
11222	Start fwd cmd sel	B1 Lift decompr	Digital input 1x	Enum	Enum	Start forward selector
11224	Start rev cmd sel	B2 Lift decompr	Digital input 2x	Enum	Enum	Start reverse selector
11226	Multi speed 30 sel	B3 Lift decompr	Digital input 4x	Enum	Enum	Multi speed selector 0
11228	Multi speed 31 sel	B4 Lift decompr	Digital input 5x	Enum	Enum	Multi speed selector 1
11230	Multi speed 32 sel	B5 Lift decompr	Digital input 6x	Enum	Enum	Multi speed selector 2
11232	Contactor fbk sel	Run cont mon	Run cont mon	Enum	Enum	Select the origin of contact feedback signal
11236	Brake fbk sel	Brake cont mon	Brake cont mon	Enum	Enum	Select the origin of brake feedback signal
11238	Door open sel	B6 Lift decompr	Null	Enum	Enum	Select the origin of door open signal
11240	Door feedback sel	Door open mon	Null	Enum	Enum	Select the origin of door feedback signal
11242	Emergency mode sel	Digital input 3x	Digital input 3x	Enum	Enum	Select the origin of emergency mode function
11244	Inversion ramp sel	Null	Null	Enum	Enum	Select the origin of contactor for change direction
11246	Upper limit sel	B12Lift decompr	Null	Enum	Enum	Select the origin of upper limit sensor
11248	Lower limit sel	B13Lift decompr	Null	Enum	Enum	Select the origin of lower limit sensor
11250	Dcp3 mode command	Off	Off	Bool	Bool	Command from DCP 3 protocol
12102*	Command input mon	1	0	Hex	DWord	Lift control word input
12104*	Command output mon	700	0	Hex	DWord	Lift status word output

Now all lift sequences are controlled via the LiftWdecomp bits in the same way as described in the manual using digital inputs.

#### 1.6.2.4 Fieldbus S2M configuration

As regards M <->S communication in this example only the first process channel is used. It can be programmed to contain the lift status word (using the LiftWComp function block). The second process channel is programmed on "Motor Speed".

- Menù 21.4 COMMUNICATION\FIELDBUS S2M

The screenshot shows the software interface for configuring a Baumeister drive. The title bar reads "Copia di add1\_0\_10\_6MoBaumullerFieldbus [ FIELDBUS S2M ] - EasyDrives". The menu bar includes File, View, Parameters, Target, Service, Help. The toolbar has various icons for file operations. The left sidebar is a tree view of the parameter structure, with "FIELDBUS S2M" selected under "COMMUNICATION". The main area is a table with columns: IPA, Parameter Name, Value, Default value, Unit, Type, Description. The table lists parameters such as 4100 (Fieldbus S->M1 src), 4102 (Fieldbus S->M1 sys), 4104 (Dig Fieldbus S->M1), 4106 (Fieldbus S->M1 md), 4108 (Fieldbus S->M2 src), 4110 (Fieldbus S->M2 sys), 4112 (Dig Fieldbus S->M2), 4114 (Fieldbus S->M2 md), 4116 (Fieldbus S->M3 src), 4118 (Fieldbus S->M3 sys), 4120 (Dig Fieldbus S->M3), 4122 (Fieldbus S->M3 md), 4124 (Fieldbus S->M4 src), 4126 (Fieldbus S->M4 sys), 4128 (Dig Fieldbus S->M4), 4130 (Fieldbus S->M5 src), 4132 (Fieldbus S->M5 sys), 4134 (Dig Fieldbus S->M5), 4136 (Fieldbus S->M5 md), 4138 (Fieldbus S->M6 src), 4140 (Fieldbus S->M6 sys), 4142 (Dig Fieldbus S->M6), 4144 (Fieldbus S->M6 md), 4146 (Fieldbus S->M7 src), 4148 (Fieldbus S->M7 sys). The "Value" column for 4100 is highlighted in yellow.

IPA	Parameter Name	Value	Default value	Unit	Type	Description
4100	Fieldbus S->M1 src	Dig Fieldbus S->M1	null		Enum	
4102	Fieldbus S->M1 sys	Motor 1E	Not assigned		Enum	
4104	Dig Fieldbus S->M1	1792	0		Long	
4106	Fieldbus S->M1 md	1	1		Float	
4108	Fieldbus S->M2 src	Dig Fieldbus S->M2	null		Enum	
4110	Fieldbus S->M2 sys	Motor 1E	Not assigned		Enum	
4112	Dig Fieldbus S->M2	0	0		Long	
4114	Fieldbus S->M2 md	0	0		Float	
4116	Fieldbus S->M3 src	Motor speed	null		Enum	
4118	Fieldbus S->M3 sys	Count 1E	Not assigned		Enum	
4120	Dig Fieldbus S->M3	0	0		Long	
4122	Fieldbus S->M3 md	1	1		Float	
4124	Fieldbus S->M4 src	Null	Null		Enum	
4126	Fieldbus S->M4 sys	Not assigned	Not assigned		Enum	
4128	Dig Fieldbus S->M4	0	0		Long	
4130	Fieldbus S->M4 md	1	1		Float	
4132	Fieldbus S->M5 src	Null	Null		Enum	
4134	Fieldbus S->M5 sys	Not assigned	Not assigned		Enum	
4136	Dig Fieldbus S->M5	0	0		Long	
4138	Fieldbus S->M5 md	1	1		Float	
4140	Fieldbus S->M6 src	Null	Null		Enum	
4142	Fieldbus S->M6 sys	Not assigned	Not assigned		Enum	
4144	Dig Fieldbus S->M6	0	0		Long	
4146	Fieldbus S->M6 md	1	1		Float	
4148	Fieldbus S->M7 src	Null	Null		Enum	
4150	Fieldbus S->M7 sys	Not assigned	Not assigned		Enum	

#### 1.7 Operator interface / MMI

The ModBus protocol can be used to access all drive parameters via serial line. Access is via IPA and of the type described in the Drive manual.

If using a fieldbus card (e.g. CanOpen, Profibus) communication via configuration channels is similar to that described above, while for the use of process channels see the drive fieldbus menu.

## Appendix - 2.0 Operation according to the DS402 profile

If the PAR 4000 **Fieldbus type** parameter is set to DS402 the drive works with the standard profile for Drives & Motion Control Ver 2.0 and contains Device Identity 192H (402) in object 1000h.

The ADL200 drive supports Velocity Mode.

In the default configuration the drive is automatically set to use PDOs No. 6 (DS402 section 7.2.1 & 7.2.2 ), mapped onto RPDO1 and TPDO1 with COB-ID 200h & 180h +Nodeld

PDO	Object Number	Object Name	Description
6	6040h	Controlword	controls the state machine and the nominal speed (vl)
	6042h	Target velocity (vl)	
6	6041h	Statusword	shows status and the current speed (vl)
	6044h	vl control effort	

The remaining PDOs can be set by the user.


The following DS402 objects are implemented:

Object Number		Description	Type	Access	Mandatory
6040h	VAR	Controlword	UNSIGNED16	rw	M
6041	VAR	Statusword	UNSIGNED16	ro	M
6042h	VAR	vl target velocity (1)	INTEGER16	rw	M
6043h	VAR	vl velocity demand (1)	INTEGER16	ro	M
6044h	VAR	vl control effort(1)	INTEGER16	ro	M
6046h	ARRAY	vl velocity min max amount	UNSIGNED32	rw	M
6048h	RECORD	vl velocity acceleration	vl velocity acceleration	rw	M
6049	RECORD	vl velocity deceleration	vl velocity deceleration	rw	M
6060h	VAR	Modes of operation (2)	INTEGER8	rw	M
6061h	VAR	Modes of operation display	INTEGER8	ro	M

(1) The unit of measure for objects 6042h, 6043h, 6044h is expressed in rpm

(2) Object 6060h is only available in that it is mandatory. As the drive only supports Velocity Mode, the value of this object is not modifiable.

The device operates as a DS402 state machine (refer to CiA DSP 402 V 2.0, section 10.1.1) :







**GEFRAN BENELUX**  
 Lammerdries-Zuid, 14A  
 B-2250 OLEN  
 Ph. +32 (0) 14248181  
 Fax. +32 (0) 14248180  
 info@gefran.be

**GEFRAN BRASIL ELETROELETRÔNICA**  
 Avenida Dr. Altino Arantes,  
 377/379 Vila Clementino  
 04042-032 SÃO PAULO - SP  
 Ph. +55 (0) 1155851133  
 Fax +55 (0) 1132974012  
 gefran@gefran.com.br

**GEFRAN DEUTSCHLAND**  
 Philipp-Reis-Straße 9a  
 63500 SELIGENSTADT  
 Ph. +49 (0) 61828090  
 Fax +49 (0) 6182809222  
 vertrieb@gefran.de

**SIEI AREG - GERMANY**  
 Gottlieb-Daimler-Straße 17/3  
 D-74385 Pleidelsheim  
 Ph. +49 7144 89 736 0  
 Fax +49 7144 89 736 97  
 info@sieiareg.de

**GEFRAN ESPAÑA**  
 Josep Pla, 163 2º-6º  
 08020 BARCELONA  
 Ph. +34 934982643  
 Fax +34 932662713  
 comercial.espana@gefran.es

**GEFRAN FRANCE**  
 4, rue Jean Desparmet - BP 8237  
 69355 LYON Cedex 08  
 Ph. +33 (0) 478770300  
 Fax +33 (0) 478770320  
 commercial@gefran.fr

**GEFRAN SUISSE SA**  
 Rue Fritz Courvoisier 40  
 2302 La Chaux-de-Fonds  
 Ph. +41 (0) 329684955  
 Fax +41 (0) 329683574  
 office@gefran.ch

**GEFRAN - UK Ltd.**  
 7 Pearson Road, Central Park  
 TELFORD, TF2 9TX  
 Ph. +44 (0) 845 2604555  
 Fax +44 (0) 845 2604556  
 sales@gefran.co.uk

**GEFRAN Inc.**  
**Sensors and Automation**  
 8 Lowell Avenue  
 WINCHESTER - MA 01890  
 Toll Free 1-888-888-4474  
 Ph. +1 (781) 7295249  
 Fax +1 (781) 7291468  
 info@gefraninc.com

**Motion and Drive Products**  
 14201 D South Lakes Drive  
 CHARLOTTE - NC 28273  
 Ph. +1 704 3290200  
 Fax +1 704 3290217  
 salescontact@sieiamerica.com

**GEFRAN SIEI - ASIA**  
 Blk. 30 Loyang way  
 03-19 Loyang Industrial Estate  
 508769 SINGAPORE  
 Ph. +65 6 8418300  
 Fax. +65 6 7428300  
 info@gefransiei.com.sg

**GEFRAN SIEI Electric Pte Ltd**  
 Block B, Gr.Flr, No.155, Fu Te Xi Yi Road,  
 Wai Gao Qiao Trade Zone  
 200131 Shanghai - CHINA  
 Ph. +86 21 5866 7816  
 Ph. +86 21 5866 1555  
 info@gefransiei.com.cn

**GEFRAN SIEI Drives Technology**  
 No.1265, Beihe Road,  
 Jiading District  
 201821 Shanghai - CHINA  
 Ph. +86 21 69169898  
 Fax +86 21 69169333  
 info@gefransiei.com.cn

**GEFRAN INDIA Pvt. Ltd.**  
 Survey No: 182/1 KH, Bhukum,  
 Paud road, Taluka - Mulshi,  
 Pune - 411 042. MH, INDIA  
 Ph:+91-20-3939 4400  
 Fax: +91-20-3939 4401  
 gefran.india@gefran.in

# GEFRAN

## GEFRAN S.p.A.

Via Sebina 74  
 25050 Provaglio d'Iseo (BS) ITALY  
 Ph. +39 030 98881  
 Fax +39 030 9839063  
 info@gefran.com  
 www.gefran.com

**Drive & Motion Control Unit**  
 Via Carducci 24  
 21040 Gerenzano [VA] ITALY  
 Ph. +39 02 967601  
 Fax +39 02 9682653  
 infomotion@gefran.com

**Technical Assistance :**  
 technohelp@gefran.com

**Customer Service :**  
 motioncustomer@gefran.com  
 Ph. +39 02 96760500  
 Fax +39 02 96760278

**Manuale ADL200 ASY FP -EN**  
 Rev. 0.2 -22-9-2010



1S9ACEN